



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI NF 100. You'll find the answers to all your questions on the DELONGHI NF 100 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual DELONGHI NF 100**  
**User guide DELONGHI NF 100**  
**Operating instructions DELONGHI NF 100**  
**Instructions for use DELONGHI NF 100**  
**Instruction manual DELONGHI NF 100**

## Important safeguards

- Use this appliance only as described in this instruction manual. As with any electrical appliance, the instructions aim to cover as many eventualities as possible. Caution and common sense should be used when operating and installing the air conditioner.
- This appliance has been manufactured to cool and dehumidify domestic environments and should not be used for other purposes.
- It is dangerous to alter or modify the unit's characteristics in any way.
- The appliance must be installed in line with the relevant national legislation.
- Should repairs be necessary, contact the nearest authorized De'Longhi Repair Service Center. Unauthorized Delonghi servicing can be dangerous.
- This appliance is to be used by adults only; keep away from children.
- In the case that the power cord becomes damaged, this must be substituted only by specialized personnel authorized by the manufacturer, to protect against fire.
- Always ensure the appliance is grounded. If you have any doubts check with a qualified electrician.
- We strongly discourage the use of an extension cord due to potential safety hazards. For temporary situations, use only CSA certified and UL Listed 3-wire grounded extension cord, rated 15 A, 125 V.
- Before cleaning or maintenance operations, always unplug the unit from the outlet.
- Do not pull on or place strain on the power cord when moving the appliance.
- The appliance should not be installed where the atmosphere may contain combustible gases, oil or sulphur, or near heat sources.
- Do not rest hot or heavy objects on the appliance.
- Clean the filters at least once a week.
- Avoid using heaters near the unit.
- The unit should be transported in a vertical position. If this is not possible secure the unit at an angle, do not lie it horizontally.
- Before transporting the unit, drain the unit. After transportation, wait at least 1 hour before switching the unit on.
- The packaging materials can be recycled. You are therefore recommended to place them in the special containers for differentiated waste collection.
- This appliance is fitted with a special safety device. When the compressor switches off, this device prevents it from switching on again for at least 3 minutes.
- **WARNING:** Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause (cancer, and) birth defects or other reproductive harm. Wash hands after handling.

**SAVE THESE INSTRUCTIONS**  
**THIS PRODUCT IS FOR HOUSEHOLD ONLY**

### DESCRIPTION

1 air outlet grille	11 wall flange
2 control panel	12 air exhaust hose
3 castors	13 accessory for wall mounting
4 handles	14 window bracket grille
5 filter	15 window bracket cap
6 evaporator air intake grille	16 window bracket
7 air exhaust hose housing	17 6 screws
8 condenser air intake grille	18 window outlet
9 power cable	19 rubber pipe
10 drainage hose	20 remote control

4



[You're reading an excerpt. Click here to read official DELONGHI NF 100 user guide](http://yourpdfguides.com/dref/3392996)

<http://yourpdfguides.com/dref/3392996>

**Manual abstract:**

As with any electrical appliance, the instructions aim to cover as many eventualities as possible. Caution and common sense should be used when operating and installing this air conditioner. · This appliance has been manufactured to cool and dehumidify domestic environments and should not be used for other purposes. · It is dangerous to alter or modify the unit's characteristics in any way. · The appliance must be installed in line with the relevant national legislation. · Should repairs be necessary, contact the nearest authorized De'Longhi Repair Service Center. Unauthorized Delonghi servicing can be dangerous. · This appliance is to be used by adults only; keep away from children. · In the case that the power cord becomes damaged, this must be substituted only by specialized personnel authorized by the manufacturer, to protect against fire. · Always ensure the appliance is grounded.

If you have any doubts check with a qualified electrician. · We strongly discourage the use of an extension cord due to potential safety hazards.

· Do not rest hot or heavy objects on the appliance. · Clean the filters at least once a week. · Avoid using heaters near the unit.

· The unit should be transported in a vertical position. If this is not possible secure the unit at an angle, do not lie it horizontally. · Before transporting the unit, drain the unit. After transportation, wait at least 1 hour before switching the unit on. · The packaging materials can be recycled.

You are therefore recommended to place them in the special containers for differentiated waste collection. · This appliance is fitted with a special safety device. When the compressor switches off, this device prevents it from switching on again for at least 3 minutes. · **WARNING:** Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause [cancer, and] birth defects or other reproductive harm. Wash hands after handling. **SAVE THESE INSTRUCTIONS THIS PRODUCT IS FOR HOUSEHOLD ONLY DESCRIPTION** 1 air outlet grille 2 3 4 5 6 7 8 9 10 4 control panel castors handles filter evaporator air intake grille air exhaust hose housing condenser air intake grille power cable drainage hose 11 12 13 14 15 16 17 18 19 20 wall flange air exhaust hose accessory for wall mounting window bracket grille window bracket cap window bracket 6 screws window outlet rubber pipe remote control Pre p a r i n g f o r u s e **ELECTRICAL CONNECTIONS** Before plugging the appliance into the mains socket, check that: · The mains power supply corresponds to the value indicated on the rating plate on the back of the appliance; · The mains socket and electrical circuit are adequate for the appliance; · The mains socket matches the plug. If this is not the case, have the plug replaced; · The mains socket is adequately earthed. Failure to follow these important safety instructions absolves the manufacturer of all liability. The power cable must be replaced by a qualified professional only. **GB** The instructions below will enable you to prepare your air conditioner for operation as efficiently as possible.

Before use, make sure the air intake and outlet grilles are unobstructed. **AIR-CONDITIONING WITHOUT INSTALLATION** Just a few simple steps and your comfort is ensured with your air conditioner: · Fit the air exhaust hose 7 12 in the housing C D at the back of the appliance. Insert it as shown in figure A. · Once the bracket is extended, it can be locked into his width by tightening the two screws provided. · Close the window (fig. D). · Place the air conditioner near the window. Insert the exhaust hose 12 into the window bracket grille 14 (fig. E). Make A Sash window · Attach the window bracket grille 14 to the window bracket 16 with the four screws provided 17 (fig.

B). sure the air exhaust hose is unobstructed. E B · When not used, the window bracket can be closed off with the cap 15 provided. · Open the window. · Place the window bracket 16 in the window, extending it to fit the width of the window (fig.

C). Keep the air hoses as short and free of curves as possible to avoid constrictions. 5 Pre p a r i n g f o r u s e French window · Attach the window outlet 18 exhaust hose 12 (fig. F)..

to the air Respect the height and dimensions of the hole given in figure I. 2 1 F · Open the French window slightly and position the outlet 12. as shown in figure G in the window pane I in the wooden kickboard of a French window in the wall: you are recommended to insulate the section of wall using suitable insulation. · Fit the wall flange 11 into the hole. · Fit the air exhaust hose 7 in the relevant hose located on the rear side of the appliance. (fig. A page 5). · Remove the plastic end of the hose 1 12 by unscrewing it and 2 in its place screw the wall mounting accessory 13 (fig. J). · Fit the end of the hose 12 to the wall flange 11 as shown in fig.

K. G Keep the air hoses as short and free of curves as possible to avoid constrictions. **SEMI-PERMANENT INSTALLATION** If required, your appliance can also be installed semi-permanently (Fig. @@@@The display shows the room temperature. @@@@Remember that the higher the speed, the more air is filtered. @@In this mode the room temperature can be slightly increased. 1. In this mode do not use the air exhaust hose. 2. @@@@3. @@L). @@Important: While in operation, the appliance vibrates. @@@@This avoids wasting electricity by optimizing operating periods. @@@@. Press the timer button (D). The timer light "H" flashes.

@@ · The time increases or decreases in steps of one hour. The indicator light (H) flashes until the appliance starts up. You can set the appliance to come on with a delay of up to 12 hours. To cancel the timer programme, press the timer button (D) again. Light (H) stops flashing.

@@ · Press the timer button (D). The timer light "H" flashes. @@The time increases or decreases in steps of one hour. The light (H) flashes until the appliance turns off as programmed. @@To cancel the timer programme, press the timer button (D) again. @@ · The remote control should be handled with extreme care and respect. Do not drop it, expose it to direct sunlight, or leave it near sources of heat. **DESCRIPTION OF THE REMOTE CONTROL** 21) "ON/OFF" button 22) "MODE" button 23) Programmed operation temperature increase button 24) Programmed operation temperature decrease button 25) "TIMER" button 26) Fan speed selection button (HIGH/MED/LOW). Replacing the batteries · Remove the cover on the rear of the remote control; · Replace the old batteries with two new LR03 "AAA" 1.5V batteries, inserting them correctly (see the instructions inside the battery compartment); · Replace the cover.



[You're reading an excerpt. Click here to read official DELONGHI NF 100 user guide](http://yourpdfguides.com/dref/3392996)

<http://yourpdfguides.com/dref/3392996>

If the remote control unit is replaced or discarded, the batteries must be removed and disposed of in accordance with current legislation as they are harmful to the environment. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Do not dispose of batteries in fire. Batteries may explode or leak. 21 26 25 22 23 24 **TURNING THE APPLIANCE ON** Plug the appliance into the mains. Press the **ON/OFF** button (21) (when turned on, the air conditioner starts operating in the same mode as when it was turned off). Press the **MODE** button (22) to select the required mode **COOLING DEHUMIDIFYING FAN ONLY** On the control panel, the light corresponding to the selected mode comes on. For air coce is full. · empty the tank by means of the hose on the back of the appliance (see "End of season operations on page 12).

13 **Technical specification TECHNICAL SPECIFICATION** Power supply voltage Max. absorbed power during air conditioning Refrigerant Cooling capacity see rating plate " " " **LIMIT CONDITIONS** Room temperature for air conditioning 69.8 ÷ 95°F (21 ÷ 35°C) Appliance dimensions: · width 18.1 inc. · height 32.

9 inc. · depth 12.5 inc. · weight 79.4 Lbs 460 mm 840 mm 320 mm 36 kg Transport, filling, cleaning, recovery and disposal of refrigerant should be performed by a technical service centre appointed by the manufacturer only.

The appliance should be disposed of by a specialist centre appointed by the manufacturer only. **NEVER TURN THE APPLAIANCE UPSIDE DOWN OR ON ITS SIDE. IF THIS OCCURS, WAIT AT LEAST 1 HOURS BEFORE TURNING THE APPLIANCE ON SAFETY PLUG** The appliance is fitted with a safety plug to protect the power cable. If power is cut off, unplug from the mains and make sure the power cable is undamaged. If the cable is damaged, call the service center immediately. If power cuts off frequently and the power cable is undamaged, contact a qualified electrician. **OPERATION OF THE SAFETY PLUG** If the safety device incorporated in the plug trips and cuts off the power supply, check that the power cable and plug are not damaged. If the power cable is undamaged, to restore operation press the "RESET" button. To verify correct operation of the plug, press the "TEST" button periodically and make sure the appliance disconnects. If this is not the case, contact the service center.

To restore operation, press the "RESET" button. 14 **Limited Warranty De'Longhi** is the distributor of Kenwood home appliances. This warranty applies to all home appliances with De'Longhi or Kenwood brand names. **FOR CONTIGUOUS UNITED STATES ONLY GB Limited Warranty** We warrant each De'Longhi **AIR CONDITIONER** to be free from defects in material and workmanship. From the purchase date, our obligation under this warranty is to provide one (1) year free parts and labor on the entire **AIR CONDITIONER**, with an additional four (4) years free on any part of the sealed system consisting of the compressor, evaporator, condenser and factory connected refrigerant tubing. @@@@This warranty is in lieu of all other warranties and representations, expressed or implied, and all other obligations or liabilities on our part. We do not authorize any other person or company to assume for us any liability in connection with the sale or use of our **AIR CONDITIONER**. This warranty shall not apply to any **AIR CONDITIONER** that has been repaired or altered outside our factory nor shall it apply to any **AIR CONDITIONER** that has been subjected to misuse, negligence or accidents. If repairs become necessary, see contact information below: U.S.

Residents: Please contact our toll free hotline at 1-800-322-3848 or log onto our website at [www.delonghi.com](http://www.delonghi.com). For all accessories, spare parts or replacement parts, please contact our parts division at 1-800-865-6330. CANADA Residents: Please contact our toll free hotline at 1-888-335-6644 or log onto our website at [www.delonghi.com](http://www.delonghi.com).

Other countries: Please visit: [www.delonghi.com](http://www.delonghi.com).



[You're reading an excerpt. Click here to read official DELONGHI NF 100 user guide](http://yourpdfguides.com/dref/3392996)  
<http://yourpdfguides.com/dref/3392996>