



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI NF 190. You'll find the answers to all your questions on the DELONGHI NF 190 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DELONGHI NF 190
User guide DELONGHI NF 190
Operating instructions DELONGHI NF 190
Instructions for use DELONGHI NF 190
Instruction manual DELONGHI NF 190

Important safeguards

GB

- This appliance is designed for home air conditioning and must not be used for other purposes.
- It is dangerous to modify or alter the characteristics of the appliance in any way.
- The appliance must be installed in conformity with legislation in force in the country concerned.
- If the appliance requires repair, contact a Service Centre authorised by the manufacturer only. Repairs carried out by unauthorised personnel may be dangerous.
- If the power cable is damaged, it must be replaced by the manufacturer, an authorised service centre or a qualified electrician in order to eliminate all risk.
- This appliance must be used exclusively by adults.
- Do not allow children or unfit persons to use the appliance without adequate supervision.
- Do not allow children to play with the appliance.
- The appliance must be connected to an efficient earth system. Have your electrical circuit checked by a qualified electrician.
- Do not use extension cables.
- Before cleaning or maintenance operations, always unplug the appliance from the mains socket.
- Do not move the appliance by pulling the power cable.
- Do not install the appliance in rooms containing gas, oil or sulphur. Do not install near sources of heat.
- Do not rest heavy or hot objects on top of the appliance.
- Clean the anti-microbial filter at least once a week.
- Avoid using heating appliances near the air conditioner.
- Always transport the appliance upright or resting on one side.
- Use the appliance as described in this instruction manual only.
- As with all electrical equipment, whilst the instructions aim to cover as many eventualities as possible, caution and common sense should be applied when operating and installing this appliance.
- At the end of its working life, take the appliance to a special collection centre.
- The materials used for packaging can be recycled. You are therefore recommended to dispose of them in special differentiated waste collection containers.
- The refrigerant gas R407c conforms to EC regulations on the environment. Avoid perforating the refrigerant circuit of the appliance.
- Keep the appliance at least 50 cm away from flammable substances (alcohol etc) or pressurised containers (e.g. aerosol cans).

DESCRIPTION

- | | |
|--------------------------------|---|
| 1 air outlet grille | 8 condenser air intake grille |
| 2 control panel | 9 power cable |
| 3 castors | 10 drain hose cap |
| 4 handles | 11 flange with cap |
| 5 filter | 12 air exhaust hose |
| 6 evaporator air intake grille | 13 window outlet |
| 7 air exhaust hose housing | 14 remote control unit (some models only) |



[You're reading an excerpt. Click here to read official DELONGHI NF 190 user guide](http://yourpdfguides.com/dref/3387292)
<http://yourpdfguides.com/dref/3387292>

Manual abstract:

It is dangerous to modify or alter the characteristics of the appliance in any way. The appliance must be installed in conformity with legislation in force in the country concerned. @@Repairs carried out by unauthorised personnel may be dangerous. @@This appliance must be used exclusively by adults. @@Do not allow children to play with the appliance. The appliance must be connected to an efficient earth system. Have your electrical circuit checked by a qualified electrician. Do not use extension cables. @@Do not move the appliance by pulling the power cable. Do not install the appliance in rooms containing gas, oil or sulphur.

Do not install near sources of heat. Do not rest heavy or hot objects on top of the appliance. Clean the anti-microbial filters at least once a week. Avoid using heating appliances near the air conditioner. Always transport the appliance upright or resting on one side.

Use the appliance as described in this instruction manual only. As with all electrical equipment, whilst the instructions aim to cover as many eventualities as possible, caution and common sense should be applied when operating and installing this appliance. At the end of its working life, take the appliance to a special collection centre. The materials used for packaging can be recycled. You are therefore recommended to dispose of them in special differentiated waste collection containers.

The refrigerant gas R407c conforms to EC regulations on the environment. Avoid perforating the refrigerant circuit of the appliance. Keep the appliance at least 50 cm away from flammable substances (alcohol etc) or pressurised containers (e.g. aerosol cans). DESCRIPTION 1 air outlet grille 2 3 4 5 6 7 control panel castors handles filter evaporator air intake grille air exhaust hose housing 8 9 10 11 12 13 14 condenser air intake grille power cable drain hose cap flange with cap air exhaust hose window outlet remote control unit (some models only) 15 Pre p a r i n g f o r u s e ELECTRICAL CONNECTIONS Before plugging the appliance into the mains socket, check that: · The mains power supply corresponds to the value indicated on the rating plate on the back of the appliance; · The mains socket and electrical circuit are adequate for the appliance; · The mains socket matches the plug. If this is not the case, have the plug replaced; · The mains socket is adequately earthed. Failure to follow these important safety instructions absolves the manufacturer of all liability. The power cable must be replaced by a qualified professional only. The instructions below will enable you to prepare your air conditioner for operation as efficiently as possible.

Before use, make sure the air intake and outlet grilles are unobstructed. AIR-CONDITIONING WITHOUT INSTALLATION Just a few simple steps and your comfort is ensured with your air conditioner: · Fit the air exhaust hose 7 12 in the housing · Open the window or French window slightly and position the outlet as shown in figure B 13 . at the back of the appliance. Keep the air hoses as short and free of curves as possible to avoid constrictions. Insert it as shown in figure A. 2 1 · Unscrew the plastic end of the air exhaust hose 12 and screw on the window outlet 13 . · Place the air conditioner near a window or French window. · Make sure the air exhaust hose is unobstructed. B 16 Pre p a r i n g f o r u s e AIR-CONDITIONING WITH INSTALLATION If required, your appliance can also be installed semi-permanently (Fig. C).

@@(fig. A page 16). @@@@NOTE. @@@@The display shows the room temperature. @@@@Remember that the higher the speed, the more air is filtered.

@@When the dehumidifying mode is selected, the light (P) comes on. At the same time, the "MIN" fan speed light (M) comes on. @@This avoids wasting electricity by optimising operating periods. @@@@ · Press the timer button (D). The timer light "H" flashes.

@@ · The time increases or decreases in steps of one hour. The indicator light (H) flashes until the appliance starts up. You can set the appliance to come on with a delay of up to 12 hours. To cancel the timer programme, press the timer button (D) again. Light (H) stops flashing. @@ · Press the timer button (D). The timer light "H" flashes. @@The time increases or decreases in steps of one hour. The light (H) flashes until the appliance turns off as programmed. @@To cancel the timer programme, press the timer button (D) again.

@@ · The remote control should be handled with extreme care and respect. Do not drop it, expose it to direct sunlight, or leave it near sources of heat. GB DESCRIPTION OF THE REMOTE CONTROL 15) "ON/OFF" button 16) "MODE" button 17) Programmed operation temperature increase button 18) Programmed operation temperature decrease button 19) "TIMER" button 20) Fan speed selection button (MAX/MED/MIN). Replacing the batteries · Remove the cover on the rear of the remote control; · Replace the old batteries with two new LR03 "AAA" 1.5V batteries, inserting them correctly (see the instructions inside the battery compartment); · Replace the cover. If the remote control unit is replaced or discarded, the batteries must be removed and disposed of in accordance with current legislation as they are harmful to the environment. 15 20 19 16 17 18 TURNING THE APPLIANCE ON Plug the appliance into the mains. Press the ON/OFF button (15) (when turned on, the air conditioner starts operating in the same mode as when it was turned off). Press the MODE button (16) to select the required mode COOLING DEHUMIDIFYING FAN ONLY On the control panel, the light corresponding to the selected mode comes on. For air conditioning/dehumidifying/fan only settings and programming the timer, see page 18-19.

21 Tips To get the best from your air conditioner, follow these recommendations: · close the windows and doors in the room to be air conditioned. The only exception is when the appliance is installed through a hole in the wall. In this case, you are recommended to leave a slight draught through a door or window to guarantee correct ventilation. · Never use the appliance in very damp rooms (laundries for example). · Never use the appliance outdoors. close doors and windows · Protect the room from direct exposure to the sun by partially closing curtains and/or blinds to make the appliance much more economical to run; · Never rest objects of any kind on the air conditioner; · Never obstruct the air intake 6 or outlet 1 grilles; · Make sure there are no heat sources in the room. close blinds or curtains · Make sure the air conditioner is on a level floor. do not cover the appliance 22 Cleaning Before cleaning or maintenance, turn the appliance off by pressing the ON/OFF button (A) or in models with remote control unit, by pressing the ON/OFF button 15 , then always unplug the appliance from the mains socket.



[You're reading an excerpt. Click here to read official DELONGHI NF 190 user guide](http://yourpdfguides.com/dref/3387292)
<http://yourpdfguides.com/dref/3387292>

@@For safety reasons, never wash the air conditioner with water. @@Never spray insecticide liquids or similar.

@@The filter is housed in the intake grille. @@If it is very dirty, immerse in warm water and rinse a number of times. The water should never be hotter than 40°C. After washing, leave the filter to dry. Put the filter back in its housing. START OF SEASON CHECKS Make sure the power cable and plug are undamaged and the earth system is efficient. Follow the installation instructions precisely. END OF SEASON OPERATIONS To drain all water from.



[You're reading an excerpt. Click here to read official DELONGHI NF
190 user guide](http://yourpdfguides.com/dref/3387292)

<http://yourpdfguides.com/dref/3387292>