



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DENON AH-NCW500. You'll find the answers to all your questions on the DENON AH-NCW500 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DENON AH-NCW500
User guide DENON AH-NCW500
Operating instructions DENON AH-NCW500
Instructions for use DENON AH-NCW500
Instruction manual DENON AH-NCW500

DENON
GLOBE CRUISER™

AH-NCW500
On-Ear Headphones / Wireless Headphones

Owner's Manual



[You're reading an excerpt. Click here to read official DENON AH-NCW500 user guide](http://yourpdfguides.com/dref/5155197)
<http://yourpdfguides.com/dref/5155197>

Manual abstract:

Denon's engineers have taken great care to design and develop these headphones to provide you with the best-in-class personal listening experience. Please refer to this guide for assistance when using these headphones. Contents

Getting started.....1
Accessories.....1 Features.....1
Functions.....2 Preparation for Use.....2 Charging the battery.....2
Pairing with a Bluetooth device.....3 Turning Bluetooth Wireless Connectivity On.....4
Adjusting the fit of the headphones.....4 Listening to Music.....5
Listening to music using Bluetooth.....5 Listening to music using the audio cable.....5
Operating the Noise Cancelling function to block out ambient noise.....5 Conducting Phone Calls.....6
Making a call.....6 Answering an incoming call.....6 Using the call waiting function.....6
Ending a call.....6 Ignoring an incoming call.....6 Switching from headphones to the mobile phone during a call.....6
Other operations.....6 Additional Information.....7 Overview of LED indicator display patterns.....7
Airplane use.....·itted and the red and blue LED indicators will flash simultaneously five times.



[You're reading an excerpt. Click here to read official DENON AH-NCW500 user guide](http://yourpdfguides.com/dref/5155197)
<http://yourpdfguides.com/dref/5155197>

off, press and hold the Bluetooth button for approx. 4 seconds. • The red and blue LED indicators will alternately flash, and the headphones will enter pairing standby mode. • If the Bluetooth function is on, turn it off (vpage 4 “Turning Bluetooth Wireless Connectivity On”). on Bluetooth device 2 Initiate pairing procedures for the headphones. to be connected, and search the • @@@@ • The blue LED indicator will light up for approx. @@ 1 second. • A beeping sound will be emitted and the red and blue LED indicators will light up simultaneously for approx. 1 second. • The power switches on, and the Bluetooth function switches on. • Bluetooth is automatically connected if the headphones and Bluetooth device have already been paired (vpage 3 “Pairing with a Bluetooth device”). Adjust the slider length to fit your head when wearing the headphones.

nnTurning Bluetooth Wireless Connectivity Off NOTE • Please read the attached “Precautions on the use of headphones” documentation. • Avoid getting your fingers or other body parts caught in the product’s moving portions. • Do not pull forcefully on the sliders. There are 2 ways of turning the Bluetooth wireless connectivity off: 1) connect the audio cable (included) to the audio input jack on the left ear cup. This automatically turns Bluetooth off and power switches to standby status.

OR; 2) Press and hold the Bluetooth button for approx.. 5 seconds or more.... • A beeping sound will be emitted and the red and blue LED indicators will light up simultaneously for approx. 1 second. • The power then switches to a standby status, and the Bluetooth function switches off. • If an audio cable is connected to the headphones while the Bluetooth function is on (power is on), the Bluetooth function automatically switches off (power switches to standby status). @@@@ • These headphones are compatible with SCMS-T copy protection. @@@@ • The noise cancelling function may not operate properly for certain portable devices with digital amplifiers, etc. The blue LED indicator will light up continuously during playback.

@@ You cannot increase the volume any more. @@@@ Issue Bluetooth function will not turn on. Cannot perform pairing. Cannot establish Bluetooth connection. @@@@ 3 • Pair devices again. 5 • If the headphones and Bluetooth device are connected using the audio cable, disconnect the cable. The headphones’ Bluetooth function will turn off automatically when it is connected using the audio cable. 4 Sound cannot be heard @@ 3, 4 through the headphones • Confirm that the Bluetooth device to be connected is turned on and its Bluetooth function is during Bluetooth activated. 5 connection. • Select the A2DP profile on the transmitting Bluetooth device.

@@- • Confirm that the connected Bluetooth device’s audio playback has been initiated. 5 • Increase the volume level. If necessary, increase the volume level on the connected Bluetooth audio device. 3 • Pair devices again. 5 Cannot operate connected • If the headphones and Bluetooth device are Bluetooth device using connected using the audio cable, disconnect the headphone controls.

cable. The headphones’ Bluetooth function will turn off automatically when it is connected using the audio cable. – • Reset the headphones by inserting a paperclip or similar object into the hole behind the ear pad and pressing the reset button inside. Reset the headphones by removing the ear pad and then using a paperclip or similar object Reset button to press the reset button (see the figure on the right). @@@ 3, 4 during phone call.

@@@@ @ 5 • Increase the call volume level. – • Increase the volume level on the connected Bluetooth-compatible mobile phone if necessary.

Remove the cable and plug, fold up the headphones and place them in the case. nnFor even more compact storage Detach the ear pads as shown in the illustration, then close the carrying case’s outer fastener. Place the detached ear pads in the available space inside the case. q q w q NOTE w q Do not force the headphones into the case, as doing so may damage them. 8 Additional Information Precautions on use of the headphones • Make sure to read the owner’s manual for the device to be connected to the headphones. • To avoid disturbing others around you, be aware of the headphones’ volume level when using public transportation or when in a public place. • This product does not guarantee successful operation of this product together with all Bluetooth devices and mobile phones. • This product does not support connection with all Bluetooth devices and mobile phones.

@@@@ @ 2.5 mW (Class 2) Approx. 10 m (varies according to usage Transmission range conditions) A2DP (audio) Supported Bluetooth AVRCP (audio control) profiles HSP (headset) HFP (hands-free) A2DP codec support AAC, aptX, SBC Max. no. of registered Max. 8 devices pairings Driver type Dynamic type Driver size ϕ 40 mm Input impedance 100 Ω (when power is on) Playback frequency 5 to 37,000 Hz Using Bluetooth and noise cancelling Continuous playback functions: 10 hours Using only Bluetooth function: 15 hours time Using only noise cancelling function: 25 hours Continuous standby Max. approx. 300 hours time Max. approx. 15 hours (when noise Cancelling is off) Operating Temp. : 5 °C to 40 °C temperature range DC 3.7 V built-in rechargeable lithium Power supply polymer battery Weight 305 g The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by D&M Holdings Inc. is under license. Other trademarks and trade names are those of their respective owners.

The CSR logo is a trademark of CSR plc or one of its group companies. 9 V00 www.denon.com D&M Holdings Inc. 5411 10890 00AD .



[You're reading an excerpt. Click here to read official DENON AH-NCW500 user guide](http://yourpdfguides.com/dref/5155197)