



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DENON DNP-720AE. You'll find the answers to all your questions on the DENON DNP-720AE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DENON DNP-720AE
User guide DENON DNP-720AE
Operating instructions DENON DNP-720AE
Instructions for use DENON DNP-720AE
Instruction manual DENON DNP-720AE

SVENSKA NEDERLANDS ESPAÑOL ITALIANO FRANÇAIS DEUTSCH ENGLISH

DENON

NETWORK AUDIO PLAYER

DNP-720AE

Owner's Manual
Bedienungsanleitung
Manuel de l'Utilisateur
Manuale delle istruzioni
Manual del usuario
Gebbruiksaanwijzing
Bruksanvisning



[You're reading an excerpt. Click here to read official DENON DNP-720AE user guide](http://yourpdfguides.com/dref/5161334)
<http://yourpdfguides.com/dref/5161334>

Manual abstract:

Clean only with dry cloth. Do not block any ventilation openings. install in accordance with the manufacturer's instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 9. 10. Only use attachments/accessories specified by the manufacturer. 11. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.

12. Unplug this apparatus during lightning storms or when unused for long periods of time. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. 14. Allow for sufficient heat dispersion when installed in a rack.

• Handle the power cord carefully. Hold the plug when unplugging the cord. □ Keep the unit free from moisture, water, and dust. □ Unplug the power cord when not using the unit for long periods of time. □ Do not obstruct the ventilation holes.

□ Do not let foreign objects into the unit. □ Do not let insecticides, benzene, and thinner come in contact with the unit. □ Never disassemble or modify the unit in any way. □ Ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths or curtains.

Do not expose the unit to dripping or splashing fluids. □ Do not handle the mains cord with wet hands. Do not use the unit with damaged power cords. Do not use the unit with damaged power cords. When discarding the unit, comply with local rules or regulations. This product and the supplied accessories, excluding the batteries, constitute the applicable product according to the WEEE directive. **IMPORTANT NOTICE: DO NOT MODIFY THIS PRODUCT** This product, when installed as indicated in the instructions contained in this manual, meets R&TTE directive requirements.

Modification of the product could result in hazardous Radio and EMC radiation. Do not place any other equipment on this unit. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone, may affect wireless performance. Copyright (C) 2000,2001,2002,2003,2004,2005,2006,2007,2008,2009 Josh Coalson Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: • Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. □ Neither the name of the Xiph. .



[You're reading an excerpt. Click here to read official DENON](#)

[DNP-720AE user guide](#)

<http://yourpdfguides.com/dref/5161334>