



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR 11 IN 1 MEGA BUNDLE. You'll find the answers to all your questions on the DREAMGEAR 11 IN 1 MEGA BUNDLE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual DREAMGEAR 11 IN 1 MEGA BUNDLE**  
**User guide DREAMGEAR 11 IN 1 MEGA BUNDLE**  
**Operating instructions DREAMGEAR 11 IN 1 MEGA BUNDLE**  
**Instructions for use DREAMGEAR 11 IN 1 MEGA BUNDLE**  
**Instruction manual DREAMGEAR 11 IN 1 MEGA BUNDLE**



[You're reading an excerpt. Click here to read official DREAMGEAR 11 IN 1 MEGA BUNDLE user guide](http://yourpdfguides.com/dref/3687584)  
<http://yourpdfguides.com/dref/3687584>

**Manual abstract:**

2. Pull the wrist strap through the hole and insert the bottom of the controller into the bottom part of the Shield. 3. Secure the top part of the controller by pushing the controller towards the cradle until it snaps into place. 4. @@@@How to Insert the PlayStation Move motion controller into the Remote Cradle: NOTE: Make sure that the wrist strap that is included with the PlayStation Move motion controller is being used. @@ 1. Insert the end of the wrist strap on the PlayStation Move motion controller into the hole at the bottom of the Remote Cradle. 2. Pull the wrist strap through the hole and insert the bottom of the controller into the bottom part of the Remote Cradle.

3. Secure the top part of the controller by pushing the controller towards the cradle until it snaps into place. 4. To remove the controller, push the controller from the hole located on the back of the Remote Cradle. How to Install an Extension onto the Remote Cradle (Table Tennis or Sword): 1.

To attach each extension, place the bottom of the extension to the Remote Cradle. The small pegs on the top of the Remote Cradle should fit into the gaps of the bottom of the extension. @@ 3. Turn the extension counter-clockwise until you hear a clicking sound. @@NOTE: Do not use the extension if it does not lock into place.

@@@ how to Set Up the Motion Blaster: 1. @@@Place each hand into a glove. @@@@ 5. @@@Once fully charged, the LED charge indicator will light solid BLUE. @@Make sure that the Quad Dock Pro is powered OFF when not in use. @@@@When you are swinging the Remote Cradle with an extension attached, be aware of your surroundings, making sure not to hit anyone or anything. To prevent injury and property damage, make sure the PlayStation Move motion controller is properly and securely attached to your Remote Cradle and that you are a reasonable distance from your television and any people around you. The accessories included are designed for gaming ONLY and should never be used to strike people, objects or other accessories. Always use your PlayStation Move motion controller wrist straps when using the accessories included. Once the top of the Motion Blaster is up, place the PlayStation®MOVE motion controller into the Motion Blaster.

NOTE: Make sure that you insert the wrist strap into the hole located at the back of the Motion Blaster before inserting the PlayStation Move motion controller. 4. Align the Start and Select button with the buttons on the side of the Motion Blaster and close the top of the blaster. 5. @@ 6. @@@Plug the included 110/240 volt AC adapter into the DC port located on the back of the Quad Dock Pro. 2. Plug the other end of the AC adapter to a standard wall outlet. 3. To charge an original DualShock3 or SIXAXIS controller, turn the controller upside down and place the controller on the mini-USB port located on the front of the charger.



[You're reading an excerpt. Click here to read official DREAMGEAR 11 IN 1 MEGA BUNDLE user guide](http://yourpdfguides.com/dref/3687584)  
<http://yourpdfguides.com/dref/3687584>