



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR ACTION CONTROLLER. You'll find the answers to all your questions on the DREAMGEAR ACTION CONTROLLER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DREAMGEAR ACTION CONTROLLER
User guide DREAMGEAR ACTION CONTROLLER
Operating instructions DREAMGEAR ACTION CONTROLLER
Instructions for use DREAMGEAR ACTION CONTROLLER
Instruction manual DREAMGEAR ACTION CONTROLLER

works with **Wii**

Action Controller

Action Controller
ITEM No. - DGWII-3107
UPC - 8 45620 03107 8
COLOR - White

PRODUCT FEATURES

The Action Remote Controller uses internal accelerometers to calculate directional motion and speed. It is perfect for racing games, sports games, shooting games and MORE! When used in combination with the Action Controller, the Play Controller provides extra control options (with compatible games).

ACTION REMOTE CONTROLLER

- Compatible with Nintendo® Nunchuk™
- Accelerometer for motion gaming
- Internal Rumble motors
- IR sensor
- Internal Speaker
- Compatible with MotionPLUS™
- Power ON/OFF button
- LED player indicator

PRODUCT PACKAGING

INCLUDES: Silicone Cover

FULLY COMPATIBLE WITH:

- ALL Wii GAMES
- Wii REMOTE JACKET
- Wii MOTIONPLUS
- Wii REMOTE & NUNCHUK™

INCLUDES WRIST STRAP

Requires 2 "AA" batteries (not included)

TRANSLATIONS

PACKAGING | FRENCH: Yes | SPANISH: Yes
USER GUIDE | FRENCH: Yes | SPANISH: Yes

SHIPPING INFORMATION

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (in³)	WEIGHT (lbs.)	UPC NUMBER
MASTER	25	8.75	8.25	20.00	0.95	10.80	8 45620 03107 8
INNER	4	8.50	3.75	9.00	0.13	1.80	8 45620 03107 8
SINGLE	1	5.00	8.50	1.50	0.02	0.35	8 45620 03107 8

DREAMGEAR and the DREAMGEAR logo are registered trademarks. MotionPLUS, Nintendo and Wii are either trademarks or registered trademarks of Nintendo. The product is not manufactured, assembled, tested, intended to be distributed by Nintendo of America.

©2009 iSound, Inc. All rights reserved. www.dreamgear.net | www.isound.net 22000 S. Golden Avenue, Torrance, CA 90503 Tel: 310.202.5022 | Fax: 310.202.9577



[You're reading an excerpt. Click here to read official DREAMGEAR ACTION CONTROLLER user guide](http://yourpdfguides.com/dref/3197231)
<http://yourpdfguides.com/dref/3197231>

