




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR DGPS3-1388. You'll find the answers to all your questions on the DREAMGEAR DGPS3-1388 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual DREAMGEAR DGPS3-1388
User guide DREAMGEAR DGPS3-1388
Operating instructions DREAMGEAR DGPS3-1388
Instructions for use DREAMGEAR DGPS3-1388
Instruction manual DREAMGEAR DGPS3-1388

RADIUM WIRELESS

USER'S GUIDE



dreamGEAR
www.dreamgear.net



PACKAGE CONTENTS:

- Radium Wireless Controller
- Radium USB Receiver
- User's Guide/Warranty Card
- Registration Card

SET-UP:

1. Open the battery compartment located on the bottom side of the Radium Wireless Controller. Insert 3 "AAA" batteries. Replace battery compartment cover.

NOTE: "AAA" batteries not included. Also, make sure that you use fresh batteries when playing with the Radium Wireless Controller.

2. The Radium Wireless Controller features an ON/OFF switch located on the bottom side of the controller. Switch the controller to ON.
3. With the PlayStation 3 console powered ON, plug the Radium USB Receiver into one of the USB ports located on the front of the PlayStation 3. The 4 channel indicator lights on the front of the Radium Wireless Controller will flash slowly.
4. Press the Connect button on the Radium USB Receiver. The LED on the receiver will flash rapidly.
5. Press the Menu button located on the front of the Radium Wireless Controller. The 4 channel indicators will flash rapidly. Press the Menu button again and the controller will be set to the appropriate channel. The solid LED will indicate which player position the controller is set to, Player 1, Player 2, etc.
6. To connect multiple Radium Wireless Controllers, connect each controller separately. First, connect Player 1's controller and then connect the remaining controllers, one by one.

NOTE: During gameplay, you can access the PlayStation 3 menu by holding the Menu button for 3 seconds. Please refer to the PlayStation 3 console User's Guide to see what menu options are available.

TURBO FUNCTION:

1. To activate Turbo, press any button and the Turbo button (located above the 4 channel indicator lights) at the same time to set Turbo to that specific button.
2. To cancel the Turbo function, repeat Step 1.

SLEEP MODE:

The Radium Wireless Controller features a Sleep Mode. The Radium Wireless Controller will enter Sleep Mode if one of the following occurs:

1. If the controller loses contact with the receiver for more 30 seconds.
2. 5 minutes of analog stick or button inactivity

To turn the controller on from being on Sleep Mode, simply move the analog stick or press a button on the controller.

LOW BATTERY INDICATOR:



When the batteries in the Radium Controller are lower than the standard amount needed, the LED on the 4 channel indicator lights will flash 4 times/second. If this occurs, please remove the old batteries and replace them with fresh batteries.

SIXAXIS™ TECHNOLOGY:

The Radium Wireless Controller features Sixaxis™ technology, allowing it to detect natural, real-time movements, along with input via pressure sensitive buttons, analog sticks and triggers.

The Sixaxis function only works with Sixaxis compatible software. Sixaxis must be enabled in the "Options" menu of a compatible PlayStation 3 game.

NOTE: Please refer to the game's User's Guide for information on the how to use the Sixaxis technology with that specific game.

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net



[You're reading an excerpt. Click here to read official DREAMGEAR DGPS3-1388 user guide](http://yourpdfguides.com/dref/3254289)
<http://yourpdfguides.com/dref/3254289>

Manual abstract:

The 4 channel indicator lights on the front of the Radium Wireless Controller will flash slowly. First, connect Player 1's controller and then connect the remaining controllers, one by one. NOTE: During gameplay, you can access the PlayStation 3 menu by holding the Menu button for 3 seconds. @@ 1. @@@@ 2. @@@@If this occurs, please remove the old batteries and replace them with fresh batteries. SIXAXISTM TECHNOLOGY: The Radium Wireless Controller features SixaxisTM technology, allowing it to detect natural, real-time movements, along with input via pressure sensitive buttons, analog sticks and triggers. The Sixaxis function only works with Sixaxis compatible software. sixaxis must be enabled in the "Options" menu of a compatible PlayStation 3 game. @@.



[You're reading an excerpt. Click here to read official DREAMGEAR DGPS3-1388 user guide](http://yourpdfguides.com/dref/3254289)
<http://yourpdfguides.com/dref/3254289>