



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR DGPS3-3809. You'll find the answers to all your questions on the DREAMGEAR DGPS3-3809 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DREAMGEAR DGPS3-3809
User guide DREAMGEAR DGPS3-3809
Operating instructions DREAMGEAR DGPS3-3809
Instructions for use DREAMGEAR DGPS3-3809
Instruction manual DREAMGEAR DGPS3-3809

WORKS WITH PS3 **PS MOVE**

Power Stand
Your Ultimate Charging Dock

ITEM No. - DGPS3-3809
UPC - 8 45620 03809 1
COLOR - Black

PRODUCT FEATURES

The Power Stand is a multi-functional stand that gives you the ability to charge all your controllers while keeping your PS3 Slim stable in a vertical position. You can charge up to 2 SIXAXIS™ or DUALSHOCK3 controllers, 2 PlayStationMove motion controllers and 2 PlayStationMove navigation controllers right on the stand. All docks are designed to securely fit their respective controllers and even have cutouts for wrist straps. It also has 4 powered USB ports built in to connect to the PS3 and charge other USB powered devices including controllers, headsets, mobile phones, keyboards and other accessories. The Power Stand includes a 110 /240 Volt AC adapter to allow for charging anytime even when the PS3 is powered off. And it has a submersized finish for that look and feel you will not get with any other stand.

POWER STAND

- Vertical stand for the PS3 Slim
- Dock securely holds and charges up to 2 original SIXAXIS™ or DUALSHOCK3 controllers
- Dock securely holds and charges up to 2 PlayStationMove motion controllers
- Dock securely holds and charges up to 2 PlayStationMove navigation controllers
- Cutouts in cradles to fit PlayStationMove controller wrist straps
- Includes a 110 /240 Volt AC adapter
- Connects to PS3 Slim to provide 4 additional USB ports (can sync controllers and can charge additional USB powered devices including controllers, headsets, mobile phones, keyboards and other accessories)
- LED charge indicators (Blue = Fully charged, Flashing blue and red = 95% charged, Red = charging)
- ON / OFF power switch (for charging controllers and powered USB ports individual of PS3 power)
- Rubberized finish

PRODUCT PACKAGING

TRANSLATIONS

PACKAGING | FRENCH: Yes | SPANISH: Yes
USER GUIDE | FRENCH: Yes | SPANISH: Yes

SHIPPING INFORMATION

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (ft³)	WEIGHT (lbs.)	UPC NUMBER
MASTER	15	17.75	18.00	18.5	0.30	32.85	8 45620 03809 1
INNER	2	8.75	15.25	8.75	0.60	7.65	8 45620 03809 1
SINGLE	1	8.5	14.5	2	0.14	1.80	8 45620 03809 1

DREAMGEAR and the DREAMGEAR logo are registered trademarks of DREAMGEAR, LLC. PlayStation Move, PlayStation 3, and PS3 are registered trademarks of Sony Computer Entertainment Inc.

LED Charge Indicators
Solid Blue = Fully Charged, Flashing Blue & Red = 95% Charged, Red = Charging

ON/OFF Switch

4 USB Ports

Charge up to 4 controllers (not included)
Add game on the PlayStation Move
Charge your SONY PSP
Charge your WIRELESS NAVIGATION

PS3 Slim, SIXAXIS™, DUALSHOCK3, PlayStation Move motion and PlayStation Move navigation controllers (not included)
Final product, features, and packaging may vary



[You're reading an excerpt. Click here to read official DREAMGEAR DGPS3-3809 user guide](http://yourpdfguides.com/dref/3582885)
<http://yourpdfguides.com/dref/3582885>

Manual abstract:

dreamGEAR.net | www.iSound.net 20001 S. @@ - DGPS3-3809 UPC - 8 45620 03809 1 COLOR - Black PRODUCT FEATURES The Power Stand is a multi-functional stand that gives you the ability to charge all your controllers while keeping your PS3 Slim stable in a vertical position. You can charge up to 2 SIXAXISTM or DUALSHOCK®3 controllers, 2 PlayStation®Move motion controllers and 2 PlayStation®Move navigation controllers right on the stand. @@@@ POWER STAND · Vertical stand for the PS3 Slim · Dock securely holds and charges up to 2 original SIXAXISTM or DUALSHOCK®3 controllers · Dock securely holds and charges up to 2 PlayStation®Move motion controllers · Dock securely holds and charges up to 2 PlayStation®Move navigation controllers · Cutouts in cradles to fit PlayStation®Move controller wrist straps · Includes a 110 / 240 Volt AC adapter · Connects to PS3 Slim to provide 4 additional USB ports (can sync controllers and can charge additional USB powered devices including controllers, headsets, mobile phones, keypads and other accessories) · LED charge indicators (Blue = Fully charged, Flashing blue and red = 95% charged, Red = charging) · ON / OFF power switch (for charging controllers and powered USB ports individual of PS3 power) · Rubberized finish LED Charge Indicators Solid Blue = Fully Charged, Flashing Blue & Red = 95% Charged, Red = Charging Rubberized Finish Designed to securely fit controllers Cutouts for wrist straps USB to PS3 Console ON/OFF Switch PRODUCT PACKAGING 4 USB Ports TRANSLATIONS PACKAGING USER GUIDE \ FRENCH: Yes \ SPANISH: Yes \ FRENCH: Yes \ SPANISH: Yes (using USB ports) PS3 Slim, SIXAXISTMDUALSHOCK®3, Playstation®Move motion and PlayStation®Move navigation controllers (not included) Final product, features, and packaging may vary SHIPPING INFORMATION QUANTITY MASTER INNER SINGLE 16 4 1 WIDTH (in.) 17.75 8.75 8. HEIGHT (in.) 16.25 15.25 14.5 DEPTH (in.) 18.5 8.75 2 CUBE (ft3) 3.09 0.68 0. 14 WEIGHT (lbs.) 32.80 7.65 1.80 UPC NUMBER 8 45620 03809 1 8 45620 03809 1 8 45620 03809 1 dreamGEAR and the dreamGEAR logo are registered trademarks of dreamGEAR, LLC. .



[You're reading an excerpt. Click here to read official DREAMGEAR DGPS3-3809 user guide](#)
<http://yourpdfguides.com/dref/3582885>