



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR DGWII-3110. You'll find the answers to all your questions on the DREAMGEAR DGWII-3110 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DREAMGEAR DGWII-3110
User guide DREAMGEAR DGWII-3110
Operating instructions DREAMGEAR DGWII-3110
Instructions for use DREAMGEAR DGWII-3110
Instruction manual DREAMGEAR DGWII-3110

works with Wii

Play Controller

Play Controller
ITEM No. - DGWII-3110
UPC - 8 45620 03110 8
COLOR - Black

PRODUCT FEATURES

The Play Controller adds control and functionality with compatible games. Used in combination with the Wii Remote or Action Remote Controller (sold separately), the Play Controller provides extra control functions (with compatible games). It is ergonomically designed to fit perfectly in your hand for comfort even during extended gaming sessions.

PLAY CONTROLLER FEATURES

- Compatible with Nintendo® Wii Remote
- Rubber palm grip
- 3-axis sensor for motion gaming

PRODUCT PACKAGING

INCLUDES: Silicone Cover

FULLY COMPATIBLE WITH:

- ALL Wii GAMES
- Wii REMOTE JACKET
- Wii MOTIONPLUS
- Wii REMOTE & NUNCHUK™

INCLUDES WRIST STRAP

TRANSLATIONS

PACKAGING | FRENCH: Yes | SPANISH: Yes
USER GUIDE | FRENCH: Yes | SPANISH: Yes

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (in³)	WEIGHT (lbs.)	UPC NUMBER
MASTER	25	8.75	14.00	16.75	1.32	10.35	8 45620 03110 8
INNER	4	8.00	4.50	9.00	0.19	1.55	8 45620 03110 8
SINGLE	1	5.00	8.50	2.00	0.03	0.30	8 45620 03110 8

DREAMGEAR and the DREAMGEAR logo are registered trademarks. MotionPLUS, Nintendo and Wii are either trademarks or registered trademarks of Nintendo. The product is not manufactured, assembled, tested, imported or distributed by Nintendo of America.

©2009 iSound. The iSound logo is a registered trademark of iSound. All rights reserved. iSound, Inc. 22001 S. Golden Avenue, Torrance, CA 90503. Tel: 310.202.5022 | Fax: 310.202.5077



[You're reading an excerpt. Click here to read official DREAMGEAR DGWII-3110 user guide](http://yourpdfguides.com/dref/3197257)
<http://yourpdfguides.com/dref/3197257>

Manual abstract:

- DGWII-3110 UPC - 8 45620 03110 8 COLOR - Black **PRODUCT FEATURES** The Play Controller adds control and functionality with compatible games. Used in combination with the Wii Remote or Action Remote Controller (sold separately), the Play Controller provides extra control functions (with compatible games). @@@@.



[You're reading an excerpt. Click here to read official DREAMGEAR](#)

[DGWII-3110 user guide](#)

<http://yourpdfguides.com/dref/3197257>