




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR LAVA GLOW WIRELESS. You'll find the answers to all your questions on the DREAMGEAR LAVA GLOW WIRELESS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

## User manual DREAMGEAR LAVA GLOW WIRELESS User guide DREAMGEAR LAVA GLOW WIRELESS Operating instructions DREAMGEAR LAVA GLOW WIRELESS Instructions for use DREAMGEAR LAVA GLOW WIRELESS Instruction manual DREAMGEAR LAVA GLOW WIRELESS



### PACKAGE CONTENTS:

1. Lava Glow Controller
2. Lava Glow Receiver

### SET-UP:

1. Open the battery compartment located on the bottom side of the Lava Glow controller. Insert 3 "AAA" batteries. Replace battery lid.
2. The Lava Glow controller features a 3 position power switch located on the bottom side of the controller.

**OFF** = The controller is powered OFF

**ON** = This setting allows you to have full use of your Lava Glow controller without the internal LEDs illuminating. This setting conserves battery life.

**LED** = The controller and LEDs are powered ON

3. With your PlayStation 3 game console powered "ON", plug the USB Receiver into your PlayStation 3's USB input #1 (or other, if using multiple controllers). The LED will flash slowly. Press the "CONNECT" button on the Receiver, the LED will flash rapidly.

4. Press the "MENU" button on the Lava Glow controller, the four channel indicators (located above the "MENU" button) will flash rapidly. Press the "MENU" button again and the channel will automatically be set. The solid LED indicates the chosen channel.

5. To connect multiple controllers, connect each controller separately. First connect player 1's controller and then connect the remaining controllers.

6. During gameplay, you can access the PlayStation 3 menu by holding the "MENU" button for 3 seconds.

### TURBO FUNCTION:

1. The Lava Glow controller features a "TURBO" mode. To activate "TURBO", press any button and the "TURBO" button at the same time to set "TURBO" to that button. To cancel the "TURBO" function, repeat step #1.

**NOTE: If the controller stops functioning properly, replace batteries. NOTE: The Lava Glow controller is NOT compatible with SIXAXIS game play.**

**FCC NOTE:** This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications made on the system not expressly approved by the manufacturer could void the user's authority to operate equipment. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FOR TECHNICAL SUPPORT  
PLEASE CONTACT: 1-877-999-DREAM  
or e-mail [support@dreamgear.net](mailto:support@dreamgear.net)

**dreamGEAR®**  
P.O. BOX 478  
Torrance, CA 90508  
[www.dreamgear.net](http://www.dreamgear.net)

TouchSense™ Technology Licensed from Immersion Corporation. Protected by one or more of the following patents:

US Patents: 8023634, 8096554, 5184319, 5185561, 5220260, 5235888, 5308865, 5414337, 5409382, 5145930, 5482056, 5513100, 5559412, 5576727, 5589854, 5592401, 5623382, 5629394, 5631861, 5676157, 5691898, 5701140, 5721566, 5724261, 5731884, 5734373, 5739311, 5757839, 5765660, 5790188, 5803180, 5811920, 5825308, 5828197, 5831408, 5844392, 5872438, 5880714, 5889670, 5889672, 5907487, 5929607, 5930741, 5929846, 5956484, 5959613, 5999168, 6015473, 6020875, 6020876, 6020987, 6024576, 6028593, 6037927, 6042559, 6046727, 6050718, 6050962, 6057328, 6059596, 6061004, 6067077, 6073388, 6078876, 6142735, 6088017, 6088019, 6100874, 6101530, 6104158, 6104379, 6104382, 6106301, 6110130, 6125337, 6125388, 6128006, 6131097, 6134506, 6145274, 6148280, 6154188, 6154201, 6161126, 6162100, 6162723, 6165448, 6184868, 6191774, 6195592, 6201533, 6211861, 6215470, 6219032, 6219033, 6232891, 6243078, 6246390, 6252579, 6252583, 6256011, 6259382, 6271820, 6271833, 6272113, 6278429, 6281651, 6283551, 6288765, 6291770, 6295023, \*E3 3734, 6292174, 6300936, 6300937, 6300938, 6304991, 6310605, 6317116, 6323837, 6342880, 6343349, 6348911, 6353850, 6353427, 6362772, 6362773, 6374255, 6380923, 6386232, 6400332, 6411270, 6413229, 6424833, 6424356, 6429846, 6428490, 6433771, 6437771, 6448977, 6469692, 6470302, 6486872, 6497672, 6563487, 6564168, 6580417, 6636161, 6636197, 6639581, 6654000, 6661403, 6680729, 6683437, 6686891, 6686911, 6693602, 6693626, 6697043, 6697044, 6697045, 6697748, 6697986, 6702550, 6704001, 6704002, 6704683, 6705871, 6707443, 6715045, 6750877, 6762745, 6781569  
Europe: 0848008, 0803114, 0870206, 0804786, 0978889, Australia: 605655, 670311, 67105, 73498, 735497, 702226, 703855, Canada: 2271129, 218336, 2278276, 2122047, 2167304, 2233206, 2210725, 2075178, 2272379, 2261893, 2287349, 2232289, France: 852770 (EP), 609363 (EP), 00101312, Germany: 299233324, 299229945, 809231645 (EP), 69007189 (EP), 29923024, 20114251, 20021561, 201027674, 200802097, 299239324, 200222449, 201800241, 200802631, 200802745, 202009546, Italy: 1315182, 852770 (EP), 609363 (EP), Japan: 3064433, 3085481, 3060791, 200008924, 200000158, 3200436, Korea: 257172, 258353, 252706; Sweden: 519661; Switzerland: 852770 (EP), 609363 (EP); Taiwan: UM-108174; United Kingdom: 23469730, 23464558, 2347990, 2349731, 2346892, 2384619, 23500688, 23872418, 628387218, 62333116, 609363 (EP), 852770 (EP), 2343489



[You're reading an excerpt. Click here to read official DREAMGEAR LAVA GLOW WIRELESS user guide](http://yourpdfguides.com/dref/3254158)  
<http://yourpdfguides.com/dref/3254158>

**Manual abstract:**

*Protected by one or more of the following patents: U.S. Patents: 4823634, 4896554, 5184319, 5185561, 5220260, 5235868, 5389865, 5414337, 5459382, B1 5459382, 5482056, 5513100, 5559412, 5576727, 5589854, 5592401, 5623582, 5629594, 5631861, 5676157, 5691898, 5701140, 5721566, 5724264, 5731804, 5734373, 5739811, 5767839, 5769640, 5790108, 5805140, 5821920, 5825308, 5828197, 5831408, 5844392, 5872438, 5880714, 5889670, 5889672, 5907487, 5929607, 5930741, 5929846, 5956484, 5959613, 5999168, 6015473, 6020875, 6020876, 6020967, 6024576, 6028593, 6037927, 6042555, 6046727, 6050718, 6050962, 6057828, 6059506, 6061004, 6067077, 6078308, 6078876, D427635, 6088017, 6088019, 6100874, 6101530, 6104158, 6104379, 6104382, 6106301, 6110130, 6125337, 6125385, 6128006, 6131097, 6134506, 6147674, 6148280, 6154198, 6154201, 6161126, 6162190, 6166723, 6169540, 6184868, 6191774, 6195592, 6201533, 6211861, 6215470, 6219032, 6219033, 6232891, 6243078, 6246390, 6252579, 6252583, 6256011, 6259382, 6271828, 6271833, 6275213 B1, 6278439, 6281651, 6285351, 6288705, 6292170, 5754023, \*RE37374, 6292174, 6300936, 6300937, 6300938, 6304091, 6310605, 6317116, 6323837, 6342880, 6343349, 6348911, 6353850, 6353427, 6366272, 6366273, 6374255, 6380925, 6396232, 6400352, 6411276, 6413229, 6424333, 6424356, 6429846, 6428490, 6433771, 6437771, 6448977, 6469692, 6470302, 6486872, 6497672, 6563487, 6564168, 6580417, 6636161, 6636197, 6639581, 6654000, 6661403, 6680729, 6683437, 6686901, 6686911, 6693622, 6693626, 6697043, 6697044, 6697048, 6697748, 6697086, 6703550, 6704001, 6704002, 6704683, 6705871, 6707443, 6715045, 6750877, 6762745, 6781569 Europe: 0843808, 0803114, 0870296, 0804786, 0974889; Australia: 649655, 670311, 671705, 734986, 735467, 762226, 770385; Canada: 2271129, 2139336, 2278726, 2122047, 2167304, 2233206, 2210725, 2075178, 2272379, 2261893, 2287349, 2223289; France: 852770 (EP), 609363 (EP), 00/01312; Germany: 29923332.4, 29922298.5, P69231634.5 (EP), 69607189 (EP), 29923623.4, 20014425.1, 20021536.1, 20102767.4, 20080209.7, 29923933, 20022244.9, 20180024.1, 20080263.1, 20080275.5, 20200955.6; Italy: 1315182, 852770 (EP), 609363 (EP); Japan: 3084433, 3085481, 3069791, 2000-008994, 2000-001158, 3290436; Korea: 257172, 258353, 252706; Sweden: 519661; Switzerland: 852770 (EP), 609363 (EP); Taiwan: UM-108174; United Kingdom: 23449730, 2346455B, 2347990, 2349731, 2346952, 2384613, 2350698B, 2387241B, GB2387218, GB2353116, 609363 (EP), 852770 (EP), 2343499 RUMBLE TECHNOLOGY DUAL MOTOR OFF = The controller is powered OFF ON = This setting allows you to have full use of your Lava Glow controller without the internal LEDs illuminating. .*



**[You're reading an excerpt. Click here to read official DREAMGEAR LAVA GLOW WIRELESS user guide](http://yourpdfguides.com/dref/3254158)**  
<http://yourpdfguides.com/dref/3254158>