



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR POWER BASE. You'll find the answers to all your questions on the DREAMGEAR POWER BASE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DREAMGEAR POWER BASE  
User guide DREAMGEAR POWER BASE  
Operating instructions DREAMGEAR POWER BASE  
Instructions for use DREAMGEAR POWER BASE  
Instruction manual DREAMGEAR POWER BASE



**Power Base**  
USER'S GUIDE



www.dreamgear.net

**for  
XBOX 360™**

 **PACKAGE CONTENTS:**

- Power Base
- 2 Rechargeable Batteries
- 110/240V AC adapter
- User's Guide/Warranty Card
- Registration Card

**TO CHARGE THE RECHARGEABLE BATTERY WHILE ATTACHED TO AN XBOX 360 CONTROLLER:**

1. Insert the Rechargeable Battery into the battery compartment located on the back of the controller. It will snap into place.

***NOTE:** Avoid pinching your fingers by pushing only on the flat surface of the Rechargeable Battery.*

2. Lay the Power Base on any flat surface.
3. Plug one end of the AC adapter into any standard wall outlet.
4. Plug the other end of the AC adapter into the back of the Power Base.
5. Press the ON button on the Power Base, which is located in the center of the Power Base.
6. Place the Xbox 360 controller face up onto the Power Base with the top of the controller facing the middle of the Power Base.
7. An LED will illuminate.

***NOTE:** The LED will light up **RED** when the battery is charging and **GREEN** when the battery is full.*

**TO CHARGE THE RECHARGEABLE BATTERY BY ITSELF:**

1. Lay the Power Base on any flat surface.
2. Plug one end of the AC adapter into any standard wall outlet.
3. Plug the other end of the AC adapter into the back of the Power Base.
4. Press the ON button on the Power Base, which is located in the center of the Power Base.

5. Place the Rechargeable Battery onto the Power Base.

***NOTE:** Position the charging sensor on the Rechargeable Battery to match the charging sensor on the Power Base dock.*

6. An LED will illuminate.

***NOTE:** The LED will light up **RED** when the battery is charging and **GREEN** when the battery is full.*

**KEEPING YOUR BATTERY CLEAN**

Be sure and keep your Rechargeable Battery clean. Dirt and debris may harm the battery contacts. Use a dry cloth to clean the battery. DO NOT use water or any chemicals to clean.

**NOTES:**

- You can place up to 2 Rechargeable Batteries on the Power Base at the same time.
- The Power Base is **ONLY** compatible with dreamGEAR Power Base Rechargeable Batteries.
- The dreamGEAR Rechargeable Batteries packs cannot be used with any charging cable, the batteries are only compatible with the dreamGEAR Xbox 360 Power Base.
- Charging times will vary depending on current charge of the battery.

**TROUBLESHOOTING:**

**Problem:** The LED lights are not lighting up.

**Solution:** Make sure that the AC adapter is plugged in properly and securely into a standard wall outlet. Make sure that the Power Base and its rechargeable batteries are free from debris. Make sure that none of the contacts on both the Power Base and rechargeable batteries are damaged or compromised.



www.dreamgear.net

**FOR TECHNICAL SUPPORT**  
PLEASE CONTACT: 1-877-999-DREAM  
or support@dreamgear.net



[You're reading an excerpt. Click here to read official DREAMGEAR POWER BASE user guide](http://yourpdfguides.com/dref/3253485)  
<http://yourpdfguides.com/dref/3253485>

**Manual abstract:**

*NOTE: Avoid pinching your fingers by pushing only on the flat surface of the Rechargeable Battery. 2. Lay the Power Base on any flat surface. 3. Plug one end of the AC adapter into any standard wall outlet. 4. Plug the other end of the AC adapter into the back of the Power Base. 5. @@ 6. Place the Xbox 360 controller face up onto the Power Base with the top of the controller facing the middle of the Power Base.*

*@@ tO CHARGE THE RECHARGEABLE BATTERY BY ITSELF: 1. Lay the Power Base on any flat surface. 2. Plug one end of the AC adapter into any standard wall outlet. 3.*

*Plug the other end of the AC adapter into the back of the Power Base. 4. @@@@ dirt and debris may harm the battery contacts. Use a dry cloth to clean the battery. DO NOT use water or any chemicals to clean.*

*@@@@@.*



**[You're reading an excerpt. Click here to read official DREAMGEAR POWER BASE user guide](#)**

**<http://yourpdfguides.com/dref/3253485>**