



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DREAMGEAR QUAD DOCK PRO. You'll find the answers to all your questions on the DREAMGEAR QUAD DOCK PRO in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DREAMGEAR QUAD DOCK PRO
User guide DREAMGEAR QUAD DOCK PRO
Operating instructions DREAMGEAR QUAD DOCK PRO
Instructions for use DREAMGEAR QUAD DOCK PRO
Instruction manual DREAMGEAR QUAD DOCK PRO



CONTENTS:
• Quad Dock Pro
• 110V/240V AC Adapter
• User's Guide
• Warranty Card

GETTING STARTED:

1. Remove all contents from the packaging.
2. Plug the included AC Adapter into the DC input located on the back of the Quad Dock Pro.
3. Insert your rechargeable battery pack on to the Quad Dock Pro and make contact with the charging terminal. The LED in front will illuminate **RED** indicating that the charge cycle has begun. When the charge cycle is complete, the LED will illuminate **GREEN**.
4. To release the rechargeable battery pack, hold down the button on the battery pack and lift up to remove.

NOTE: The Quad Dock Pro is compatible with all Xbox 360 compatible battery packs. Additional rechargeable battery packs can be purchased separately.

TROUBLESHOOTING:

Question: The LED lights are not lighting up.

Answer:

- Make sure that the AC Adapter is plugged in properly and securely into the Quad Dock Pro.

Question: My rechargeable battery pack is not charging.

Answer:

- Make sure the rechargeable battery pack is inserted into the Quad Dock Pro securely.
- Make sure that the rechargeable battery pack is making proper contact with the charging terminals on the Quad Dock Pro. Make sure the Quad Dock Pro is free from debris.
- Make sure that the contacts on the rechargeable battery pack and the Quad Dock Pro are not damaged.

NOTE: Be sure and keep your rechargeable battery packs and the Quad Dock Pro clean. Dirt and debris ham the battery contacts. Use a dry cloth to clean. DO NOT use water or any chemicals to clean.



FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net



[You're reading an excerpt. Click here to read official DREAMGEAR QUAD DOCK PRO user guide](http://yourpdfguides.com/dref/3253493)
<http://yourpdfguides.com/dref/3253493>

Manual abstract:

2. Plug the included AC Adapter into the DC input located on the back of the Quad Dock Pro. 3. Insert your rechargeable battery pack on to the Quad Dock Pro and make contact with the charging terminal. @@When the charge cycle is complete, the LED will illuminate GREEN. 4. @@@@@@Question: My rechargeable battery pack is not charging. @@@@Make sure the Quad Dock Pro is free from debris. @@Dirt and debris harm the battery contacts. Use a dry cloth to clean.

DO NOT use water or any chemicals to clean. USER'S GUIDE .



[You're reading an excerpt. Click here to read official DREAMGEAR QUAD DOCK PRO user guide](http://yourpdfguides.com/dref/3253493)
<http://yourpdfguides.com/dref/3253493>