



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for EPSON WORKFORCE WF-2760DWF. You'll find the answers to all your questions on the EPSON WORKFORCE WF-2760DWF in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual EPSON WORKFORCE WF-2760DWF**

**User guide EPSON WORKFORCE WF-2760DWF**

**Operating instructions EPSON WORKFORCE WF-2760DWF**

**Instructions for use EPSON WORKFORCE WF-2760DWF**

**Instruction manual EPSON WORKFORCE WF-2760DWF**



[You're reading an excerpt. Click here to read official EPSON WORKFORCE WF-2760DWF user guide](http://yourpdfguides.com/dref/5906921)  
<http://yourpdfguides.com/dref/5906921>

**Manual abstract:**

*For the initial setup, make sure you use the ink cartridges that came with this printer. These cartridges cannot be saved for later use. The initial ink cartridges will be partly used to charge the print head. These cartridges may print fewer pages compared to subsequent ink cartridges. D Caution; must be followed carefully to avoid bodily injury. @@@@The cartridge is vacuum packed to maintain its reliability. J H Shake all new cartridges and then unpack. Press each unit until it clicks. Do not connect a USB cable unless instructed to do so. @@Com/ Insert and then unfold the tray.*

*Wait until the charging is finished. Insert the CD, and then select A or B. If the Firewall alert appears, allow access for Epson applications. @@Visit the website for more information. Set the paper size and paper type for the paper cassette.*

*You can change these settings later. @@@@Visit the website to start the setup process, install software, and configure network settings. R O Load A4 size paper toward the front edge guide with the printable side face down then slide the side edge guides to the paper. Do not load paper above the arrow mark inside the edge guide. You can change these settings later.*

*If you do not want to make settings now, close the fax settings screen. @@Se este for o caso, use o cabo. .*



**[You're reading an excerpt. Click here to read official EPSON  
WORKFORCE WF-2760DWF user guide  
http://yourpdfguides.com/dref/5906921](http://yourpdfguides.com/dref/5906921)**