



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FUJITSU SIEMENS ESPRIMO P3510 (IG31). You'll find the answers to all your questions on the FUJITSU SIEMENS ESPRIMO P3510 (IG31) in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual FUJITSU SIEMENS ESPRIMO P3510 (IG31)**  
**User guide FUJITSU SIEMENS ESPRIMO P3510 (IG31)**  
**Operating instructions FUJITSU SIEMENS ESPRIMO P3510 (IG31)**  
**Instructions for use FUJITSU SIEMENS ESPRIMO P3510 (IG31)**  
**Instruction manual FUJITSU SIEMENS ESPRIMO P3510 (IG31)**



Intel® G31 Express Chipset for DDR2 667 SDRAM Memory and Intel® Core™2 Duo Processors and Core™2 Quad Processors (up to 1333 MHz FSB)



(Picture similar to product)



**Chipset:**  
Intel® G31 / ICH7

**Processors:**  
Intel® Core™ 2 Quad Processors,  
LGA775 with 1333/1066 MHz FSB  
Intel® Core™ 2 Duo Processors,  
LGA775 with 1333/1066/800 MHz FSB  
Intel® Pentium® Dual Core E6xxx Processors,  
LGA775 with 800 MHz FSB  
Intel® Celeron® 4xx Processors,  
LGA775 with 800 MHz FSB  
Compatible with Intel® 06 and 05A processors

**Memory:**  
DDR2 800 SDRAM  
DDR2 667 SDRAM

**Product Features:**  
Graphics on board  
Audio on board  
USB 2.0 on board  
GB/LAN on board  
Serial ATA II on board



[You're reading an excerpt. Click here to read official FUJITSU SIEMENS ESPRIMO P3510 \(IG31\) user guide](http://yourpdfguides.com/dref/1249092)

<http://yourpdfguides.com/dref/1249092>

**Manual abstract:**

3) 3.3V Auxiliary Supply Voltage on PCI Slots (Wake-Up Function) On board CPU Voltage Regulator, 5V / 2A Auxiliary Power required for USB Wake-Up from Save-to-RAM, Save-to-Disk Power Supply Requirements for onboard components (worst case) Source Voltage PS Load I (min. .) + 12 V - 12 V +5V + 3.3 V +5V 0.3 A 0A 0.6A 0A 0A ® Graphics ® Intel GMA3100 Graphics Controller, shared memory (up to 256MB), DirectX 9 compliant, upgradeable with PCI Express x16 Graphics Card or ADD2 cards Audio Realtek ALC262, 2-channel, High Definition Audio LAN Realtek Ethernet Controller with 10/100/1000 MBit/s via PCI Express, Wake-on-LAN (WoL) by interesting Packets, Link Status Change and Magic Packet™, bootix® PXE Support, BIOS MAC Address Display Drives - 4 Serial ATA 300 Interfaces, up to 4 Drives - Floppy Main Power Supply Aux. @@@@ Delivery subject to availability.  
@@ Copyright © Fujitsu Siemens Computers, 09/2007 .



[You're reading an excerpt. Click here to read official FUJITSU  
SIEMENS ESPRIMO P3510 \(IG31\) user guide  
http://yourpdfguides.com/dref/1249092](http://yourpdfguides.com/dref/1249092)