



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HAIER L32B1120. You'll find the answers to all your questions on the HAIER L32B1120 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HAIER L32B1120
User guide HAIER L32B1120
Operating instructions HAIER L32B1120
Instructions for use HAIER L32B1120
Instruction manual HAIER L32B1120

Haier.

TFT-LCD TV
OWNER'S MANUAL

Please READ this manual carefully before operating your TV, and keep it for future reference.

Haier
Haier

MODELS :
L26B 1120
L32B 1120
L42B 1180

Haier



[You're reading an excerpt. Click here to read official HAIER L32B1120 user guide](http://yourpdfguides.com/dref/3981502)
<http://yourpdfguides.com/dref/3981502>

Manual abstract:

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....2-3 Introduction....

.....
.....
.....

.....
.....
.....

.....
.....
.....

....4 Stand installation guide.....

.....
.....

.....
.....
.....

.....
.....

.....5 Installation....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....6-9 Remote Control....

.....
.....
.....

.....
.....
.....
.....
.....
.....
.....
.....

.....10 Operation..

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.... 11-15 Trouble Shooting.

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

16 Warranty.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.. . 17 -1- SAFETY AND WARNINGS IMPORTANT SAFETY INSTRUCTION 1) Read these instructions. 2) Keep these instructions. 3) Heed all warnings. 4) Follow all instructions. 5) Do not use this apparatus near water. 6) Clean only with dry cloth. 7) Do not block any ventilation openings, install in accordance with the instructions.

8) Do not install near any heat sources such as radiations, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 9) Do not defeat the safety purpose of the polarized plug. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. @@11)

Only use attachments/accessories specified by the manufacturer. @@13) Refer all servicing to qualified service personnel.

@@@14) Mains plug is used as the disconnect device, the disconnect device shall remain readily operable. @@@@18) The use of apparatus in moderate

imitate dangerous acts which they may see on the screen . General: Considered acceptable for all age groups, Appropriate viewing for the entire family contains very little violence, physical, , verbal or emotional.



[You're reading an excerpt. Click here to read official HAIER L32B1120 user guide](http://yourpdfguides.com/dref/3981502)
<http://yourpdfguides.com/dref/3981502>

Parental Guidance: Intended for a general audience, but may not be suitable for younger children (under the age of 8) because it could contain controversial themes or issues.

Over 14 Years: Could contain themes where violence is one of the dominant elements of the storyline, but it must be integral to the development of plot or character. @@@@ Press to select, press to exit. to adjust, press MENU C8+ G Age PG <<< Off Pacific Off 1999/12/31 04:03PM >>> 14+ Adjust Select Menu Exit 18+ Sleep Timer: You can set the sleep timer. Note: Time zone, DST and Clock are available in ATSC mode, and the Clock can't be adjusted. 3.3 Closed Caption: switch the closed caption mode. 2). Canada French: switch the French-rating control level: E, G, 8ANS+, 13 ANS+, 16ANS+, 18ANS+. Rating E G Description Exempt programming General: All ages and children, contains minimal direct violence, but may be integrated into the plot in a humorous or unrealistic manner.

-15- TROUBLE SHOOTING Trouble phenomenon Symptom Inspection Check Picture Audio antenna position, direction or connection Snow Noise Ghost Normal audio antenna position, direction or connection Interference Noise electronic equipment, car/motorcycle, fluorescent light Normal Picture Mute Volume (check if mute is activated or if the audio system connections are not correct) No picture Mute Power cord is not inserted Power switch is not opened Contrast and brightness/volume setup Press standby key on the remote control for inspecting No color Normal audio Color control Picture breaking up Normal audio or weak Retune channel No color Noise TVsystem The LCD TV panel is built with very high precision technology giving you fine picture details in vibrant color. Occasionally, a few non-active pixels may appear on the screen as a fixed point of red, green, blue, black or white. Please note this does not affect the performance of the product. -16- WARRANTY -17- .



[You're reading an excerpt. Click here to read official HAIER L32B1120 user guide](http://yourpdfguides.com/dref/3981502)
<http://yourpdfguides.com/dref/3981502>