

Manual abstract:

-1- INTRODUCTION Thanks for choosing the Haier W716, Dual SIM Android smart phone based on 1.2 GHz Quad Core Processor. This smart phone is running on Android OS, v4.2. If you'd like your phone to live a long and fruitful life, please read this guide carefully and keep it for future reference. You never know when you might need it. And don't worry if the pictures we use to demonstrate your phone's functions look a little different from what you see on its screen. It's the functions that matter. * The Manufacturer reserves the right for the changes in the manual without advanced notice. 1 Safety Precautions Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

□ Your mobile phone model has been designed to comply with applicable safety requirements for exposure to radio waves. The radio wave exposure guidelines employ a unit of measurement called Specific Absorption Rate (SAR). For mobile phones, the maximum SAR value allowed is 2.0 watts per kilogramme (W/Kg). □ Maximum SAR value for this model: Maximum SAR value in the head: 0.465 W/Kg Maximum SAR value in the body: 1.120 W/Kg □ Use cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message.

@@@ Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. Dispose of used batteries according to the instructions. □ For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible. -5- 1.

2 Using your phone safely On The Road Using a phone while driving is illegal in many countries. please follow local laws and drive safely at all times. Near Sensitive Electronics Don't use your phone near sensitive electronic equipment – particularly medical devices such as pacemakers – as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment. For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor. Your phone may cause interference when used near TVs, radios or automated office equipment. While Flying Your phone can cause interference with aircraft equipment. so it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say. -6- In Hospital Your phone may interfere with the normal operation of medical equipment.

Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff. at a Petrol Station Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives. Around Water Keep your phone away from water (or any other liquid). it's not a waterproof model. Making Repairs Never take your phone apart. Please leave that to the professionals. Unauthorized repairs could break the terms of your warranty. Broken Antenna Don't use your phone if the antenna is damaged, as it could cause injury. -7- Around Children Keep your mobile out of children's reach.

It should never be used as a toy and it might not be good for their health. Original Accessories Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, make the warranty void, break national regulations on the use of mobile phones, or even cause injury. @@ Always obey local laws and turn off your phone when requested. @@ Dial the national emergency number and press 'send'.

@@@ Please don't use the phone outside the range. @@@@ -9- 2 Understanding your Phone 2. @@@@ Home key (): Touch the key to return to the home screen. @@@@ Touch it to view menu options. Back key (): Touch to go back to the previous menu.

Call on hold The ringing type is set on Vibration. 3G network in use. You have missed calls. In call Icons Descriptions Show the phone's battery capacity. 3 Inserting & Removing the Battery Inserting the Battery 1. Open the battery cover on the back of your phone. @@ Replace the battery cover clicking it back into position. Inserting the Battery Closing the Back Cover Removing the battery 1. Lift the battery up and out of your phone. @@ 2.

@@ It is easy to do & can be done in 4 simple steps below: 1. Connect the charger to your phone, and plug it into a socket. @@ When fully charged, the battery indicator will stop scrolling. Disconnect the charger from your mobile, and unplug. 2. 5 Power ON/OFF Press the power key to power-ON/OFF the phone. @@ Please replace it with your own PIN code as soon as possible. Enter the wrong PIN three times, and your SIM will be locked. @@ It is applicable for both the SIMs if you are using 2 SIM Cards. 2.

@@ 2. @@ 2. @@ -14- 2. @@@@ 2. 10 Add icons on the main interface You can long press the icon on the main menu until it's enlarged and the mobile phone vibrates, and copies the icons in the main menu to the main interface.

Move icons on the main interface Long press the icon on the main interface until it's enlarged and the mobile phone vibrates. Drag the icon to the desired position and then release it. Delete icons on the main interface Long press the icon on the main interface until it's enlarged and the mobile phone vibrates.

Choose from "Gallery"/"Live Wallpapers"/"Video Wallpaper"/"Wallpapers", and Select the wallpaper and press "Set wallpaper" to complete. 2. 14 Install APK through File Manager APK is a supported file format for the Android mobile operating system. A) Please copy the downloaded APK file into the SD card, and then insert the SD card into the phone. D) Click the APK file you wish to install, and follow the installation wizard. E) Comment on the memory available for the user: Your Smartphone Haier has an internal memory of 4 GB (eMMC) and 512 MB of RAM; the memory used by the operating system (OS) and the preinstalled applications is 2 GB. The memory available for the user is 2 GB. -16- 3 Using your Phone 3. 1 Select Main Menu & Its Functions to enter the main menu... Allow you to view a list of features available in your phone 1. Clock Allow you to set the Alarm from Clock. Calculator Allow you to make tedious calculations quickly. Camera Allow you to click pictures anytime you want.

Your Haier W716 has High Definition camera supporting many special features which ensures you always click good quality of pictures and stores them under the Gallery folder. In -17- Camera, easily choose Camcorder to record Video Files.



[You're reading an excerpt. Click here to read official HAIER W716 user guide](http://yourpdfguides.com/dref/5578411)
<http://yourpdfguides.com/dref/5578411>

Email Allows you set up your POP/IMAP email accounts. -18- 8. Gallery Allow you to save & view photos & videos. Messaging Allow you to view messages sent & received as a thread. 10. Music View the list of songs available in your phone. Phone Allow you to make quick outgoing calls. -19- 12. File Manager You could install the files in APK format & also view your files. Sound Recorder Allows you to record sounds. 2 Wi-Fi Haier W716 supports Wi-Fi which allows Android later devices with the appropriate hardware to connect directly to each other via Wi-Fi without an intermediate access point. Using the APIs, you can discover and connect to other devices when each device supports Wi-Fi, then communicate over a speedy connection across distances -21- much longer than a Bluetooth connection. This is useful for applications that share data among users, such as a multiplayer game or file sharing.

1. After turning on the feature click "Search" at the bottom and it will display the available devices. 2. Then choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages. -24- 5Maintenance Use a dry soft cloth to wipe general dirt.

6Taking Care of your Device Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone: Always keep the small parts of the phone away from children. keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it. Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged. Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries. Do not attempt to open the device other than as instructed in this guide. Do not drop, kn.



[You're reading an excerpt. Click here to read official HAIER W716 user guide](http://yourpdfguides.com/dref/5578411)
<http://yourpdfguides.com/dref/5578411>