



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HAIER WDNS116BBS. You'll find the answers to all your questions on the HAIER WDNS116BBS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HAIER WDNS116BBS
User guide HAIER WDNS116BBS
Operating instructions HAIER WDNS116BBS
Instructions for use HAIER WDNS116BBS
Instruction manual HAIER WDNS116BBS

Water Dispenser
Dispensador de agua



User Manual

WDNS116BBS

Manual de Usuario

Haier.

Quality • Innovation • Style



[You're reading an excerpt. Click here to read official HAIER WDNS116BBS user guide](http://yourpdfguides.com/dref/3981544)
<http://yourpdfguides.com/dref/3981544>

Manual abstract:

Read all of the instructions before using this appliance. Use this appliance only for its intended purpose as described in this use and care guide. This water dispenser must be properly installed in accordance with the installation instructions before it is used. See the grounding instructions in the installation section. Never unplug your water dispenser by pulling on the power cord. Always grasp the plug firmly and pull straight out from the outlet. Repair or replace immediately, all electric service cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length, on the plug or at the connector end. Unplug your water dispenser before cleaning and making any repairs. Note: If for any reason this product requires service, we strongly recommend that a certified technician perform the service.

This water dispenser should not be recessed or built into an enclosed cabinet. It is designed for freestanding installation only. This appliance is designed for **INDOOR USE ONLY** and should not be used outdoors. Do not operate your water dispenser in the presence of explosive fumes. Close supervision is necessary when any appliance is used by or near children.

11. Thank you for purchasing our Haier product. Remember to record the model and serial number. They are on a label in back of the unit. You will need it to obtain warranty service.

2. Inspect and remove any remaining packaging, tape and printed material before turning on the water dispenser. Note: Allow the water dispenser to stand in an upright position for at least 12 hours before turning on the power. To ensure that your water dispenser works at the maximum efficiency it was designed for, you should install it in a location where there is proper air circulation and electrical connections. The water dispenser is for indoor use only. Note: Thermostats maintain the hot and cold water temperatures automatically. On the compressor cooled water coolers the hot water temperature will be between 190°F-203°F / 88°C- 95°C and the cold water temperature will be between 43°F- 50°F / 6°C-10°C. Select a suitable location for the unit on a hard even surface away from direct sunlight and heat sources (e. CAUTION: DO NOT plug in the water dispenser until full bottle is installed first and water flows from both Hot and Cold water faucets. Note: Hot and cold water will not be instantly available as the unit will need time to heat up and cool down the water.

Before connecting the unit to the power source, Let it stand upright for approximately 12 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation. The water dispenser is pre-cleaned at the factory but the reservoir and water lines should be flushed with fresh water before use as follows: 1. Check and make sure the drain cap on the back of the water dispenser is firmly closed. 4. 9.

Please remember to close the drain cap firmly after the drainage. 10. 11. Push water faucet buttons to insure water flows from both faucets.

Now you are ready to use your water dispenser. Read carefully and understand all installation instructions before installing the water dispenser. 1. Remove the cap from the water bottle first. Lift up the water bottle and quickly place it into the water receptacle.

(The water bottle is not included.) 2. DO NOT plug in the water dispenser until you have checked that water flows out of both faucets when the hot and cold water release levers are pressed. Never turn on the water dispenser without water. Doing so may cause the unit to catch fire or malfunction.

3. Check that water flows out by pressing both the hot and cold water faucets one at a time. 4. Plug the power cord into an 115volt / 60 Hz outlet. This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. We do not recommend the use of an extension cord with this unit. Remove the power cord from wall outlet when a power outage occurs. 3. 7.

Turn off and unplug the water dispenser then follow the Start-Up Instructions. PLEASE NOTE: You need to press the Hot/+ (#4 below) button to turn on the water heater and the Cold/- (#5 below) button to turn on the cooling compressor. When in stand-by mode, pressing the ON/ OFF button will cut off all power. 2. Set function: While the dispenser is in stand-by mode, press and hold the Set button for 2 seconds, the display will go into Set Mode. In Set mode you will be able to set the clock time, hot water temperature and cold water temperature. - Press and hold the SET button to enter SET Mode - Press a 2nd time to set Clock Hours (Hours flashing) - Press a 3rd time to set Clock Minutes (Minutes flashing) - Press a 4th time to set Hot Water Temperature (Heating Level flashing) - Press a 5th time to set Cold Water Temperature (Cooling Level flashing) - If nothing is pressed for 8 seconds the display will automatically exit the Set Function 3. Night Light: Press the Night Light button and the light will turn ON, press it once more and the light will turn OFF.

8. To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

Caution: Before using any cleaning product, always read and follow the manufacturer's instructions and warnings to avoid personal injury and/ or product damage. Note: It is best to clean the dispenser and its surrounding area when replacing the empty bottle with a new one. This way you can move the unit easily without the weight of the bottle. Before cleaning, place a dust cover on top of the water guard to prevent dust and debris from going into the dispenser while cleaning. Prepare a cleaning solution of 3-4 tablespoons of baking soda mixed with warm water.

Use a sponge or a soft cloth dampened with the cleaning solution to wipe down the unit. Always unplug the unit before cleaning to avoid electric shock. Failure to do so may result in death or injury. Wipe with clean warm water and dry with a soft cloth. When cleaning, you do not need to take anything apart.

Simply pour the baking soda/water solution through the water guard. Then rinse with plenty of water and allow the water to drain. We recommend that you move the dispenser away from the wall and vacuum or brush the coils on the rear of the unit at least 4 times a year. Some operating environments may require more frequent cleaning. If bottle still contains water, remove it quickly and carefully to avoid spillage. Please note not to use any tools to remove or authorized dealer or service center. This warranty does not cover incidental or consequential damages, so the above limitations may not apply to you. Some States do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.



[You're reading an excerpt. Click here to read official HAIER](#)

[WDNS116BBS user guide](#)

<http://yourpdfguides.com/dref/3981544>

This warranty gives you specific legal rights, and you may have other rights, which vary, from state to state. Staple your receipt to your manual.

You will need it to obtain warranty service. Se configura la hora en 06:00 y AM/PM Press HOT/+ or COLD/- to adjust hours and AM/PM 06:00 set hour and AM/PM 4. If you have a problem with this product, please contact the "Haier Customer Satisfaction Center" at 1-877-337-3639. .



[You're reading an excerpt. Click here to read official HAIER](#)

[WDNS116BBS user guide](#)

<http://yourpdfguides.com/dref/3981544>