



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO BABY ALIVE MY BABY ALIVE. You'll find the answers to all your questions on the HASBRO BABY ALIVE MY BABY ALIVE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual HASBRO BABY ALIVE MY BABY ALIVE
- User guide HASBRO BABY ALIVE MY BABY ALIVE
- Operating instructions HASBRO BABY ALIVE MY BABY ALIVE
- Instructions for use HASBRO BABY ALIVE MY BABY ALIVE
- Instruction manual HASBRO BABY ALIVE MY BABY ALIVE

MI Baby Alive

BATERÍAS INCLUIDAS x2

TAMBIÉN INCLUYE:

La comida y el biberón contienen imanes.

La comida para muñeca BABY ALIVE no es tóxica y está hecha con ingredientes de grado alimentario, pero no está concebida para el consumo. Sin embargo, si llegara a ingerirse por accidente, es inocua. Solo usa comida de muñeca BABY ALIVE con esta muñeca.

NOTA AL CLIENTE: Esta muñeca está empaquetada en modo "TRY ME" (PRUEBAME). Cuando llevas la muñeca a casa, mueve el interruptor ON/OFF/TRY ME (encendido/apagado/pruébame) a "ON" para acceder a todas las funciones del juguete.

ALSO INCLUDES:

Spoon and bottle contain magnets.

BABY ALIVE doll food is nontoxic and made of food-grade ingredients, but it is not intended to be eaten. If accidentally ingested, however, it is not harmful. Use only BABY ALIVE doll food with your BABY ALIVE doll.

x2 1.5V AA BATTERIES INCLUDED

Replace with 2x 1.5V "AA" or R6 size battery. Alkaline batteries recommended. Phillips cross head screwdriver (not included) needed to replace batteries.

AGES 3+

My Baby Alive

NOTE TO THE CONSUMER: This doll is packaged in "TRY ME" mode. When you bring the doll home, move its ON/OFF/TRY ME switch to the "ON" position.



[You're reading an excerpt. Click here to read official HASBRO BABY ALIVE MY BABY ALIVE user guide](http://yourpdfguides.com/dref/3971641)
<http://yourpdfguides.com/dref/3971641>

Manual abstract:

If accidentally ingested, however, it is not harmful. Use only BABY ALIVE doll food with your BABY ALIVE doll. @@Phillips/cross head screwdriver (not included) needed to replace batteries. @@@@When you feed her with the spoon or give her the bottle, she'll talk and make eating sounds. She really "eats" her doll food and "drinks" from her bottle! After meals, she'll need you to change her diaper! When it's time for your doll to take a nap, cradle her in your arms or lay her down. To switch the doll's language to English or Spanish, press and hold the bracelet button until she says a phrase (3-4 seconds). Release button once the doll changes languages. Start by adding water up to the fill line in your doll's bowl (about 15 ml or 3 teaspoons of water). @@ 2. @@Doll food will thicken as it's stirred.

4. @@Be sure to feed your doll right after you've mixed up her food. 2. Use the included spoon to feed your doll small amounts of doll food. 3. @@Gently squeeze the bottle to release water, giving her a few sips at a time. TIPS: Just like a real baby, your doll can be messy when she eats! She's easier to feed when you tilt her head back (as shown). Feeding your doll: Preparing your doll's meal: NOTE: To conserve batteries, move switch to the "OFF" position when doll is not being used. Before you feed your doll, put on her bib and make sure her diaper is securely fastened. @@@@@@Use a soft cloth or paper towel to wipe away any remaining food.

STAIN ADVISEMENT: BABY ALIVE doll food may stain some surfaces. @@Doll bib should be cleaned with a soft, damp cloth; hang to dry.

@@@@@@Use only clean tap water; do not use any other liquids. @@@@ 2. Put on a new diaper and fasten securely. â· ALWAYS change your doll's diaper and clean her after she drinks. â· NEVER let your doll sit with a wet diaper. To change diaper: After feeding your doll, you'll need to change her diaper! Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings. 2. @@ 3.

Remove exhausted or dead batteries from the product. 4. Remove batteries if product is not to be played with for a long time. @@@@ 7. @@Always remove from the product before recharging. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. @@@@@@Do not dispose of in your household waste bin. @@Do not dispose of in your household waste bin. Replace door and tighten screw (make sure ribbon is clear of seal). .



[You're reading an excerpt. Click here to read official HASBRO
BABY ALIVE MY BABY ALIVE user guide
http://yourpdfguides.com/dref/3971641](http://yourpdfguides.com/dref/3971641)