




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO FURBY SLEEPYTIME BED. You'll find the answers to all your questions on the HASBRO FURBY SLEEPYTIME BED in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO FURBY SLEEPYTIME BED
User guide HASBRO FURBY SLEEPYTIME BED
Operating instructions HASBRO FURBY SLEEPYTIME BED
Instructions for use HASBRO FURBY SLEEPYTIME BED
Instruction manual HASBRO FURBY SLEEPYTIME BED




AGES 4 AND UP
MODEL NO. D852

ELECTRONIC
Furby Sleepy Time Bed

INSTRUCTION MANUAL

Furby is reminded of his cloud home each time he sleeps in his cloud bed. Now you can gently rock Furby or Furby Babies to sleep with the Sleepy Time Bed. The Furby cloud pillow has a soft place for Furby to rest. Use the safety belt to buckle Furby in place so he doesn't fall out. Place Furby into the bed, move the handle into "sleepy time" position and press the "sleepy time" button. Furby will gently fall asleep!

GETTING STARTED










BATTERY INSTALLATION
CAUTION: Battery installation and replacement should be done by an adult. Carefully loosen the battery door screw and open the battery compartment door located on the backside of the handle. Insert the batteries, making sure to align the "+" and "-" signs as shown. Close the battery compartment door and tighten the screw. Do not over-tighten as this may cause damage. Requires 2 "AAA" batteries (not included).

To ensure proper function:

- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Battery installation should be done by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short circuited.
- Replace with new batteries at the first sign of erratic operation.

PREPARING FURBY FOR A NAP

- The handle must be in the "UP" position. 
- Place Furby or Furby Babies into the bed. Make certain Furby is facing forward or toward you. The bed will not make Furby go to sleep if Furby is facing in the wrong direction. 
- Buckle the safety belt by threading the right strap through the loop on the left strap. Fold the right strap over the buckle and press the end against the strap. This will securely hold Furby. 
- Move the handle to the "sleepy time" position.  
- Press the "sleepy time" button when Furby is NOT speaking or moving. Furby commences speaking or moving when the "sleepy time" button is pressed or Furby will not respond to the nap command. 
- You will hear Furby fall asleep. 

NOTE: Keep the handle in the DOWN position until Furby completely falls asleep. Moving the handle to the UP position before Furby falls asleep may cause Furby to wake up.



[You're reading an excerpt. Click here to read official HASBRO FURBY SLEEPYTIME BED user guide](http://yourpdfguides.com/dref/1193535)
<http://yourpdfguides.com/dref/1193535>

Manual abstract:

@@Now you can gently rock Furby or Furby Babies to sleep with the Sleepy Time Bed. The fluffy cloud pillow has a soft place for Furby to rest. @@Place Furby into the bed, move the handle into "sleepy time" position and press the "sleepy time" button. Furby will gently fall asleep! 2. Place Furby or Furby Babies into the bed. Make certain Furby is facing forward, or toward you. The bed will not make Furby go to sleep if Furby is facing in the wrong direction. GETTING STARTED "Sleepy Time" Button ELECTRIC! ON ® 3. Buckle the safety belt by threading the right strap through the loop on the left strap. Fold the right strap over the buckle and press the end against the strap.

This will securely hold Furby. "Sleepy Time" Handle 4. @@@@Close the battery compartment door and tighten the screw. Do not over-tighten as this may cause damage. Requires 2 "AAA" batteries(not included) 5.

Press the "sleepy time" button when Furby is NOT speaking or moving. Furby cannot be speaking or moving when the "sleepy time" button is pressed or Furby will not respond to the nap command. To ensure proper function: - Do not mix old and new batteries - Do not mix alkaline, standard or rechargeable batteries - Battery installation should be done by an adult - Non-rechargeable batteries are not to be recharged - Rechargeable batteries are to be removed from the toy before being charged (if removable) - Rechargeable batteries are only to be charged under adult supervision (if removable) - Only batteries of the same or equivalent type as recommended are to be used - Batteries are to be inserted with the correct polarity - Exhausted batteries are to be removed from the toy - The supply terminals are not to be short circuited - Replace with new batteries at the first sign of erratic operation 6. @@@@The store doesn't have replacement parts. Instead, write to us at: Tiger Repair Department 1000 N.

Butterfield Road, Unit 1023 Vernon Hills, IL 60061, U.S.A. @@@@All product returned must be shipped prepaid and insured for loss or damage to: Tiger Repair Department 1000 N. Butterfield Road, Unit 1023 Vernon Hills, IL 60061, U.S.A. The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. @@@@IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT. Some states do not allow limitations as to how long an implied warranty lasts and/or exclusions or limitations of incidental or consequential damages, so the above limitations and/or exclusions of liability may not apply to you.

This warranty gives you specific rights, and you may also have other rights which vary from state to state. @@All rights reserved. 980 Woodlands Parkway, Vernon Hills, Illinois 60061, U.S.A. ®, TM, & © 1999 Tiger Electronics UK Ltd. @@.



[You're reading an excerpt. Click here to read official HASBRO FURBY SLEEPYTIME BED user guide](http://yourpdfguides.com/dref/1193535)
<http://yourpdfguides.com/dref/1193535>