



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372. You'll find the answers to all your questions on the HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372

User guide HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372

Operating instructions HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372

Instructions for use HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372

Instruction manual HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372

FCC STATEMENT

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Just like a real animal, it's normal for your FURREAL FRIENDS toy to shed a little when you groom it.

FurRealFriends.com

Questions? Call 1-800-844-3733

Product and colors may vary.

© 2009 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks. U.S. Pat. No. 6811461 and patent pending.

94372/943710900 Asst.

PN 7022450000

AGES 4+

FurReal
friends

GoGo
my walkin' pup



**CARE
GUIDE**



CAUTION:

air entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required.



[You're reading an excerpt. Click here to read official HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372 user guide](http://yourpdfguides.com/dref/2453254)
<http://yourpdfguides.com/dref/2453254>

Manual abstract:

-----This device complies with part 15 of the FCC Rules. This device may not accept any interference received and may cause undesired operation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. Increase the separation between the equipment and the receiver. Consult the dealer or an experienced radio/TV technician for help. Please refer to the user manual for more information. To attach the leash, insert the connector piece into the opening on GoGo's collar until it clicks. When she senses her leash is attached, GoGo will make excited movements and sounds to show you she's eager. Leash mode: To walk, make sure her leash is attached, then use the controls on her leash handle to move her forward, left and right. Do not walk her on grass, sand or gravel, or through mud or deep water. Look for the label.

- Loosen screw on battery cover. Remove and discard old batteries.
- Use only the batteries specified and be sure to insert them correctly by matching the + and - polarity markings. Do not mix old batteries and new batteries or [1] standard (carbon-zinc) with alkaline batteries. Remove exhausted or dead batteries from the product.
- Remove batteries if product is not to be played with for a long time. Do not short-circuit the supply terminals.
- Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.** ; **IMPORTANT: BATTERY ~ ~ F U R M A ~ .**

CAUTION: Do not dispose of in your household waste bin.



[You're reading an excerpt. Click here to read official HASBRO FURREAL FRIENDS GOGO MY WALKING PUP 94372 user guide http://yourpdfguides.com/dref/2453254](http://yourpdfguides.com/dref/2453254)