



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO NERF N STRIKE ALPHA TROOPER CS-18. You'll find the answers to all your questions on the HASBRO NERF N STRIKE ALPHA TROOPER CS-18 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO NERF N STRIKE ALPHA TROOPER CS-18

User guide HASBRO NERF N STRIKE ALPHA TROOPER CS-18

Operating instructions HASBRO NERF N STRIKE ALPHA TROOPER CS-18

Instructions for use HASBRO NERF N STRIKE ALPHA TROOPER CS-18

Instruction manual HASBRO NERF N STRIKE ALPHA TROOPER CS-18



[You're reading an excerpt. Click here to read official HASBRO NERF N STRIKE ALPHA TROOPER CS-18 user guide](http://yourpdfguides.com/dref/3237840)
<http://yourpdfguides.com/dref/3237840>

Manual abstract:

TO AVOID INJURY: Use only darts designed for this product. Do not modify darts or dart blaster. ALWAYS READ THE USER GUIDE TO READ AND follow all instructions carefully before using. It may warn you to Load DARTS into DRUM MAGAZINE. Be sure DARTS are inserted in direction indicated on DRUM MAGAZINE. Insert 1 CLIP-SYSTEM DART at a time. DRUM MAGAZINE can hold up to 18 CLIP-SYSTEM DARTS. To load, pull the TRIGGER to fire. To open the ACCESS DOOR and remove a loaded drum, pull the TRIGGER to fire. To unload DARTS from blaster before putting it away, pull the TRIGGER to fire.



[You're reading an excerpt. Click here to read official HASBRO NERF N STRIKE ALPHA TROOPER CS-18 user guide](http://yourpdfguides.com/dref/3237840)
<http://yourpdfguides.com/dref/3237840>