



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO ROSE PETAL COTTAGE PLAYSKOOL. You'll find the answers to all your questions on the HASBRO ROSE PETAL COTTAGE PLAYSKOOL in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO ROSE PETAL COTTAGE PLAYSKOOL  
User guide HASBRO ROSE PETAL COTTAGE PLAYSKOOL  
Operating instructions HASBRO ROSE PETAL COTTAGE PLAYSKOOL  
Instructions for use HASBRO ROSE PETAL COTTAGE PLAYSKOOL  
Instruction manual HASBRO ROSE PETAL COTTAGE PLAYSKOOL

**STOVE ASSEMBLY:**

**PARTS REQUIRED FOR THIS STEP:**

- STOVE PIECES (6)

1. Lay back panel flat on floor.
2. Press side panels into grooves on back panel.
3. Press grooves on front panel onto side panels.
4. Set upright, and place shelf inside stove.
5. Place top on stove and push down firmly.

AG ES 3+

THANKS FOR PURCHASING THE ROSE PETAL COTTAGE. PLEASE READ AND RETAIN THESE INSTRUCTIONS.

68601

Quick, simple storage!

**STORAGE**

Adult assembly required.

**WARNING:** KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THE ROSE PETAL COTTAGE FABRIC.

This Cottage meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the Cottage fabric may render the flame resistant properties ineffective.

Stove front and Cottage door contain magnets.

© 2007 Hasbro. All Rights Reserved.  
TM & © denote U.S. Trademarks.  
© 2007 Worlds Apart Ltd. All rights Reserved.  
PLAYSKOOL.com  
Questions? Call 1-800-PLAYSKOOL



[You're reading an excerpt. Click here to read official HASBRO ROSE PETAL COTTAGE PLAYSKOOL user guide](http://yourpdfguides.com/dref/1196060)  
<http://yourpdfguides.com/dref/1196060>

**Manual abstract:**

Lay back panel flat 2. 3. Press grooves on front panel onto side panels. 4. Set upright, and side place shelf inside stove. 5. Place top on stove and push down firmly. Shelf back side Thanks for purchasing the ROSE PETAL Cottage. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the Cottage fabric may render the flame resistant properties ineffective.

Visit PN 6686270000 © 2007 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks.

© 2007 Worlds Apart Ltd. All rights Reserved. .com Questions? 8. Holding the peak in place, move to the other side of the frame.

Slide that side of the cover over the frame. Do not pull the cover all the way onto the frame at this time. 7. Holding the roof peak in 9. Work your way around the frame, sliding each corner of the cover one evenly. 10. Zip up rear wall. 11. Zip up door. 12. Adjust window hook-and-loop fastener attachments.

15. Assemble pink frame as shown on page 2. 2. Remove the Cottage cover from the Door Side Cottage Cover: Parts required for this step: - Completed pink frame 6. Lifting from the peak of the roof, bring the main part of the cover up onto the peak of the frame. For video assembly instructions, please visit [www.playskool.com/rosepetalcottage](http://www.playskool.com/rosepetalcottage). #2 #8 bag marked "Door." 3.

Completely unzip the 2 zippers at the rear wall and door frame. Separate door frame zipper into 2 halves. Assemble frames as shown. #2 #7 #2 with the printed side down. 5.

Assemble white frame as shown on page 2. 2. Completely unzip the rear wall from the body of the Cottage, and detach the fabric fasteners around the two windows and chimney. 5. Set the frame on the cover as shown, so that the two red connector pieces on the open sides sit on top of the red seams.

Bottom sides of frames should overlap about 2 inches of the red seams. 6. 8. Holding the peak in place, move to the other side of the frame. Slide that side of the cover over the frame. 4. Pull the cover all the way on, so that the frame is tucked inside the zipper. 11. Starting with the two straps nearest the peak of the roof, attach fabric tabs around frame tubes. 12.

Zip up rear wall. 13. Adjust chimney and window hook-and-loop fastener attachments. 14. .



[You're reading an excerpt. Click here to read official HASBRO ROSE PETAL COTTAGE PLAYSKOOL user guide](#)

<http://yourpdfguides.com/dref/1196060>