




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO SMORES MY FURREAL PONY. You'll find the answers to all your questions on the HASBRO SMORES MY FURREAL PONY in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO SMORES MY FURREAL PONY
User guide HASBRO SMORES MY FURREAL PONY
Operating instructions HASBRO SMORES MY FURREAL PONY
Instructions for use HASBRO SMORES MY FURREAL PONY
Instruction manual HASBRO SMORES MY FURREAL PONY

TO REATTACH HALTER



- The assembled halter looks like this.
 - Buckle this part of halter.
- Turn halter over with the buckle underneath.
- Place halter over pony's muzzle as shown.
- Buckle behind the pony's ears (using second or third hole).

FCC STATEMENT
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

© 2007 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
U.S. Pat. No. 6911461 and Patents Pending
77422 PN 671100000

Questions?
Call 1-800-327-8264



AGES 4+
77422

CAUTION:
This product contains small parts which are necessary for assembly. Prior to and during assembly of this product, keep small parts out of children's reach. Small parts pose a choking hazard to children under 3 years.

ADULT ASSEMBLY REQUIRED. Tool needed: Phillips/cross head screwdriver (not included).

S'mores Pony

PONY CARE GUIDE

Thank you for purchasing this FURREAL FRIENDS® toy! Be sure to read and follow instructions carefully, so you and your pony can have lots of fun together! Remember, S'MORES™ pony is like a real pony in many ways. The more you take care of her and love her, the happier she'll be!

Pony comes with carrot, brush, halter and special adoption certificate.

For indoor use only.

6 XG ALKALINE BATTERIES REQUIRED
1.5V D or LR20 size
NOT INCLUDED
Phillips/cross head screwdriver (not included) needed to insert batteries.

MAXIMUM WEIGHT 80lbs/36kg



[You're reading an excerpt. Click here to read official HASBRO SMORES MY FURREAL PONY user guide](http://yourpdfguides.com/dref/1196317)
<http://yourpdfguides.com/dref/1196317>

Manual abstract:

ADULT ASSEMBLY REQUIRED. Tool needed: Phillips/cross head screwdriver (not included). 1. The assembled halter looks like this. 1a. Buckle this part of halter. 2. Turn halter over with the buckle underneath. 3. Place halter over pony's muzzle as shown.

4. Be sure to read and follow instructions carefully, so you and your pony can have lots of fun together! Remember, S'MORE S'MORE pony is like a real pony in many ways. The more you take care of her and love her, the happier she'll be! Pony comes with carrot, brush, halter and special adoption certificate. FCC STATEMENT This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · · · Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Consult the dealer or an experienced radio/TV technician for help. For indoor use only.

ALKALINE x6 BATTERIES REQUIRED TM © 2007 Hasbro.

All Rights Reserved. TM & ® denote U.S. Trademarks. U.S. Pat. No. 6811461 and Patents Pending 77422 PN 6711000000 Questions? Call 1-800-327-8264 1.5V D or LR20 size FurReal Friends.

com NOT INCLUDED Phillips/cross head screwdriver (not included) needed to insert batteries. MAXIMUM WEIGHT 80lbs/36kg ASSEMBLY "RIDING" YOUR PONY GROOMING YOUR PONY Brush your pony with her special grooming brush to keep her coat healthy. Step 1 Head Body Head Turning Mechanism Head Step 2 Step 1a Your pony can tell when you're sitting on her to have a "ride"! When you sit on your pony, she will move her head up and down, blink her eyes and twitch her ears while making soft sounds. Wait for your pony to stop moving before you take her into "riding mode." Body Pullback head plush. Snap head onto body.

Do not get wet; to remove stains use only a slightly damp cloth. Do not use detergent or stain removers. Avoid spilling food or beverages on the pony. FurReal Friends.

Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries; 3. Always remove weak or dead batteries from the product. If it is dark in the room and the lights come on suddenly while your pony is asleep, she'll lift her head and open her eyes.

If your pony is left alone for a while, she will go into "hangout" mode. She will move her head a little, blink and twitch her ears.

She will whinny and neigh a bit to get your attention! After a few minutes in hangout mode, pony will go into "power save" mode. In this mode, pony will rest with her eyes open if the room is light, and will go to sleep if the room is dark (or start to darken). IMPORTANT: BATTERY INFORMATION Please retain this information for future reference. Batteries should be replaced by an adult. OFF/ON CAUTION: 1.

Always follow the instructions carefully. 2. 3. Remove exhausted or dead batteries from the product. 4. Remove batteries if product is not to be played with for a long time. 5. Do not short-circuit the supply terminals. 6. 7.

RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES. 2 Note: The toy uses battery power whenever switch is in the "ON" position.

S'MORE S'MORE pony responds when you pet her! A. When you pet your pony on her neck/shoulder, or start to groom her mane, she will move her head and neck toward you, and her head will tilt from side to side (she really likes it when you pet her!).



[You're reading an excerpt. Click here to read official HASBRO S'MORE S'MORE MY FURREAL PONY user guide](http://yourpdfguides.com/dref/1196317)
<http://yourpdfguides.com/dref/1196317>