




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO TONKA CHUCK TOW TRUCK. You'll find the answers to all your questions on the HASBRO TONKA CHUCK TOW TRUCK in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO TONKA CHUCK TOW TRUCK
User guide HASBRO TONKA CHUCK TOW TRUCK
Operating instructions HASBRO TONKA CHUCK TOW TRUCK
Instructions for use HASBRO TONKA CHUCK TOW TRUCK
Instruction manual HASBRO TONKA CHUCK TOW TRUCK



[You're reading an excerpt. Click here to read official HASBRO TONKA CHUCK TOW TRUCK user guide](http://yourpdfguides.com/dref/1197234)
<http://yourpdfguides.com/dref/1197234>

Manual abstract:

5V "AA" or R6 size batteries. Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to replace batteries. King Trucks with CHUCK & FRIENDS are tall. They always have the buddy built right in! Kids will love to something to say and kid MY TALKING TOW make them talk! BOOMERs are revved up TRUCK and all his friend and ready for adventure! **TM TO REPLACE BATTERIES** Using a Phillips/crosshead screwdriver (not included), loosen screw in battery compartment cover. Remove cover. Remove and discard batteries. Insert 2 x 1.5V "AA" or R6 size batteries. Alkaline batteries recommended. Replace door and tighten screw with screwdriver.

See diagrams for polarity. 1. @@@@Always remove weak or dead batteries from the product. ! CAUTION: TO AVOID BATTERY LEAKAGE IMPORTANT: BATTERY INFORMATION Please retain this information for future reference. Batteries should be replaced by an adult.

! 1. Always follow the instructions carefully. @@2. @@3. Remove exhausted or dead batteries from the product.

4. Remove batteries if product is not to be played with for a long time. 5. Do not short-circuit the supply terminals. 6. @@@@7. @@Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES. @@These limits are designed to provide reasonable protection against harmful interference in a residential installation.

@@@@If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna. · Increase the separation between the equipment and receiver. @@© 2006 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks. .



[You're reading an excerpt. Click here to read official HASBRO TONKA CHUCK TOW TRUCK user guide](http://yourpdfguides.com/dref/1197234)
<http://yourpdfguides.com/dref/1197234>