



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO TRANSFORMERS BUMBLEBEE. You'll find the answers to all your questions on the HASBRO TRANSFORMERS BUMBLEBEE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO TRANSFORMERS BUMBLEBEE
User guide HASBRO TRANSFORMERS BUMBLEBEE
Operating instructions HASBRO TRANSFORMERS BUMBLEBEE
Instructions for use HASBRO TRANSFORMERS BUMBLEBEE
Instruction manual HASBRO TRANSFORMERS BUMBLEBEE

TRANSFORMERS
DARK OF THE MOON

AUTOBOTS
BUMBLEBEE LEVEL 1, 2, 3

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

AGES 5+

x2
AA BATTERIES INCLUDED

Requires 2 x 1.5 AA (LR6) batteries. Not for use with rechargeable batteries. Do not use with other battery types.

NOTE: Some parts are made to detach if excessive force is applied, and are designed to be reattached if separation occurs. Adult supervision may be necessary for younger children.

TO REPLACE BATTERIES:
Use a Phillips screw head screwdriver (not included) to loosen screw in battery compartment door. Remove door and discard old batteries. Insert 2 x 1.5 AA or six size batteries. Alkaline batteries recommended. Replace door and tighten screw.

IMPORTANT: BATTERY INFORMATION

CAUTION:

- Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- Remove exhausted or dead batteries from the product.
- Remove batteries if product is not to be played with for a long time.
- Do not short-circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**

FCC STATEMENT
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. The equipment generates, uses and can radiate radio frequency energy, and if not used and not well shielded with the equipment, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in certain situations. If the equipment does cause interference to a nearby radio or television receiver, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.
CAUTION: Changes or modifications to this device, not expressly approved by the party responsible for compliance, could void the user's authority to operate the equipment.



[You're reading an excerpt. Click here to read official HASBRO TRANSFORMERS BUMBLEBEE user guide](http://yourpdfguides.com/dref/3981593)
<http://yourpdfguides.com/dref/3981593>

Manual abstract:

Insert 2 x 1.5V "AA" or R6 size batteries. Alkaline batteries recommended. Replace door and tighten screw. **IMPORTANT: BATTERY INFORMATION CAUTION:** 10 11 CoMPARTMENT dooR 1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings. 2. @@3. Remove exhausted or dead batteries from the product.

4. Remove batteries if product is not to be played with for a long time. 5. Do not short-circuit the supply terminals. 6.

@@Reset (switching off and back on again or removing and re-inserting batteries) if necessary. 7. @@Always remove from the product before recharging. Recharge batteries under adult supervision. @@@@ @@@@ However, there is no guarantee that interference will not occur in a particular installation. @@ · Increase the separation between the equipment and receiver. @@ CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. VEHICLE MODE 21 22 CHANGING TO ROBOT 19 1 2 3 20 21 ROBOT MODE 4 5 6 7 8 TM* 9 10 11 TM* 12 13 14 TM* 15 16 17 18 Retain instructions for future reference. Product and colors may vary. Some poses may require hand support. © 2010 Paramount Pictures Corporation. Manufactured under license from TOMY Company, Ltd. ®* and/or TM* & © 2010 Hasbro. All Rights Reserved. TM & ® denote U.

S. Trademarks. .



[You're reading an excerpt. Click here to read official HASBRO TRANSFORMERS BUMBLEBEE user guide](http://yourpdfguides.com/dref/3981593)
<http://yourpdfguides.com/dref/3981593>