




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HASBRO TRANSFORMERS CYBERTRON MEGATRON. You'll find the answers to all your questions on the HASBRO TRANSFORMERS CYBERTRON MEGATRON in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HASBRO TRANSFORMERS CYBERTRON MEGATRON  
User guide HASBRO TRANSFORMERS CYBERTRON MEGATRON  
Operating instructions HASBRO TRANSFORMERS CYBERTRON MEGATRON  
Instructions for use HASBRO TRANSFORMERS CYBERTRON MEGATRON  
Instruction manual HASBRO TRANSFORMERS CYBERTRON MEGATRON



[You're reading an excerpt. Click here to read official HASBRO TRANSFORMERS CYBERTRON MEGATRON user guide](http://yourpdfguides.com/dref/1197579)  
<http://yourpdfguides.com/dref/1197579>

**Manual abstract:**

AGES Requires 2 x 1.5V "AAA" or R03 size batteries (not included). Alkaline batteries recommended. Turn to spin hand-cannon! 3 2 4 1 1 2 3 TM Insert CYBER PLANET KEY™ to reveal hidden power thrusters and activate sound! 2 1 KEY ACTIVATED LIGHTS AND ELECTRONIC INSERT KEY TO ACTIVATE FEATURES! SOUNDS! 1. Insert missile. 2. Remove door. Insert 2 x 1.5V "AAA" or R03 size batteries. Alkaline batteries recommended. Replace door and tighten screw. (2) Make sure the batteries are inserted correctly and follow the toy and battery manufacturers' instructions. 3) Do not mix old and new batteries, alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. CAUTION: FCC Statement: This device complies with part 15 of the FCC Rules. Increase the separation between the equipment and receiver.

Batteries should be replaced by an adult. 1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings. 2.

Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries. 3. Remove exhausted or dead batteries from the product. 4. Remove batteries if product is not to be played with for a long time. 5. Do not short-circuit the supply terminals. 6. 7. Always remove from the product before recharging.

Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES. 8. If swallowed, seek medical attention immediately. GO TO CAUTION: © 2005 Hasbro. All Rights Reserved. TM & ® denote Reg. U.S. Pat. & TM Office. .



[You're reading an excerpt. Click here to read official HASBRO TRANSFORMERS CYBERTRON MEGATRON user guide](http://yourpdfguides.com/dref/1197579)  
<http://yourpdfguides.com/dref/1197579>