




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI KH1000D. You'll find the answers to all your questions on the HITACHI KH1000D in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI KH1000D  
User guide HITACHI KH1000D  
Operating instructions HITACHI KH1000D  
Instructions for use HITACHI KH1000D  
Instruction manual HITACHI KH1000D

## HITACHI KH1000D DAB /FM Radio



User's Guide

### Some Do's And Don'ts On The Safe Use Of Equipment

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

**DO** read the operating instructions before you attempt to use the equipment. **DO** ensure that all electrical connections (including the mains plug, extension leads and inter-connections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections.

**DO** consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

**DON'T** remove any fixed cover as this may expose dangerous voltages. **DON'T** obstruct the ventilation openings of the equipment with items such as newspapers, tablecloths, curtains, etc.

Overheating will cause damage and shorten the life of the equipment.

**DON'T** allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment. **DON'T** place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires.

**DON'T** use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety.

**DON'T** listen to headphones at high volume, as such use can permanently damage your hearing.

**DON'T** leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation. Switch off using the switch on the equipment and make sure that your family knows how to do this. Special arrangements may need to be made for infirm or handicapped people.

**DON'T** continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way switch off, withdraw the mains plug and consult your dealer.



[You're reading an excerpt. Click here to read official HITACHI KH1000D user guide](http://yourpdfguides.com/dref/2814933)  
<http://yourpdfguides.com/dref/2814933>

**Manual abstract:**

*KH1000D DAB /FM Radio DO read the operating instructions before you attempt to use the equipment. DO ensure that all electrical connections (including the mains plug, extension leads and inter-connections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections. DO consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment. DON'T remove any fixed cover as this may expose dangerous voltages. @@Overheating will cause damage and shorten the life of the equipment. @@DON'T place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires. DON'T use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. DON'T listen to headphones at high volume, as such use can permanently damage your hearing.*

*@@@Special arrangements may need to be made for infirm or handicapped people. DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way switch off, withdraw the mains plug and consult your dealer. DAB / FM - DIGITAL RECEIVER SCAN DAB / FM PREV. NEXT SHIFT MENU DISPLAY SELECT User's Guide GETTING STARTED · Press the Power Button to turn on the unit. · Press DAB / FM button to select DAB or FM · Adjust the Volume by pressing Volume Up / Down DAB · Select DAB mode by pressing the DAB /FM button. · Press the SCAN button. @@@@It is possible to manually search for stations. @@@@Stations are listed in numerical then alphabetical order. @@You can, however, choose the station search if you wish to find any new DAB stations or if the radio has been re-located. Simply press the SCAN button. USING THE DAB RADIO Changing DAB stations Press either the PREV or NEXT buttons to scroll through the available stations. The stations will appear on the second line of the display. When the station you require is displayed press the SELECT button. The radio will now tune to that station. Memory/Pre-set radio station: Input Memory: Using the MENU Control The MENU button enables you to configure some of the system options of the DAB radio. These options are arranged in a menu structure as shown below. BBC Radio 5 Live DLS Scrolling... Press MENU · Select the desired station · Press and Hold the preset Key (no.*

*1/6, 2/7, 3/8, 4/9 or 5/10) for 3 seconds, the station will be stored into that preset key no. · Hold the Shift button and press no. key to switch to 6-10. (The unit can store up to 10 pre-set station for FM) Listen to Memory station: BBC Radio 5 Live Station order Press NEXT Press SELECT Fav station Fav station Alphanumeric PREV/NEXT then SELECT Active station Prune Station - Press preset Key (no. 1/6, 2/7, 3/8, 4/9 or 5/10) once to recall that stored station. BBC Radio 5 Live Manual tune Press NEXT Press SELECT 11B 218.64MHz PREV/NEXT then SELECT BBC Radio 5 Live DRC value Press NEXT Press SELECT DRC 1 DRC 0 DRC 2 DRC 1 English English PREV/NEXT then SELECT BBC Radio 5 Live Language Press NEXT Press SELECT BBC Radio 5 Live Sw version Press NEXT Press SELECT v 1.6 Sw version Changing the DAB Station Information It is possible to change the information that is displayed on the second line of the display when listening to a DAB station. @@@@To select an option press the MENU button. 'Station order' will be displayed. @@@@As a guide any value up to 50 is acceptable. @@@@Press the MENU button. 'Station order' will be displayed. Press the NEXT button to display 'Manual tune'. Press the SELECT button.*

*Use the PREV/NEXT buttons to select the channel/frequency. Press the SELECT button. A rectangle will be displayed on first line of the display. The position of this rectangle indicates the signal strength, i.e.*

*@@ 'Station order' will be displayed. Press one of the PREV/NEXT buttons until 'DRC value' is displayed. Press the SELECT button. The current DRC level will be displayed on line 1. Press the PREV/NEXT buttons to select between the three values on line 2 of the display. When the required value is displayed press the SELECT button. Language There is only one option presented-English. Software Version This is provided as a reference when servicing is required. Press the MENU button. @@@@. DRC1 Maximum compression applied (this is the default).*

*@@ · Try adjusting the position of the antenna. Poor reception · As with any radio service there will be areas of weak signal that may cause poor reception. Follow the instructions for Manual Tuning and adjust the antenna while monitoring the signal strength until the optimum signal is obtained. If reception is still poor try relocating the radio to another part of the room. I cannot access secondary services · At the time of publishing this manual not many secondary services are available in the UK. This will increase as more DAB stations start broadcasting. @@@@The radio will try to re-tune to the station. Alternatively perform a SCAN. @@@@2) Left (L) and right (R) audio line out for connection to external amplifier equipment. 3) Optical output connection to external amplifier equipment.*

*SPECIFICATIONS: Power Requirements: DAB Frequency Range (BandIII): Usable Sensitivity: FM Frequency Range: Power Consumption: Rated Output Power: Dimensions: Speaker: ~230V/50Hz 174 - 240 MHz 92 dBm 87.5 - 108MHz 15W 1W x 2 265(W) x 128(H) x 120(D)mm 4 Ohm Note: This product is exclusively available through Dixons Stores Group. In the unlikely event of a problem with your product please return to the store where your purchase was made. Partmaster Direct Partmaster Direct can provide accessories, spares, batteries and replacement parts with Next Day Delivery available upon request.*

*Please call: (UK customers only) Calls charged at National Rate .*

*..or visit our website at [www.partmaster.co](http://www.partmaster.co).*

*uk 0870 600 1338 .*



**[You're reading an excerpt. Click here to read official HITACHI](#)**

**[KH1000D user guide](#)**

**<http://yourpdfguides.com/dref/2814933>**