



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI TRAVELSTAR 5K250. You'll find the answers to all your questions on the HITACHI TRAVELSTAR 5K250 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual HITACHI TRAVELSTAR 5K250**  
**User guide HITACHI TRAVELSTAR 5K250**  
**Operating instructions HITACHI TRAVELSTAR 5K250**  
**Instructions for use HITACHI TRAVELSTAR 5K250**  
**Instruction manual HITACHI TRAVELSTAR 5K250**

## HITACHI Inspire the Next

### Quick Installation Guide Hitachi Travelstar 5K250 & Travelstar E5K250



Models: HTSS42525K9A300 HTE542525K9A300  
HTSS42516K9A300 HTE542516K9A300  
HTSS42512K9A300 HTE542512K9A300  
HTSS42580K9A300 HTE542580K9A300  
HTSS42525K9SA00  
HTSS42516K9SA00  
HTSS42512K9SA00  
HTSS42580K9SA00

#### Handling precautions

- Set the drive down gently to prevent damage from impact or vibration.
- Handle the drive carefully by the edges. Do not touch the exposed printed circuit board or any electronic components.
- Do not press on the top or bottom of the drive.
- Before handling the drive, discharge any static electricity from yourself and your clothing. With one hand touch an unpainted metal surface, then touch the ESD bag with the other hand. Remain in contact with the chassis and the bag for a minimum of two seconds.
- Vibration, shock and static electricity to the drive will damage the precision parts. In particular, prevent vibration or shock generated by dropping, knocking over or hitting the drive. Also, avoid touching the electrical components directly, which can discharge electrostatic energy and damage the drive.



[You're reading an excerpt. Click here to read official HITACHI TRAVELSTAR 5K250 user guide](http://yourpdfguides.com/dref/2839350)  
<http://yourpdfguides.com/dref/2839350>

**Manual abstract:**

*Do not touch the exposed printed circuit board or any electronic components. Do not press on the top or bottom of the drive. Before handling the drive, discharge any static electricity from yourself and your clothing. With one hand touch an unpainted metal surface, then touch the ESD bag with the other hand. Remain in contact with the chassis and the bag for a minimum of two seconds. @@@@The recommended mounting screw torque is  $0.3 \pm 0.05$  Nm. @@@@Other product names are trademarks or registered trademarks of their respective companies. References in this publication to Hitachi Global Storage Technologies products, programs or services do not imply that Hitachi Global Storage Technologies intends to make these available in all countries in which Hitachi Global Storage Technologies operates.*

*Product information is provided for information purposes only and does not constitute a warranty. @@Actual results may vary. This publication is for general guidance only. Photographs may show design models. 05 June 2007 Page 5 version 1.*



[You're reading an excerpt. Click here to read official HITACHI TRAVELSTAR 5K250 user guide](http://yourpdfguides.com/dref/2839350)  
<http://yourpdfguides.com/dref/2839350>