



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HONEYWELL HB85. You'll find the answers to all your questions on the HONEYWELL HB85 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual HONEYWELL HB85**  
**User guide HONEYWELL HB85**  
**Operating instructions HONEYWELL HB85**  
**Instructions for use HONEYWELL HB85**  
**Instruction manual HONEYWELL HB85**

**Honeywell**



**HB 85 / 95**

**Helligkeitssensor-Modul**  
**Montage und Bedienung**

**Brightness Sensor Module**  
**Mounting and Operation**

**Módulo sensor de claridad**  
**Montaje y Operación**



[You're reading an excerpt. Click here to read official HONEYWELL HB85 user guide](http://yourpdfguides.com/dref/2939023)  
<http://yourpdfguides.com/dref/2939023>

**Manual abstract:**

*the HB 85 can be connected to a vane anemometer for measurement of wind speed. This set is sold as HB 95. When selecting the operating site ensure that the distance to radio devices such as radio headphones, cordless phones, etc. According to the DECT standard is at least 1 m. Ensure that there is sufficient distance to metallic objects. Select another mounting site if the radio interference cannot be rectified. @@@@Familiarize yourself with the following steps beforehand. @@@@If the sensor value does not appear, repeat binding. @@@@Do not dispose of used batteries with household rubbish. They must be returned in accordance with the local statutory requirements.*

*Always replace both batteries. Insert new batteries, paying attention to Brightness sensor module not assigned or assigned incorrectly Battery too weak Hereby declares that this device complies with the basic requirements and other relevant regulations of guideline 1999/5/EC. The declaration of conformity of the product can be requested from the manufacturer. @@.*



[You're reading an excerpt. Click here to read official HONEYWELL  
HB85 user guide  
http://yourpdfguides.com/dref/2939023](http://yourpdfguides.com/dref/2939023)