



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HOTPOINT PK 644 D GH X /HA. You'll find the answers to all your questions on the HOTPOINT PK 644 D GH X /HA in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HOTPOINT PK 644 D GH X /HA
User guide HOTPOINT PK 644 D GH X /HA
Operating instructions HOTPOINT PK 644 D GH X /HA
Instructions for use HOTPOINT PK 644 D GH X /HA
Instruction manual HOTPOINT PK 644 D GH X /HA

Istruzioni per l'uso

PIANO

IT Italiano, 1	GB English, 11	FR Français, 20
BE Nederlands, 30	ES Español, 40	DE Deutsch, 50
PT Português, 60	GR Ελληνικά, 70	

PK 644DGH X /HA
PKO 644DGH /HA
PK 755DGH X/HA
PKO 755DGH /HA

Sommario

Installazione, 2-4

Posizionamento
Collegamento elettrico
Collegamento gas

Descrizione dell'apparecchio, 5

Vista d'insieme

Avvio e utilizzo, 6

Consigli pratici per l'uso dei bruciatori
Taglierina caratteristiche

Precauzioni e consigli, 7

Sicurezza generale
Smaltimento

Manutenzione e cura, 8

Escludere la corrente elettrica
Pulire l'apparecchio
Manutenzione tubi netti gas

Anomalie e rimedi, 9

Assistenza, 10
Assistenza attiva 7 giorni su 7

IT



[You're reading an excerpt. Click here to read official HOTPOINT PK 644 D GH X /HA user guide](http://yourpdfguides.com/dref/4641946)
<http://yourpdfguides.com/dref/4641946>

Manual abstract:

It contains important information for safe use, installation and care of the appliance. ! Please keep these operating instructions for future reference. Pass them on to possible new owners of the appliance. Fitting the appliance Gas and mixed hobs are manufactured with type X degree protection against overheating. The following precautions must be taken when installing the hob: • Kitchen cabinets adjacent to the appliance and taller than the top of the hob must be at least 600 mm from the edge of the hob. □ Hoods must be installed according to their relative installation instruction manuals and at a minimum distance of 650 mm from the hob. □ Place the wall cabinets adjacent to the hood at a minimum height of 420 mm from the hob (see figure). If the hob is installed beneath a wall cabinet, the latter must be situated at a minimum of 700 mm above the hob (see figure). gB Positioning ! Keep packaging material out of the reach of children. The appliance must be installed by a qualified professional according to the instructions provided.

Incorrect installation may cause harm to people and animals or may damage property. ! @@@@ 700mm min. @@Fastening hooks are provided, allowing you to fasten the hob to tops that are between 20 and 40 mm thick. To ensure the hob is securely fastened to the top, we recommend you use all the hooks provided. @@@@The air circulation system may take air directly from the outside by means of a pipe with an inner cross section of at least 100 cm²;

A the opening must not be vulnerable to any type of Examples of ventilation holes for comburant air.

blockages. Adjacent Room Room to be Vented 555 mm •Before fastening the cooktop in place, position the seal (supplied) along the perimeter of the countertop, as shown in the figure. Enlarging the ventilation slot between window and floor. The system can also provide the air needed for combustion indirectly, i. e.

From adjacent rooms fitted with air circulation tubes as described above. However, these rooms must not be communal rooms, bedrooms or rooms that may present a fire hazard. Hook fastening diagram Hooking position for top H=20 mm Hooking position for top H=30 mm 12 Front and must comply with current electrical regulations (the earthing wire must not be interrupted by the circuit-breaker). The supply cable must not come into contact with surfaces with temperatures higher than 50°C. ! The installer must ensure that the correct electrical connection has been made and that it is compliant with safety regulations. @@@@□ The socket is compatible with the plug of the appliance. @@@@ ! The cable must not be bent or compressed. ! @@ ! @@ ! Use the hooks contained in the "accessory pack" • Where the hob is not installed over a built-in oven, a wooden panel must be installed as insulation. This must be placed at a minimum distance of 20 mm from the lower part of the hob. Ventilation To ensure adequate ventilation, the back panel of the cabinet must be removed.

It is advisable to install the oven so that it rests on two strips of wood, or on a completely flat surface with an opening of at least 45 x 560 mm (see diagrams).

Gas connection The appliance should be connected to the main gas supply or to a gas cylinder in compliance with current national regulations. @@ !

@@@@ connection with a rigid pipe (copper or steel) ! @@@@@@The earth wire in the cable has a green and yellow cover.

@@@@@ ! @@Checking the tightness of the connection ! @@ never use a flame. @@ ! @@@@The largest slot should be inserted into the ignition. • GAS BURNERS differ in size and power. @@□ Control Knobs for GAS BURNERS adjust the size of the flame. • GAS BURNER ignition enables a specific burner to be lit automatically. □ SAFETY DEVICE stops the gas flow if the flame is accidentally extinguished. 15 Start-up and use ! The position of the corresponding gas burner or electric hotplate* is shown on every knob.

Gas burners Each burner can be adjusted to one of the following settings using the corresponding control knob: • Off Maximum Minimum To turn on one of the burners, place a lighted match or lighter near the burner, press the knob all the way in and turn it anti-clockwise to the "High" setting. The knob must be pressed in for about 6 seconds until the device that keeps the flame lit warms up. Some models are equipped with an ignition button incorporated into the control knob. If this is the case, the ignitor is present. To light a burner, simply press the corresponding knob all the way in and then turn it anti-clockwise to the "High" setting, keeping it pressed in until the burner lights.

! @@@@@@□ Always use cookware with a flat base and a cover. @@@@@@The following warnings are provided for safety reasons and must be read carefully. □ In case of malfunction, under no circumstances should you attempt to repair the appliance yourself. Repairs carried out by inexperienced persons may cause injury or further malfunctioning of the appliance. contact a Service Centre (see Assistance).

□ Always make sure that pan handles are turned towards the centre of the hob in order to avoid accidental burns. • Do not use unstable or deformed pans. □ The appliance should not be operated by people (including children) with reduced physical, sensory or mental capacities, by inexperienced individuals or by anyone who is not familiar with the product. These individuals should, at the very least, be supervised by someone who assumes responsibility for their safety or receive preliminary instructions relating to the operation of the appliance. @@@@□ These instructions are only valid for the countries whose symbols appear in the manual and on the serial number plate. @@@@@@Disposal • The appliance must be used by adults only for the preparation of food, in accordance with the instructions outlined in this booklet. Any other use of the appliance (e. g. For heating the room) constitutes improper use and is dangerous. The manufacturer may not be held liable for any damage resulting from □ The pan support grids have been positioned correctly.

The flame dies in models with a safety device. The burner does not remain lit when set to minimum. the cookware is unstable. If, despite all these checks, the hob does not function properly and the problem persists, call the nearest Customer Service Centre. Please have the following information handy: • The appliance model (Mod. This information can be found on the data plate located on the appliance and/or on the packaging. ! Never use unauthorised technicians and never accept replacement parts which are not original. .



[You're reading an excerpt. Click here to read official HOTPOINT PK 644 D GH X /HA user guide](http://yourpdfguides.com/dref/4641946)
<http://yourpdfguides.com/dref/4641946>