



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HP SLATE 21. You'll find the answers to all your questions on the HP SLATE 21 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual HP SLATE 21**  
**User guide HP SLATE 21**  
**Operating instructions HP SLATE 21**  
**Instructions for use HP SLATE 21**  
**Instruction manual HP SLATE 21**



HP Slate 21 All-in-One

User Guide



[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)

<http://yourpdfguides.com/dref/5512789>

**Manual abstract:**

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

First Edition (August 2013) Document Part Number: 734558-001 Product notice This guide describes features that are common to most models. Some features may not be available on your computer. About This Guide This guide provides information on setting up and using the HP Slate 21 All-in-One. WARNING! Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life. CAUTION: Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information. NOTE: Text set off in this manner provides important supplemental information. iii iv About This Guide Table of contents 1 Product features ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 1 Front components ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 2 Rear components ....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....

*3 2 Setting up the hardware .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*..... 4 Preparing for desk use .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*..... 4 Preparing for wall mounting .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.... 4 Connecting the cables .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 7 Adjusting the tilt .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 10 Turning on the all-in-one for the first time .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 11 Using the touchscreen .....

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.. 12 One-finger slide .....*

.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*..... 12 Tapping .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 12 Pinching/stretching .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

.....  
.... 12 Rotating .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.... 13 Swipes .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 13 Connecting to networks .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 14 Connecting to wireless networks .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... *14 Connecting to wired networks* ....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... *15 Bluetooth* ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. *15 3 Using the user interface* .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 16 Browsing the internet .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

. 17 Playing media ....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.... 17 Using the camera .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

. 18 Printing .....

.....



.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.... 18 Adjusting the settings .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 18 Date/time settings .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*18 Security settings .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 19 Screen lock ...

.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

19 Encryption .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 19 Sound settings .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

19 Language .....



.....

.....

.....

.....

.....

.....

.....

.... 20 v *Factory data reset* .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 21 *Enabling input method editor (IME)* .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.... 21 4 *Safety and Maintenance Guidelines* .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 22 *Important Safety Information* ...

.....

.....

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 22 Maintenance guidelines ...

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 22 Cleaning the all-in-one .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 23 Shipping the all-in-one ..

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
*. 23 5 Frequently asked questions .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 24 6 Product support .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 25 7 Technical specifications ....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 26 HP Slate 21 All-in-One ...*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*. 26 Energy saver feature ....*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*... 27 Appendix A Agency Regulatory Notices ..*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 28 Federal Communications Commission Notice .....*

.....  
.....

.....  
.....  
.....

.....

.....  
.....  
.....  
.... 28 Modifications .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. 28 Cables .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

28 Declaration of Conformity for Products Marked with the FCC Logo (United States Only) .....

.....  
.. 28 Canadian Notice ...

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....



..... 29 *Avis Canadien* ....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 29 *European Union Regulatory Notice* ..

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

... 30 *German Ergonomics Notice* ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 30 *Japanese Notice* .

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*... 30 Korean Notice ..*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 30 Power Cord Set Requirements .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*... 31 Japanese Power Cord Requirements ..*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 31 Product Environmental Notices ..*

.....

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.... 31 ENERGY STAR® Qualification .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.... 31 Materials Disposal .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

... 32 Disposal of Waste Equipment by Users in Private Household in the European Union ..

... 32 HP Recycling Program ..

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

32 Chemical Substances .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 32 Restriction of Hazardous Substances (RoHS) .

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 33 Turkey EEE Regulation .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 33 Ukraine Restriction of Hazardous Substances .....

.....

.....

.....

.....

.....

.....

.....

..... 34 vi 1 Product features The HP Slate 21 All-in-One provides easy, simple access to the internet, and streaming views of media content (video, audio, photos). The all-in-one has an active matrix, thin-film transistor (TFT) panel.

Features include:                         Android 4.2 operating system with multi-user support 54.6 cm (21.5-inch) diagonal viewable area LED display with 1920 x 1080 resolution 5 ms response time, 250 nits, 178/178 viewing angle, 1000:1 contrast ratio Tilt capability from 15 to 70 degrees 2 point optical touchscreen that uses 3 cameras Nvidia Tegra 4 Quad Core (T40S) processor 8 GB flash memory storage 3 USB 2.0 ports Secure Digital (SD) card reader HP TrueVision Webcam (720p HD) and microphone Ethernet jack Audio out ports Plug and play capability that lets the all-in-one automatically recognize hardware devices Wireless 802.

11 a/b/g/n + Bluetooth 4.0 Built-in stereo speakers Wired USB keyboard and mouse included with select models Video Electronics Standards Association (VESA) standard mounting holes for flexible mounting solutions, including wall-mounting Full Internet capability 1 Front components Component (1) (2) (3) (4) (5) (6) (7) (8) (9) Webcam Internal microphone Webcam light Volume up button Volume down button Brightness up button Brightness down button Power button Speakers Function Records video and captures still photographs Records sound On: The webcam is in use Increases volume Decreases volume

Increases display brightness Decreases display brightness Turns the all-in-one on and off Produce sound 2 Chapter 1 Product features Rear components Component (1) (2) (3) (4) (5) (6) (7) SD card reader USB 2.0 connector Audio-out (headphone) jack DC power connector Ethernet connector USB 2.0 connector USB 2.0 connector Function Reads data from and writes data to Secure Digital (SD) memory cards Connects external USB devices to the all-in-one Produces sound when connected to optional powered stereo speakers, headphones, earbuds, or a headset Connects the DC-in cable from the AC power adapter Connects an Ethernet cable to the all-in-one Connects external USB devices to the all-in-one Connects external USB devices to the all-in-one Rea hold it so that you do not topple it while changing the tilt.

Without touching the screen, adjust the tilt by rotating the stand up and down. 10 Chapter 2 Setting up the hardware Turning on the all-in-one for the first time NOTE: For a seamless experience, the Startup Wizard requires an internet connection. Before powering on the all-in-one, please be prepared to establish a wired (Ethernet) or wireless (Wi-Fi) internet connection. After connecting the cables, press the power button on the right side of the all-in-one to turn it on. CAUTION: Burn-in image damage may occur on displays that show the same static image on screen for a prolonged period of time.\* To avoid burn-in image damage on the screen, always turn off the all-in-one when it is not in use for a prolonged period of time. Image retention is a condition that may occur on all LCD screens. Display with a "burned-in image" are not covered under the HP warranty. \* A prolonged period of time is 12 consecutive hours of non-use. When you turn on the all-in-one for the first time, the Startup Wizard will begin.

Follow the instructions in the Startup Wizard to: □ □ □ Select your language. Enter the network settings. Configure the all-in-one to automatically be backed up. HP strongly recommends that you back up the all-in-one. In the case of hardware replacement, backups will allow you to restore your system as seamlessly as possible. Set the date and time. Register your all-in-one with HP. □ □ NOTE: You can modify the settings that were entered in the Startup Wizard any time by accessing Settings from the All Apps screen, accessed using the center icon on the launch bar. For more information on the settings in the Startup Wizard, refer to Adjusting the settings on page 18. If you want to configure security settings, such as passwords, go to Settings from the All Apps screen.

After completing the Startup Wizard, the Home page displays. Turning on the all-in-one for the first time 11 Using the touchscreen A touch screen device allows you to control items on the screen directly with your fingers.



[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)

<http://yourpdfguides.com/dref/5512789>

**TIP:** On touch screen devices, you can also perform on-screen actions with a keyboard and mouse. **One-finger slide** The one-finger slide is mostly used to pan or scroll through lists and pages, but you can use it for other interactions, too, such as moving an object. □ □ To scroll across the screen, lightly slide one finger across the screen in the direction you want to move.

**To drag,** press and hold an object, and then drag the object to move it. **Tapping** To make an on-screen selection, use the tap function. Use one finger to tap an object on the screen to make a selection and/or to open it. **Pinching/stretching** Pinching and stretching allows you to zoom out or in on images or text. □ □ Zoom in by placing two fingers together on the display and then move your fingers apart.

**Zoom out** by placing two fingers apart on the display and then move your fingers together. **12 Chapter 2 Setting up the hardware Rotating** Rotating allows you to turn items such as photos. Anchor the forefinger of your left hand on the object you want to rotate. Using your right hand, slide your forefinger around in a sweeping motion from 12 o'clock to 3 o'clock. To reverse the rotation, move your forefinger from 3 o'clock to 12 o'clock. **NOTE:** Rotate is intended for specific apps where you can manipulate an object or image. Rotate may not be functional for all apps. **Swipes** With swipes you can flip between screens or images. Gently swipe your finger inward from the edge of the display onto the screen to reveal the next or previous screen or image. **Using the touchscreen 13** **Connecting to networks** You can connect to networks with either a wired (Ethernet) or wireless (Wi-Fi) connection.

You cannot enable Ethernet and Wi-Fi connections at the same time. **Connecting to wireless networks** The all-in-one's wireless network capability lets you connect the all-in-one to wireless local area networks (commonly referred to as Wi-Fi networks, wireless LANs, or WLANs). In a WLAN, the mobile wireless module in your all-in-one communicates with a wireless router or a wireless access point. **NOTE:** To set up a WLAN and connect to the Internet, you need a broadband modem (either DSL or cable) (purchased separately), high-speed Internet service purchased from an Internet service provider, and a wireless router (purchased separately). **To connect to a wireless network:** 1. 2. 3. 4. Select the All Apps icon Select Wi-Fi. Select the ON button to turn the wireless radio on.

Select your WLAN from the list. **NOTE:** If no WLANs are listed, you may be out of range of a wireless router or access point. 5. If the WLAN is security-enabled, you are prompted to enter a security code. Type the code, and then select Connect. **from the Home page, and then select Settings. 14 Chapter 2 Setting up the hardware Connecting to wired networks** Use a LAN connection if you want to connect the all-in-one directly to a router in your home (instead of working wirelessly), or if you want to connect to an existing network at your office. **Connecting to a LAN** requires an 8-pin, RJ-45 network cable. **To connect to a wired network:** 1. 2.

Plug the network cable into the network jack (1) on the all-in-one. Plug the other end of the network cable into a network wall jack (2) or router. **NOTE:** If the network cable contains noise suppression circuitry (3), which prevents interference from TV and radio reception, orient the circuitry end of the cable toward the all-in-one. **Bluetooth** The all-in-one includes Bluetooth capability, which creates a personal area network (PAN) to connect to other Bluetooth enabled devices such as computers, phones, printers, headsets, speakers, and cameras. In a PAN, each device communicates directly with other devices, and devices must be relatively close together—typically within 10 meters (approximately 33 feet) of each other. **Connecting to networks 15 3 Using the user interface** The Home page is displayed when the all-in-one is powered on. An Android operating system uses apps to perform most tasks. **NOTE:** The user interface icons for your operating system may look different from the icons shown in the user guide. **Google apps** KingSoft Office Email Gallery Google calendar Camera Google Play Store HP Media Player All apps HP File Manager The row of icons near the bottom of the screen provide quick access to popular apps. Three navigation icons in the black area at the bottom of the screen perform the following functions: **16 Chapter 3 Using the user interface** Return to the previous screen.

**Return to the Home page.** Display a list of open apps. **Browsing the internet** The all-in-one uses the Google Chrome web browser that supports HTML5 and JavaScript to browse the Internet. You must have Internet access to browse the Internet. @ @ 2. 3. @ @ @ @ 2. 3. Open Google Chrome. In the address bar, type chrome:history.

@ @ You can also access the camera using the Play icon. @ @ To play or view your media files: 1. 2. 3. 4. 5. 6. @ @ @ @ Navigate to the desired media file. Select the file to play it. @ @ @ @ You can preview and save the photo or video recording. **To use the camera:** 1. 2. @ @ Select Camera. @ @ @ @ @ @ @ @ Once enabled, ePrint assigns an email address to your printer. @ @ @ @ To configure HP ePrint: 1. 2. 3. 4. Select the All Apps icon Select Add account. Select HP ePrint.

Follow the on-screen instructions. @ @ To set the date and time: 1. 2. Select the All Apps icon Select Date & time. @ @ 3. @ @ @ @ 5. Select Set date to manually set the date. @ @ To set up security settings: 1. 2. 3. **Select the All Apps icon Select Security. @ @ from the Home page, and then select Settings.** Screen lock You can configure the screen on the all-in-one to lock after a period of inactivity. You can choose a specific action the user must perform to unlock the screen. **To configure the screen lock feature:** 1. 2. 3. 4. Select the All Apps icon Select Security. Select Screen lock.

Select the action required to unlock to the screen. **from the Home page, and then select Settings.** Encryption You can encrypt your accounts, settings, downloaded apps and their data, media, and other files. Once you encrypt your all-in-one, you need to type a numeric PIN or password to decrypt it each time you power it on. **NOTE:** The encryption process can take a long time to complete. **CAUTION:** Once you set up encryption, the only way to remove it is to perform a factory data reset. **To set up encryption and a power-on password:** 1. 2. 3. 4.

**Select the All Apps icon Select Security. Select Encrypt tablet.** Follow the on-screen instructions. **from the Home page, and then select Settings.** Sound settings The all-in-one offers DTS Sound+ that you can configure from the Settings screen. **To configure DTS Sound+ settings:** 1. 2. Select the All Apps icon Select DTS Sound+. **from the Home page, and then select Settings.** Adjusting the settings 19 3. 4. Select the ON button to turn on DTS+ Sound. Select the sound type. **Language** To change the language: 1. 2. 3. 4. Select the All Apps icon Select Language & input. Select Language. Select your language. **from the Home page, and then select Settings.**



**[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)**  
<http://yourpdfguides.com/dref/5512789>

*Updating the software* The all-in-one periodically checks for software updates automatically. However, you can manually check for updates as well. To check for system updates: 1. 2. Select the All Apps icon Select About tablet. NOTE: You may have to scroll down the settings list to display About tablet. 3. 4. Select System updates.

To check for updates, select the Check Now button and follow the on screen instructions. from the Home page, and then select Settings. Backup & reset You can configure the all-in-one to back up app data and restore backed up settings and data when reinstalling an app. You can erase all personal data on the all-in-one. Backup & restore To configure backup and restore settings: 1. 2. 3. Select the All Apps icon Select Backup & reset. Select the boxes next to the settings you want to enable. from the Home page, and then select Settings.

20 Chapter 3 Using the user interface Factory data reset You can reset the all-in-one to its original factory data settings. This action erases all data from your all-in-one's internal storage. To reset to factory data: 1. 2. 3.

4. Select the All Apps icon Select Backup & reset. Under Personal Data, select Factory data reset. Select Reset tablet. from the Home page, and then select Settings.

Enabling input method editor (IME) Additional virtual and external keyboard and input methods are available for Hebrew, Arabic, Thai, Korean, Pinyin, Chinese (ZhuYin), Chinese (ChanJie), and Japanese. To select a language: 1. 2. 3. 4. 5. Select the All Apps icon from the Home page, and then select Settings. Select Keyboard & input methods, and then select More keyboards. Select Default, and then select More keyboards. Click the More keyboards icon.

On the More keyboard settings menu, under IME and keyboard settings, select Primary IME, and then select your language. Helpful hints To switch languages on the virtual keyboard:   Press the selected language key or EN/US (English/US) key to toggle between the selected language and English. If you press and hold the language key, available languages display in a pop-up window. Use the following key combinations to perform actions: Key combination Shift + A Alt + Shift Ctrl + Space Behavior Switch from upper or lower case Switch among primary languages Switch between primary and secondary languages To hide the virtual keyboard, click the keyboard icon To select handwriting in virtual mode for Traditional Chinese, Simplified Chinese, Korean, and Japanese, select the handwriting icon Enabling input method editor (IME) 21 4 Safety and Maintenance Guidelines Important Safety Information A power cord is included with the all-in-one. If another cord is used, use only a power source and connection appropriate for this all-in-one. For information on the correct power cord set to use with the all-in-one, refer to the Power Cord Set Requirements on page 31. WARNING! To reduce the risk of electric shock or damage to the equipment: • Do not disable the power cord grounding feature. The grounding plug is an important safety feature. • Plug the power cord in a grounded (earthed) outlet that is easily accessible at all times. • Disconnect power from the product by unplugging the power cord from the electrical outlet.

For your safety, do not place anything on power cords or cables. Arrange them so that no one may accidentally step on or trip over them. Do not pull on a cord or cable. When unplugging from the electrical outlet, grasp the cord by the plug. To reduce the risk of serious injury, read the Safety and Comfort Guide.

It describes proper workstation, setup, posture, and health and work habits for computer users, and provides important electrical and mechanical safety information. This guide is located on the Web at <http://www.hp.com/ergo> and/or on the documentation CD, if one is included with the all-in-one. CAUTION: For the protection of the all-in-one, connect all power cords for the all-in-one and its peripheral devices to some form of surge protection device such as a power strip or Uninterruptible Power Supply (UPS).

Not all power strips provide surge protection; the power strips must be specifically labeled as having this ability. Use a power strip whose manufacturer offers a Damage Replacement Policy so you can replace the equipment, if surge protection fails. Use the appropriate and correctly sized furniture designed to properly support your HP all-in-one. WARNING! All-in-ones that are inappropriately situated on dressers, bookcases, shelves, desks, speakers, chests, or carts may fall over and cause personal injury. Care should be taken to route all cords and cables connected to the all-in-one so that they can not be pulled, grabbed, or tripped over. Maintenance guidelines To enhance the performance and extend the life of the all-in-one:  Do not open the all-in-one cabinet or attempt to service this product yourself. Adjust only those controls that are covered in the operating instructions. If the all-in-one is not operating properly or has been dropped or damaged, contact an authorized HP dealer, reseller, or service provider. Use only a power source and connection appropriate for this all-in-one, as indicated on the label/ back plate of the all-in-one. Be sure the total ampere rating of the products connected to the outlet does not exceed the current rating of the electrical outlet, and the total ampere rating of the products connected to the cord does not exceed the rating of the cord.

Look on the power label to determine the ampere rating (AMPS or A) for each device.   22 Chapter 4 Safety and Maintenance Guidelines  Install the all-in-one near an outlet that you can easily reach. Disconnect the all-in-one by grasping the plug firmly and pulling it from the outlet. Never disconnect the all-in-one by pulling the cord. Turn the all-in-one off when not in use. You can substantially increase the life expectancy of the all-in-one by turning off the all-in-one when not in use. NOTE: All-in-one with a "burned-in image" are not covered under the HP warranty.     Slots and openings in the cabinet are provided for ventilation. These openings must not be blocked or covered. Never push objects of any kind into cabinet slots or other openings.

Do not drop the all-in-one or place it on an unstable surface. Do not allow anything to rest on the power cord. Do not walk on the cord. Keep the all-in-one in a well-ventilated area, away from excessive light, heat or moisture. When removing the all-in-one stand, you must lay the all-in-one face down on a soft area to prevent it from getting scratched, defaced, or broken.

Cleaning the all-in-one 1. 2. 3. Turn off the all-in-one and unplug the power cord from the back of the unit. Dust the all-in-one by wiping the screen and the cabinet with a soft, clean antistatic cloth.

For more difficult cleaning situations, use a 50/50 mix of water and Isopropyl alcohol. CAUTION: Spray the cleaner onto a cloth and use the damp cloth to gently wipe the screen surface.



[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)  
<http://yourpdfguides.com/dref/5512789>

Never spray the cleaner directly on the screen surface. It may run behind the bezel and damage the electronics. CAUTION: Do not use cleaners that contain any petroleum based materials such as benzene, thinner, or any volatile substance to clean the all-in-one screen or cabinet. These chemicals may damage the all-in-one. Shipping the all-in-one Keep the original packing box in a storage area. You may need it later if you move or ship the all-in-one. Maintenance guidelines 23 5 Frequently asked questions Question How do I surf the Internet? Answer Connect to a wired (Ethernet) or wireless (Wi-Fi) network and use one of the two pre-installed browser options. Once you have established an Internet connection, select the All apps icon on the Home screen.

Two browser options are available to choose from: Chrome and Browser. Touch one of the browser options to begin surfing the Internet. How do I install software, such as my favorite game? Find Android apps for your all-in-one in the Google Play Store (in English), an online marketplace featuring both free and paid downloadable content. Yes, you can run some apps and media features offline. You can use some apps without an Internet connection. For example, the preinstalled HP Media Player app allows you to view images and photos, listen to music, and use the camera. How do I open files? You can open files with the app or apps they are associated with. Files are opened within apps or by utilizing the HP File Manager application preinstalled on your all-in-one.

Where do I save files on my all-in-one? How do I print? Can I connect a Bluetooth device to my all-in-one? Where can I find the all-in-one's Wi-Fi MAC address? You can use local storage, an SD memory card, a USB flash drive, or online (cloud) storage to save files. Print wirelessly from your all-in-one using HP's built-in printing solution, the HP ePrint app, or Google Cloud Print.

Yes, many Bluetooth devices are compatible with your all-in-one. The MAC address is listed in the About tablet section of the Settings menu, under Status. 1.

On the Home screen, select the All apps icon then select Settings. In the System section, select About tablet.

Select Status. The Wi-Fi MAC address is listed. Can I install a different operating system on my all-in-one? Android 4.2 is the only operating system supported on the all-in-one. , and Can I use my all-in-one without an Internet connection? 2.

3. 24 Chapter 5 Frequently asked questions 6 Product support For additional information on using your all-in-one, go to <http://www.hp.com/support>. Select your country or region, select Product Support & Troubleshooting, and then enter your model in the SEARCH window. NOTE: The user guide, reference guide, and drivers are available at <http://www.hp.com/support>. The Ethernet cable and Internet access are not provided. If the information provided in the guide does not address your questions, you can contact support.

For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to [http://welcome.hp.com/country/us/en/wwcontact\\_us.html](http://welcome.hp.com/country/us/en/wwcontact_us.html). Here you can:  Chat online with an HP technician NOTE: When support chat is not available in a particular language, it is available in English.

E-mail support Find support telephone numbers Locate an HP service center 25 7 Technical specifications NOTE: All specifications represent the typical specifications provided by HP's component manufacturers; actual performance may vary either higher or lower. Specifications are subject to change.

The complete and latest specifications on display products are available on <http://www.hp.com/support>.

HP Slate 21 All-in-One Maximum weight (unpacked) Dimensions (include base) Height Depth Width Temperature ranges Operating Temperature Non-operating Temperature Humidity Operating (noncondensing) NonOperating (38.7°C maximum wet bulb temperature) Altitude Operating Non-operating Optimum graphic resolution Power source Processor Flash RAM memory Memory USB 2.0 ports Audio Operating system Image / component updates Internet solution (browser) Video player Audio player Photo frame 1920 × 1080 90 – 265 VAC 45/63 Hz ARM A15 Quad Core 1.6 GHz 8 GB 1 GB DDR3L 3 downstream Line Out Android 4.2 OverTheAir (OTA) software updates Google Chrome and Android browser Support Support Support 0 to 5,000 m (0 to 16,400 feet) 0 to 12,192 m (0 to 40,000 feet) 20% to 80% 5% to 95% 35.

4 cm (13.9 inches) 6.7 cm (2.6 inches) 53.1 cm (20.9 inches) 5°C to 35°C (41 to 95°F) -20°C to 60°C (-4 to 140°F) 4.85 kg (10.7 lbs) 26 Chapter 7 Technical specifications Video codecs Video container Audio codecs Audio container Image codecs Image container Productivity - document handler External input device VESA mounting See HP codec list or the nVidia document "Tegra Board Support Package for Android 17r14 Release Software Feature List" See HP codec list or the nVidia document "Tegra Board Support Package for Android 17r14 Release Software Feature List" See HP codec list or the nVidia document "Tegra Board Support Package for Android 17r14 Release Software Feature List" See HP codec list or the nVidia document "Tegra Board Support Package for Android 17r14 Release Software Feature List" JPEG, GIF, PNG, BMP, WEBP JPEG, GIF, PNG, BMP, WebP KingSoft Office Secure Digital (SD) card reader 100 mm × 100 mm For a list of recommended USB and card reader storage devices consult the HP Slate 21 All-in-One Quickspecs. NOTE: HP recommends that the storage device is formatted FAT16/32 or NTFS. ExFAT is not supported.

Energy saver feature The all-in-one supports a reduced power state. The reduced power state will be entered into after a period of inactivity. The all-in-one screen is blanked, the backlight is turned off, and the power light on the power button blinks. When the all-in-one is in the reduced power state, the all-in-one will utilize less than one watt of power. There is a brief warm up period before the all-in-one will return to its normal operating mode. Energy saver feature 27 A Agency Regulatory Notices Federal Communications Commission Notice This equipment has been tested and found to comply with the limits for a Class

B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:    Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.



[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)

<http://yourpdfguides.com/dref/5512789>



Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio or television technician for help. Modifications The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett Packard Company may void the user's authority to operate the equipment. Cables Connections to this device must be made with shielded cables with metallic RF/EMI connector hoods to maintain compliance with FCC Rules and Regulations.

Declaration of Conformity for Products Marked with the FCC Logo (United States Only) This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. 2. This device may not cause harmful interference. This device must accept any interference received, including interference that may cause undesired operation.

For questions regarding the product, contact: Hewlett Packard Company P. O. Box 692000, Mail Stop 530113 Houston, Texas 77269-2000 Or, call 1-800-HP-INVENT (1-800 474-6836) 28 Appendix A Agency Regulatory Notices For questions regarding this FCC declaration, contact: Hewlett Packard Company P. O. Box 692000, Mail Stop 510101 Houston, Texas 77269-2000 Or, call (281) 514-3333 To identify this product, refer to the Part, Series, or Model number found on the product. Canadian Notice This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations. CAN ICES-3(B)/NMB-3(B) Avis Canadien Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada. Canadian Notice 29 European Union Regulatory Notice Products bearing the CE marking comply with one or more of the following EU Directives as may be applicable:    Low Voltage Directive 2006/95/EC; EMC Directive 2004/108/EC; Ecodesign Directive 2009/125/EC; R&TTE Directive 1999/5/EC; RoHS Directive 2011/65/EU Compliance with these directives is assessed using applicable European Harmonised Standards. The full Declaration of Conformity can be found at the following web site: <http://www.hp>.

eu/ certificates. (Search with the product model name or its Regulatory Model Number (RMN), which may be found on the regulatory label.) The point of contact for regulatory matters is Hewlett-Packard GmbH, Dept./MS:HQ-TRE, Herrenberger Strasse 140, 71034 Boeblingen, GERMANY. German Ergonomics Notice HP products which bear the "GS" approval mark, when forming part of a system comprising HP brand computers, keyboards and monitors that bear the "GS" approval mark, meet the applicable ergonomic requirements. The installation guides included with the products provide configuration information. Japanese Notice Korean Notice 30 Appendix A Agency Regulatory Notices Power Cord Set Requirements The all-in-one power supply is provided with Automatic Line Switching (ALS). This feature allows the all-in-one to operate on input voltages between 100–120V or 200–240V. The power cord set (flexible cord or wall plug) received with the all-in-one meets the requirements for use in the country where you purchased the equipment. If you need to obtain a power cord for a different country, you should purchase a power cord that is approved for use in that country.

@@@A power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product. Japanese Power Cord Requirements For use in Japan, use only the power cord received with this product. CAUTION: Do not use the power cord received with this product on any other products. Product Environmental Notices ENERGY STAR® Qualification As an ENERGY STAR® Partner, Hewlett Packard Company has followed the EPA's enhanced product qualification and certification process to ensure that the products marked with the ENERGY STAR® logo are ENERGY STAR® qualified per the applicable ENERGY STAR® guidelines for energy efficiency.

The following ENERGY STAR® certification mark appears on all ENERGY STAR® qualified displays: The ENERGY STAR® program specifications for displays and computers were created by the EPA to promote energy efficiency and reduce air pollution through more energy-efficient equipment in homes, offices, and factories. One way products achieve this goal is by using the Microsoft Windows power management feature to reduce power consumption when the product is not in use. The power management feature enables the computer to initiate a low-power or "sleep" mode after a period of user inactivity. When used with an external ENERGY STAR® qualified display, this feature also supports similar power management features for the display. To take advantage of these potential energy savings, users should use the default power management settings that are provided Power Cord Set Requirements 31 with ENERGY STAR qualified computers and displays.

The default power management settings on ENERGY STAR® qualified computers are preset to behave in the following ways when the system is operating on AC power:   Turn off an external display after 15 minutes of user inactivity Initiate a low power sleep mode for the computer after 30 minutes of user inactivity ENERGY STAR® qualified computers exit the low power sleep mode and ENERGY STAR® qualified displays resume operation when the user resumes use of the computer. Examples include the user pressing the power/sleep button, receiving an input signal from an input device, receiving an input signal from a network connection with the Wake On LAN (WOL) feature enabled, etc. Additional information on the ENERGY STAR® program, its environmental benefits and the potential energy and financial savings of the power management feature can be found on the EPA ENERGY STAR® Power Management Web site at <http://www.energystar.gov/powermanagement>. Materials Disposal Some HP LCD monitors contain mercury in the fluorescent lamps that might require special handling at end-of-life. Disposal of this material can be regulated because of environmental considerations. For disposal or recycling information, contact the local authorities or the Electronic Industries Alliance (EIA) <http://www.eia.org>.

Disposal of Waste Equipment by Users in Private Household in the European Union This symbol on the product or on its packaging indicates that this product must not be disposed of with your household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling or waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.



[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)  
<http://yourpdfguides.com/dref/5512789>

*For more information about where you can drop off your waste equipment for recycling, please contact the local city office, the household waste disposal service or the shop where you purchased the product. HP Recycling Program HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, go to <http://www.hp.com/recycle>. Chemical Substances HP is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements such as REACH (Regulation EC No 1907/2006 of the European Parliament and Council). A chemical information report for this product can be found at <http://www.hp.com/go/reach>. 32 Appendix A Agency Regulatory Notices Restriction of Hazardous Substances (RoHS) A Japanese regulatory requirement, defined by specification JIS C 0950, 2005, mandates that manufacturers provide Material Content Declarations for certain categories of electronic products offered for sale after July 1, 2006. To view the JIS C 0950 material declaration for this product, visit <http://www.hp.com/go/jisc0950>. Turkey EEE Regulation In Conformity with the EEE Regulation EEE Yönetmeliğine Uygundur Product Environmental Notices 33 Ukraine Restriction of Hazardous Substances The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of December 3, 2008 No. 1057, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment. 34 Appendix A Agency Regulatory Notices .*



**[You're reading an excerpt. Click here to read official HP SLATE 21 user guide](http://yourpdfguides.com/dref/5512789)**

**<http://yourpdfguides.com/dref/5512789>**