



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HUSQVARNA R152SV. You'll find the answers to all your questions on the HUSQVARNA R152SV in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HUSQVARNA R152SV
User guide HUSQVARNA R152SV
Operating instructions HUSQVARNA R152SV
Instructions for use HUSQVARNA R152SV
Instruction manual HUSQVARNA R152SV

 **Husqvarna**



R152SV



Instruction manual
Please read these instructions carefully and make sure you understand them before using this machine.

Anleitungshandbuch
Bitte lesen Sie diese Anleitungen sorgfältig durch und vergewissern Sie sich, daß Sie diese verstehen, bevor Sie die Maschine in Betrieb nehmen.

Manuel d'instructions
Si vous n'êtes pas suffisamment sûr de comprendre ces instructions avant d'utiliser cette machine.

Manual de las instrucciones
Por favor lea cuidadosamente y comprenda estas instrucciones antes de usar esta máquina.

Instructieboekje
Lees deze instructies aandachtig en zorg dat u ze begrijpt voordat u deze machine gebruikt.

Manuale di istruzioni
Prima di utilizzare la macchina leggete queste istruzioni con attenzione ed accertatevi di averle comprese bene.



[You're reading an excerpt. Click here to read official HUSQVARNA R152SV user guide](http://yourpdfguides.com/dref/3468755)

<http://yourpdfguides.com/dref/3468755>

Manual abstract:

@@Failure to observe the following safety instructions could result in serious injury or death. Be familiar with the controls and the proper use of the equipment. @@Local regulations may restrict the age of the operator. Never mow while people, especially children, or pets are nearby. @@While mowing, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals. Thoroughly inspect the area where the equipment is to be used and remove all objects which may be thrown by the machine. - Refuel outdoors only and do not smoke while refueling. -

Add fuel before starting the engine. Never remove the cap of the fuel tank or add petrol while the engine is running or when the engine is hot. - If petrol is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until petrol vapors have dissipated. Before using, always visually inspect to see that the blades, blade bolts and cutter assembly are not worn or damaged. replace worn or damaged blades and bolts in sets to preserve balance. @@@Mow only in daylight or in good artificial light. avoid operating the equipment in wet grass , where feasible.

Always be sure of your footing on slopes. Walk, never run. @@@@ - Stop the blade if the lawnmower has to be tilted for transportation when crossing surfaces other than grass, and when transporting the lawnmower to and from the area to be mowed. Never operate the lawnmower with defective guards, or without safety devices, for example deflectors and/or grass catchers, in place. Do not change the engine governor settings or overspeed the engine.

Operating the engine at excessive speed may increase the hazard of personal injury. disengage all blade and drive clutches before starting the engine. @@@@Do not put hands or feet near or under rotating parts. Keep clear of the discharge opening at all times. Never pick up or carry lawnmower while the engine is running. @@@@ go slow when using a trailing seat. @@@@Allow the engine to cool before storing in any enclosure. To reduce the fire hazard, keep the engine, silencer, battery compartment and petrol storage area free of grass, leaves, or excessive grease. If the fuel tank has to be drained, this should be done outdoors. These symbols may appear on your machine or in the literature supplied with the product.

Learn and understand their meaning. Put grass catcher frame into grass bag with lower handle (4) on the bottom. @@Do not drag the bag when emptying, it will cause unnecessary wear. The mower can be set to different cutting levels. Fill the engine with engine oil. Fill the tank with petrol, not oil-blended. Both lead-free and lead-containing petrol may be used. Do not fill with petrol while the engine is running. @@To "STOP" engine, release engine brake yoke.

@@Select ground speed with gear shift lever (3).

@@The mower should not be used on ground that slopes more than 15°. This could cause engine lubrication problems. Before mowing, objects such as twigs, toys and stones should be removed from the lawn. Mow the lawn twice weekly during the most active periods of growth. Never cut more than 1/3 of the length of the grass, especially during dry periods.

Mow with a high cutting height setting the first time. examine the result and lower the mower to the desired setting. Mow slowly or mow the grass twice if it is very long. Always remove the spark plug lead before repair, cleaning or maintenance work. After 5 hours running time, tighten screws and nuts. check the oil. @@The level should be between FULL and ADD. Avoid filling with too much oil. Tighten the screw properly when reassembling. Change oil after each season or after 25 hours running time. Run the engine warm, remove the spark plug lead. Remove the drain plug from bottom of engine and drain oil. Fill with new oil. Over time, ground speed may decrease. Push button (1) back in.

Ground speed should increase. @@@@Before public transporting, engine oil and petrol must be removed. SNCH 11, Route de Luxembourg L-5230 Sandweiler/TUVRheinland Complies with the provisions and current amendments of the following European directives: Â.



[You're reading an excerpt. Click here to read official HUSQVARNA R152SV user guide](http://yourpdfguides.com/dref/3468755)
<http://yourpdfguides.com/dref/3468755>