



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ICOM BC-160. You'll find the answers to all your questions on the ICOM BC-160 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ICOM BC-160
User guide ICOM BC-160
Operating instructions ICOM BC-160
Instructions for use ICOM BC-160
Instruction manual ICOM BC-160




Thank you for purchasing the BC-160 desktop charger. The BC-160 charges a Li-Ion battery pack in approx. 1.5-3 hrs.
Please read these instructions thoroughly before operating the BC-160.

PRECAUTION

- **⚠ DANGER** Charge the specified Icom batteries only. Only tested and approved for use with genuine Icom batteries. Fire and/or explosion may occur when a third party or counterfeit battery pack is charged.
- **⚠ USE INDOORS ONLY! NEVER** expose the charger to rain, snow or any liquids.
- **⚠ CAUTION! NEVER** insert battery pack/transceiver (with the battery pack attached) in a wet or soiled condition into the charger. This may result in corrosion of the charger terminals or damage to the charger. The charger is not waterproof and water can easily get into it.
- **⚠ NEVER** attempt to charge Ni-Cd or Ni-MH batteries. The BC-160 charges Li-Ion batteries only.
- **⚠ NEVER** attempt to charge alkaline or dry cell batteries. They may burst causing damage and personal injury.
- **NEVER** let metal, wire, etc. touch any internal part of the charger.
- **NEVER** inderate used batteries. This may cause an explosion.
- **NEVER** use the charger when it is covered by objects which impede heat dispersal.
- Place the charger in a secure place to avoid inadvertent use by children.
- **AVOID** charging in conditions of extreme cold (under 0°C, +32°F) or extreme heat (over +40°C, +113°F). Batteries may not charge under extreme temperatures.
- Keep the charger away from TV sets or radios to prevent interference.
- Make sure battery and charger contacts are always clean, otherwise batteries may not fully charge.
- **Recommendation**
Li-Ion batteries are different from Ni-Cd batteries in that it is not necessary to completely charge and discharge them to prolong the battery life. Therefore, charging the battery in intervals, and not for extended periods is recommended.
- If your batteries seem to have no capacity even after being fully charged, charge them again. If they still do not retain a charge (or very little), new batteries must be purchased.

BATTERY PACK CHARGING



- **Approx. charging period**
BP-230 : 1.5 hours
BP-231 : 2 hours
BP-232 : 3 hours
- **LED indication**
Orange : During rapid charging
Green : Rapid charging is completed
Red (blink) : The inserted battery pack or the charger has problem.

*When the LED indicator does not light even after a battery pack is inserted properly, the battery pack may have a problem.

Icom, Icom Inc. and the Icom are registered trademarks of Icom Inc. (incorporated in Japan) in the United States and/or other countries.

Icom Inc.
1-1-32 Kamminami, Hirano-ku, Osaka 547-0003, Japan

Count on us!
A-6381D-1EX Printed in Japan
© 2004 Icom Inc.



[You're reading an excerpt. Click here to read official ICOM BC-160 user guide](http://yourpdfguides.com/dref/209466)
<http://yourpdfguides.com/dref/209466>

Manual abstract:

53 hrs. CHARGER. Please read these instructions thoroughly before operating the BC-160. PRECAUTION - DANGER Charge the specified Icom batteries only. Only tested and approved for use with genuine Icom batteries. Fire and/or explosion may occur when a third party or counterfeit battery pack is charged. - RUSE INDOORS ONLY! NEVER expose the charger to rain, snow or any liquids. - RCAUTION! NEVER insert battery pack/transceiver (with the battery pack attached) in a wet or soiled condition into the charger. This may result in corrosion of the charger terminals or damage to the charger. The charger is not waterproof and water can easily get into it.

- RNEVER attempt to charge Ni-Cd or Ni-MH batteries. The BC-160 charges Li-Ion batteries only. - RNEVER attempt to charge alkaline or dry cell batteries. They may burst causing damage and personal injury. - NEVER let metal, wire, etc. touch any internal part of the charger. - NEVER incinerate used batteries. This may cause an explosion. @@@@ Batteries may not charge under extreme temperatures. @@@@ Guide rail Lobs b c -1 6 0 - Approx.

@@Therefore, charging the battery in intervals, and not for extended periods is recommended. If your batteries seem to have no capacity even after being fully charged, charge them again. If they still do not retain a charge (or very little), new batteries must be purchased. Icom, Icom Inc. .



[You're reading an excerpt. Click here to read official ICOM BC-160 user guide](http://yourpdfguides.com/dref/209466)
<http://yourpdfguides.com/dref/209466>