



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ICOM IC-RX7. You'll find the answers to all your questions on the ICOM IC-RX7 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ICOM IC-RX7
User guide ICOM IC-RX7
Operating instructions ICOM IC-RX7
Instructions for use ICOM IC-RX7
Instruction manual ICOM IC-RX7

ICOM WIDEBAND RECEIVER **IC-RX7**

New Style, Slim & Smart Wideband Receiver

Menu-Driven User Interface and Easy-to-See Category Icons
The 4-Way cursor buttons provide quick and easy navigation.

One-Touch Search Button
Easily detects new active channels within a designated frequency range or fixed category.

One-Touch Scan Button
The link scan dynamically adds and deletes a category or a group to the scan list, even while scanning.

Efficient 3-Level Memory Management
A total of 1000 memory channels can be classified in 3 levels by "Category" (up to 26 categories), by "Group" (up to 100), and "Memory name" (up to 100).

Category 01	Group 01	Name 01	Ch 1
Category 02	Group 02	Name 02	Ch 2
Category 26	Group 100	Name 100	

Computer Programmable with Optional CS-RX7 Software

0.150-1300MHz Wide Frequency Coverage
(*Call for details with the US version)

Slim, Stylish and Light Weight
Only 23mm (0.91 in) slim depth and weighing just 205g (7.25 ounces) with BT-244 and antenna.

Tone control function and audio filter*
(*All with memory)



[You're reading an excerpt. Click here to read official ICOM IC-RX7 user guide](http://yourpdfguides.com/dref/2468193)
<http://yourpdfguides.com/dref/2468193>

Manual abstract:

) · Antenna impedance · Dimensions (W×H×D) (projections not included) · Mode : AM, FM, WFM · No. @@(Backlight off) Stand-by 100mA typ. (Backlight off) Power save 35mA typ. @@ · BC-149A/D, BC-153SA WALL CHARGERS 6V DC, 1A output. Same as supplied. · CP-18A/E CIGARETTE LIGHTER CABLE 6V DC, 2A output from 12V cigarette lighter socket. @@OPC-478UC, USB cable is included. @@@@ · OPC-478/UC CLONING CABLES OPC-478: RS-232C type. OPC-478UC: USB type. @@@@ · MB-112G BELT CLIP Same as supplied. @@ · AD-92SMA ANTENNA CONNECTOR ADAPTER Allows you to connect a BNC-type antenna. HP-4 LC-170 CP-18A/E Icom, Icom Inc. @@@@.



[You're reading an excerpt. Click here to read official ICOM IC-RX7 user guide](#)

<http://yourpdfguides.com/dref/2468193>