



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL AVR 480. You'll find the answers to all your questions on the JBL AVR 480 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL AVR 480  
User guide JBL AVR 480  
Operating instructions JBL AVR 480  
Instructions for use JBL AVR 480  
Instruction manual JBL AVR 480




## AVR480 QUICK-START GUIDE

Thank you for purchasing a JBL AVR480. This Quick-Start Guide will help you with a basic system installation. For detailed information on any step in this Guide, please refer to the pages referenced in the Owner's Manual. We strongly recommend that you read the Owner's Manual for complete details on how to install, configure and operate the AVR480, as well as for the important safety information it contains.

### FIGURE 1 - SPEAKER PLACEMENT

The colors shown for each speaker correspond to the matching output terminal connection on the back of the AVR480 (see page 10).



Step 1. Place your speakers in the listening room (see page 17).

CONNECTIONS COLOR GUIDE		
Audio Connections	Left	Right
Front		
Center		
Surround		
Subwoofer		
Digital Audio Connections		
Coax		
Optical		
Video Connections		
Composite		
S-Video		

Match the colored jacks on the AVR480 to the appropriate jacks on your source equipment or speakers. The colors are standardized, but not all equipment or connectors use them.

SPEAKER PLACEMENT



[You're reading an excerpt. Click here to read official JBL AVR 480 user guide](http://yourpdfguides.com/dref/3930575)

<http://yourpdfguides.com/dref/3930575>

**Manual abstract:**

@@For detailed information on any step in this Guide, please refer to the pages referenced in the Owner's Manual. @@@Place your speakers in the listening room (see page 17). SPEAKER PLACEMENT ® PRO SOUND COMES HOMETM AVR480 QUICK-START GUIDE REGION SELECTOR LINE IN/SUB/LFE + \_ + \_ + \_ + \_ + \_ SUBWOOFER SURROUND RIGHT SPEAKER SURROUND LEFT SPEAKER CENTER SPEAKER FRONT RIGHT SPEAKER FRONT LEFT SPEAKER Step 2. Connect the speakers to the receiver: red (+) on speaker to colored (+) on receiver and black ( ) to black ( ). (See page 15.) Step 3. Connect the Subwoofer Pre-Out jack to the Line-In jack on your subwoofer (see page 16). You may adjust the settings on the subwoofer later as needed. FIGURE 2 - SPEAKER CONNECTIONS FIGURE 3 - HOW TO USE THE BINDING-POST SPEAKER TERMINAL FM Antenna AM Antenna L R CD PLAYER Optical Coax REGION SELECTOR AUDIO RECORDER L R REC/IN PLAY/OUT FIGURE 4 - AUDIO CONNECTIONS Dashed lines ( ) indicate coax and optical digital audio connections. @@Connect AM and FM antennas (Figure 4).

(See page 15.) Step 5. @@@@@The Coax input defaults to the DVD player, but may be reassigned. Assign the other digital input and output as appropriate for your equipment (see Step 8). VIDEO connections: If available, connect your source device's component (Y/Pb/Pr) video outputs directly to your TV's component video inputs.

Otherwise, choose either composite (yellow) or S-Video (4-pin) for each video source. Connect the composite and S-Video Monitor outputs to your Video Monitor (TV). @@@@Set it to "C" for China or Hong Kong. @@@@Step 7. @@Plug all components into AC power outlets.

Basic Receiver Configuration Step 8. @@@@Step 9. @@@@@@Otherwise, press the Speaker button and then the Set and arrow buttons to select the correct speaker choices for your system (see pages 1920). Step 11. Set output levels: Set the Balance to 12 o'clock, and the Volume to 15dB. @@@@@@If you have an SPL meter, set it to 75dB, C-Weighting Slow. Press the Test button again. (See pages 2223.) Step 12. @@Choose either type (but not both) for each digital audio source.

Component (Y/Pb/Pr) video connections are preferred; if available, connect the component video outputs on your source device directly to the component video inputs on your TV. Dotted lines (....) indicate composite or S-Video connections for your DVD or VCR. S-Video is the second preferred connection when available, but you may use either composite or S-Video (but not both). If you have two source devices with S-Video, you may connect one S-Video output directly to the TV. @@The Video 3 inputs are on the front panel of the receiver. @@@@\*\* Digital audio recorders only. PRO SOUND COMES HOMETM VIDEO CONNECTIONS ® A Harman International Company 250 Crossways Park Drive, Woodbury, New York 11797 www.jbl.com © 2004 Harman International Industries, Incorporated Part No. 55929040 Out/Play .



[You're reading an excerpt. Click here to read official JBL AVR 480 user guide](#)

<http://yourpdfguides.com/dref/3930575>