



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL AVR 580. You'll find the answers to all your questions on the JBL AVR 580 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL AVR 580
User guide JBL AVR 580
Operating instructions JBL AVR 580
Instructions for use JBL AVR 580
Instruction manual JBL AVR 580



AVR580 QUICK-START GUIDE


Thank you for purchasing a JBL AVR580. This Quick-Start Guide will help you with a basic system installation. For detailed information on any step, please refer to the Owner's Manual pages referenced in this guide. We strongly recommend that you read the Owner's Manual for complete details on how to install, configure and operate the AVR580, as well as for the important safety information it contains.

FIGURE 1 - SPEAKER PLACEMENT

The colors shown for each speaker correspond to the matching output terminal connection on the back of the AVR580 (see page 9).

CONNECTIONS COLOR GUIDE		
Audio Connections	Left	Right
Front		
Center		
Surround		
Subwoofer		
Surround Back		
Digital Audio Connections		
Coxc		
Optical		
Video Connections		
Composite		
S-Video		

Match the colored jacks on the AVR580 to the appropriate jacks on your source equipment or speakers. The colors are standardized, but not all equipment or connectors use them.



Step 1. Place your speakers in the listening room (see page 23).

SPEAKER PLACEMENT



[You're reading an excerpt. Click here to read official JBL AVR 580 user guide](#)

<http://yourpdfguides.com/dref/3930576>

Manual abstract:

@@@For detailed information on any step, please refer to the Owner's Manual pages referenced in this guide. @@@Place your speakers in the listening room (see page 20). SPEAKER PLACEMENT ® PRO SOUND COMES HOMETM AVR580 QUICK-START GUIDE FRONT LEFT SPEAKER CENTER SPEAKER + FRONT RIGHT SPEAKER _ + _ + _ COMP V2 COMP V1 REGION SELECTOR + _ + _ SURROUND LEFT SPEAKER SURROUND RIGHT SPEAKER + LINE IN/SUB/LFE _ FIGURE 2 SPEAKER CONNECTIONS + _ SUBWOOFER SURROUND BACK LEFT SPEAKER SURROUND BACK RIGHT SPEAKER Step 2. Connect the speakers to the receiver: red (+) on speaker to colored (+) on receiver and black () to black () (see page 17). Step 3. Connect the Subwoofer Pre-Out jack to the Line-In jack on your subwoofer. Adjust the settings on the subwoofer later as needed (see page 17). FIGURE 3 HOW TO USE THE BINDING-POST SPEAKER TERMINAL FM Antenna AM Antenna L R CD PLAYER Optical Coax COMP V2 COMP V1 REGION SELECTOR AUDIO RECORDER FIGURE 4 AUDIO CONNECTIONS Dashed lines () indicate coax and optical digital audio connections. @@Connect AM and FM antennas (Fig. 4) (see page 17).

Step 5. @@@@@@The Coax 1 input defaults to the DVD player, but may be reassigned. Assign the other digital inputs and outputs as appropriate for your equipment (see Step 8). VIDEO connections: Choose component (Y/Pb/Pr green/blue/red), composite (yellow) or S-Video (4-pin) for each video source. The devices connected to the Component Video 1 and 2 inputs must be used with the DVD and Video 2 sources respectively.

Connect the component, composite and S-Video Monitor outputs to your Video Monitor (TV). @@@@Set it to "C" for China or Hong Kong. @@@@Step 7. @@Plug all components into AC power outlets. Basic Receiver Configuration Step 8.

@@@@Step 9. @@@@@@Otherwise, press the Speaker button and then the Set and arrow buttons to select the correct speaker choices for your system (see pages 2426). Step 11. Use EzSet to set output levels: Set the Balance to 12 o'clock, and the Volume to 10dB. @@@@@@Step 12. Your system is configured sit back and enjoy! SPEAKER AND AUDIO CONNECTIONS VCR (Video 1) L In/Rec In R Video Video TV or Video Monitor (Video 3) S-Video Component Video Y Pb Pr Y Pb Cable or Sat or HDTV Set-Top Box (Video 2) Component Video Pr L Out R Video S-Video Out L R Optical Coax COMP V2 COMP V1 REGION SELECTOR Component Video L R Video S-Video Y Pb Optical Coax Pr FIGURE 5 VIDEO CONNECTIONS Dashed lines () indicate coax and optical digital audio connections. Choose either type (but not both) for each digital audio source. Dotted lines (....) indicate component, composite or S-Video connections. Component video is the preferred connection when available, but you may use any of the three types (but not more than one). When component, composite and S-Video sources are connected to the AVR you must also connect all outputs from the AVR to your TV.

DVD PLAYER Device Connection Options: Recommended connections are shown in red, but connections may be made to best fit your system requirements.

@@@@@@** Digital audio recorders only. PRO SOUND COMES HOMETM ® VIDEO CONNECTIONS 250 Crossways Park Drive, Woodbury, New York 11797 www.jbl.com © 2004 Harman International Industries, Incorporated Part No. 55929050 Out/Play .



[You're reading an excerpt. Click here to read official JBL AVR 580 user guide](http://yourpdfguides.com/dref/3930576)

<http://yourpdfguides.com/dref/3930576>