



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL CREATURE II. You'll find the answers to all your questions on the JBL CREATURE II in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL CREATURE II
User guide JBL CREATURE II
Operating instructions JBL CREATURE II
Instructions for use JBL CREATURE II
Instruction manual JBL CREATURE II



Document Number: 390 0045 001
Revision: A

Description: MANUAL CREATURE ENGLISH
Page 1 of 6

Harman Multimedia Confidential



[You're reading an excerpt. Click here to read official JBL CREATURE II user guide](http://yourpdfguides.com/dref/3930762)
<http://yourpdfguides.com/dref/3930762>

Manual abstract:

Retain instructions for future reference. Heed warnings --- All warnings on this audio system and in the operating instructions should be adhered to. Follow instructions --- All operating and use instructions should be followed. TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). THERE ARE NO USER SERVICEABLE PARTS INSIDE THIS UNIT, PLEASE REFER SERVICING TO QUALIFIED HARMAN MULTIMEDIA CORPORATION SERVICE PERSONNEL. Do not expose the speakers to liquid or solvent. Never remove grille covers in order to service the speaker system.

The speaker system does not contain any user serviceable parts. Refer all servicing to the Harman Multimedia Technical Support Group. @@Place the speaker system on a stable, level surface.

@@If cleaning is required, use a soft dry cloth. If necessary, use a damp cloth without any solvents. In order to protect the speaker system, avoid microphone feedback, continuous output from electronic musical instruments, or distorted output from any signal source. Do not place the speakers close to fluorescent light sources, or neon light fixtures. Although the speakers are magnetically shielded, keep magnetic storage media (disks and tapes) at least four inches from the speaker system in order to avoid data loss.

@@@@@In addition to the bass, the small, rigid and light inverted aluminum cone provides performance that will rival any tweeter used in multimedia speakers today. The result is a small and elegant satellite speaker that perfectly integrates with the subwoofer while providing superior midrange and highs.

The Magnum series subwoofer transducer provides deep bass. This Magnum series of subwoofers are designed specifically to match with the Harman Multimedia Odyssey Plus transducers. @@@@The system includes two desktop speakers and a subwoofer that can be placed either on the floor or on your desk.

Both satellite speakers and the subwoofer are magnetically shielded to provide the greatest protection against computer monitor image distortion. Setup Carefully unpack your speaker system and identify all components: A Control/Right Satellite speaker B Auxiliary/Left Satellite speaker C Subwoofer D Power Supply E Audio input cable Connect the speaker system as shown in the Connecting the speaker system to sound card illustrations. Once the speaker system is properly connected, turn on the power switch located on the rear of the subwoofer. Document Number: 950-0045-001 Revision: A Harman Multimedia Confidential Description: MANUAL, CREATURE, ENGLISH Page 2 of 6 Step 1 Connecting the speaker system to the computer: · If you have an integrated sound solution or a stereo sound card; connect the green connector from the subwoofer into the green jack on the computer. · If you have a multi-channel sound card; connect the green connector from the subwoofer into the green jack on the computer. · If you have a portable computer; connect the green connector from the subwoofer into the headphone jack on the computer. Step 2 Plug the orange connector from the right/control satellite into the orange jack on the subwoofer. Step 3 Plug the brown connector from the left satellite into the brown jack on the subwoofer. Step 4 Plug the AC power supply jack into the subwoofer. Step 5 Plug the AC plug into the wall outlet.

@@@@@Power will remain on (both speakers' LED's remain illuminated). When muted, touching either the left button or the right button, or both buttons simultaneously will restore volume to the level prior to the activation of the mute function. Controls on the Subwoofer Bass - Turn the knob marked Bass clockwise to increase the subwoofer level or counterclockwise to decrease the subwoofer level. Treble

Turn the knob marked Treble clockwise to increase the treble level or counterclockwise to decrease the treble level. Document Number: 950-0045-001

Revision: A Harman Multimedia Confidential Description: MANUAL, CREATURE, ENGLISH Page 4 of 6 Troubleshooting SYMPTOM No sound from Speakers POSSIBLE PROBLEM No power to unit. SOLUTION Make sure wall power outlet or power strip has power. @@Ensure that the control speaker connector is pushed in properly. @@Turn monitor off to see if noise is eliminated. Move speaker cables farther away from monitor. Ensure that speaker is connected to the appropriate receptacle.

Check color-coding on connectors when making connections. @@Check volume of sound card via Windows Volume Control. Check speakers with another audio source. NOTE Check green power LED on the sub. Are the LED's on? @@Try the solutions shown.

@@These should both be lit. @@Speaker is being overdriven by an amplified audio source. Volume level on sound card may be too high. Sound card or audio source material may be cause of problem. Disconnect speaker input cable (green connector) from sound card and plug into CD ROM headphone jack. If static is eliminated, troubleshoot the soundcard. Check the speaker control settings. Too much bass or treble. Bass/Treble level is set too high Input cables not plugged in properly Input cable may be picking up interference Subwoofer emits a loud hum or buzzing noise. Speaker system experiences radio frequency interference or picks up a radio station Set each of the two knobs (treble, bass level) on front of the subwoofer back the their center /nominal positions. Turn

Bass/Treble down or return their settings to the center position. @@@@However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: a) Re-orient or relocate the receiving antenna. b) Increase the separation between the equipment and receiver. c) Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

d) Consult the dealer or an experienced radio/TV technician for help. MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURER COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT UNDER FCC RULES. Document Number: 950-0045-001 Revision: A Harman Multimedia Confidential Description: MANUAL, CREATURE, ENGLISH Page 6 of 6 .



[You're reading an excerpt. Click here to read official JBL CREATURE II user guide](http://yourpdfguides.com/dref/3930762)
<http://yourpdfguides.com/dref/3930762>