



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL ON STAGE IV. You'll find the answers to all your questions on the JBL ON STAGE IV in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL ON STAGE IV
User guide JBL ON STAGE IV
Operating instructions JBL ON STAGE IV
Instructions for use JBL ON STAGE IV
Instruction manual JBL ON STAGE IV

JBL ON STAGE^{®*} IV

speaker dock for iPod/iPhone



OWNER'S MANUAL



[You're reading an excerpt. Click here to read official JBL ON STAGE IV user guide](http://yourpdfguides.com/dref/3930669)

<http://yourpdfguides.com/dref/3930669>

Manual abstract:

Read these instructions. 2. Keep these instructions. 3. Heed all warnings. 4. Follow all instructions. 5. Do not use this apparatus near water. 6.

Clean only with dry cloth. 7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. 8.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong.

The wide blade or third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. 10. Protect the power cord from being walked on or pinched, particularly at the plugs, convenience receptacles and the point where they exit from the apparatus. 11. Only use attachments/accessories specified by the manufacturer. 12. @@@@13. Unplug this apparatus during lightning storms or when unused for long periods of time. 14.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as: when the power supply cord or plug has become damaged, when liquid has been spilled or objects have fallen into the apparatus, when the apparatus has been exposed to rain or moisture, when the apparatus does not operate normally, or the apparatus has been dropped. 15. Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus. 16. @@@@17. @@@@18. @@@@The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product. WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

FCC regulations FCC InFormation For Users This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation. @@@@ Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by JBL could void the user's authority to operate the equipment. iC statement and Warning This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. ImpoRtANt Note foR All electRoNlc pRoDucts: Before inserting or unplugging audio cables from the source device's headphones or line-level output jacks, it is good practice to turn off the device first. This will prolong the life of your unit, help protect your device from static electricity and prevent potential damage. 2 JBL On stage®* IV easy setup guide 1. Carefully unpack your speaker dock and confirm that all the items shown here are included: JBL On Stage®* IV Speaker Dock, power supply, remote control and iPod/iPhone adapter.

Notes on battery use: · If you are using rechargeable batteries, make sure that all of them are fully charged before inserting them. The JBL On Stage IV will not charge rechargeable batteries. · If you are using conventional batteries, make sure that all of them are fresh. @@Use all of one type or the other. @@@. @@@@ · Do not mix charged and partially charged batteries. · Batteries will not recharge while in JBL On Stage IV. 3. Insert six AA batteries in the compartment. @@@@Dispose of used batteries according to the instructions.

www.jbl.com 3 English 5. @@@@7. @@@@1. 2. USB Type Mini B 6. @@@@ Press the JBL On Stage IV's On/Off button. @@Adjust the volume using the (+) and (-) buttons. Press both buttons to mute the sound; press either button to unmute the sound.

NOTE: If applicable, use the adapter supplied with your iPod or iPhone. www.jbl.com 5 English reMOte cOntrOl ButtOns status led Your JBL On Stage IV's LED will display different colors to indicate the unit's status: led display White Constant White Flashing Amber Constant state JBL On Stage IV is on JBL On Stage IV is muted Low battery JBL On Stage IV is muted and low battery JBL On Stage IV is in Standby mode or off Volume Down Volume Up Play/Pause* Mute/Unmute Amber Flashing No LED Previous/Rewind (Hold for rewind) Next/Fast Forward (Hold for fast forward) Menu Scroll Up Menu Scroll Down Menu Menu Select/Enter * iPod touch and iPhone menu navigation may require you to manually put the iPod/iPhone in music mode. 6 synchrOnIzIng wIth iTunes NOTE: Before attempting to synchronize your iPod/iPhone with iTunes, be sure that both your iPod/iPhone and iTunes are updated to the latest software version.

Before attempting to synchronize, be sure that the JBL On Stage IV's USB port is connected to the computer on which your iTunes is located. 1. @@Make sure the iPod/iPhone is inserted all the way onto the connector. 2. @@@3.

@@@@@As above, it will return to normal operation upon detecting an audio signal, and the LED will light up. Notes on battery power operation: · The JBL On Stage IV will not charge rechargeable batteries. · The JBL On Stage IV will not charge a docked iPod/iPhone while under battery power unless it is also connected to a computer via a USB cable. ipod/iphone chargIng The JBL On Stage IV will charge a docked iPod/iPhone under these conditions: · When the JBL On Stage IV is being powered by its AC power adapter · When the JBL On Stage IV is connected to a computer via a USB cable The JBL On Stage IV will not charge a docked iPod/iPhone while under battery power unless it is also connected to a computer via a USB cable. www.jbl.com 7 English trOuBleshOOtIng yOur JBl On stage IV prOBleM No sound (white led is not illuminated): sOlutiOn · akesurethatthepowersupplyisproperlyconnectedtotheJBLOnStageIVand M to a working AC outlet. · fyou'reusingbatterypower,replaceallsixbatterieswithbrand-newdisposableor I freshly charged rechargeable batteries. The LED will glow amber if the batteries need replacing. · heJBLOnStageIVisintheenergyconservationmode(it has detected no sound T for at least 10 minutes).

No sound (white led is illuminated): · ouchtheVolumeUp(+)buttontoincreasethesystemvolume. @@@@ · eplacetheaudiocable. R · nplugthepowersupplyandconnectittoadifferentACoutlet.



[You're reading an excerpt. Click here to read official JBL ON STAGE IV user guide](#)

<http://yourpdfguides.com/dref/3930669>

*U 8 prOBleM maximum volume level is reduced: sound comes from only one speaker: sOlutIOn ·
heJBLOnStageIVisinbatteryconservationmode(BCM).SwitchtoACpowerfor T higher performance. ·
akesurethattheiPod/iPhoneisproperlyseatedallthewayintothedocking M connector. · akesurethattheaudiocableispluggedallthewayintotheAudioInjack. M ·
akesurethattheaudiocableisastereocable. M www.jbl.*

*com 9 English specIfIcatIOns Compatibility: Docking versions of the iPod, including iPod nano 5th generation, iPod touch 2nd generation, iPod nano 4th
generation, iPod classic, iPod touch 1st generation, iPod nano 3rd generation, iPod nano 2nd generation, iPod 5th generation, iPhone 4GB, 8GB, 16GB,
iPhone 3G 8GB, 16GB, iPhone 3GS 16GB, 32GB, MP3 and CD players, desktop and laptop computers (all platforms) 4 x 1" (25mm) JBL Odyssey®full-
rangetransducers 10 watts x 2 110Hz, 20kHz 70dB 5k ohms .*



[You're reading an excerpt. Click here to read official JBL ON STAGE](#)

[IV user guide](#)

<http://yourpdfguides.com/dref/3930669>