



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL ON TIME MICRO. You'll find the answers to all your questions on the JBL ON TIME MICRO in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual JBL ON TIME MICRO
- User guide JBL ON TIME MICRO
- Operating instructions JBL ON TIME MICRO
- Instructions for use JBL ON TIME MICRO
- Instruction manual JBL ON TIME MICRO

JBL ON TIME™ MICRO

AM/FM RADIO AND SPEAKER DOCK FOR iPod/iPhone



iPod/iPhone not included / iPod/iPhone non inclus

USER GUIDE

English.....	2
Français.....	16
Deutsch.....	30
Italiano.....	44
Español.....	58
Nederlands.....	72
한글.....	86
Dansk.....	100
Japanese.....	114
.....	128
Русский.....	142
Svenska.....	156
Suomi.....	170
Norsk.....	184



[You're reading an excerpt. Click here to read official JBL ON TIME MICRO user guide](http://yourpdfguides.com/dref/3930239)

<http://yourpdfguides.com/dref/3930239>

Manual abstract:

.....
.....
.....
.....

2 Franais

.....
.....

..... 16 Deutsch...

.....
.....
.....

... 30 Italiano

.....
.....
.....

. 44 Espaol

.....
.....

... 58 Nederlands..

.....
.....

..... 72 .

.....
.....
.....

86 Dansk

.....
.....

..... 100 Japanese ..

.....
.....
.....

114

.....
.....
.....

. 128

.....
.....

..... 142 Svenska

.....
.....
.....

156 Suomi

.....
.....

... 170 Norsk ..

.....
.....

.....
.....

.. 184 IMpOrTanT safETy InsTrUcTIOns 1. Read these instructions. 2.

Keep these instructions. 3. Heed all warnings. 4. Follow all instructions. 5. Do not use this apparatus near water. 6. Clean only with a dry cloth. 7.

Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. 8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat. 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus. 11. Only use attachments/accessories specified by the manufacturer. 12.

13. Unplug this apparatus during lightning storms or when unused for long periods of time. 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

15. Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus. 16.

17. 18. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. **IMPORTANT NOTE for all Electrical Products:** Before inserting or unplugging audio cables from the source device's headphones or line-level output jacks, it is good practice to turn off the device first. This will prolong the life of your unit, help protect your device from static electricity and prevent potential damage. 2. jbl On TIME Micro User Guide fcc sTaTEMEnt and WarnInG This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Increase the separation between the equipment and receiver.

Consult the dealer or an experienced radio/TV technician for help. **MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURER COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT UNDER FCC RULES.** IC Statement and Warning This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme la norme NMB-003 du Canada **CAUTION** Risk Of Electric Shock --

DO NOT OPEN THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU TO DANGEROUS VOLTAGE INSIDE THE PRODUCT. **CAUTION: TO REDUCE THE RISK OF SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU TO IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.**

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE. IMPORTANT: THE APPROPRIATE ADAPTER MUST BE INSTALLED BEFORE INSERTING YOUR iPod/iPhone INTO THE JBL PRODUCT. MAKE SURE THAT THE CONNECTOR FOR THE iPod/iPhone IS PROPERLY ALIGNED WITH THE JBL PRODUCT'S CONNECTOR WHEN INSTALLING YOUR iPod/iPhone.

FAILURE TO DO SO MAY CAUSE PERMANENT DAMAGE TO THE CONNECTOR FOR THE iPod/iPhone, RENDERING THE iPod/iPhone INOPERABLE. WWW.

jbl.com 3 English jbl On TIME Micro TM The JBL On Time™ Micro high-performance loudspeaker dock and clock radio for iPod/iPhone will revolutionize the way you listen to your radio, use your iPod/iPhone, and wake from a good night's sleep. The JBL On Time Micro system is a revolution in time travel. Imagine waking up to music on your favorite station or your iPod/iPhone, with no more buzzer or bad radio reception. The compact time machine and sound center, when connected to your iPod/iPhone, MP3 player or other music source, produces clean, powerful sound while providing time-keeping, alarm and radio features.

The JBL On Time Micro loudspeaker dock has full ability to navigate your iPod via IR remote. Also, not only can you wake up to your favorite radio station or song on your iPod/iPhone, but with the multiple alarm setting option, you can set up to seven different alarms for "His" and "Hers," at whatever day or frequency needed. The system's memory is maintained by a backup battery. Even with the power out, it will provide the alarm function.

Then place your iPod/iPhone into the adapter. Connect the external AM antenna for better reception. Unwind the FM antenna and straighten the wire for the best reception. All batteries must be disposed of in an environmentally sound manner. 2. Use Up/Down arrows to highlight Clock.

Press Enter to confirm. 3. Use Up/Down arrows to highlight 12-hour or 24-hour format. Press Enter to confirm. 4. Use Up/Down arrows to set Hour. Press Enter to confirm. Minute field becomes highlighted. 5. Use Up/Down arrows to set Minutes.

Press Enter to confirm. AM/PM field becomes highlighted. 6. Use Up/Down arrows to set Day of Week. Press Enter to confirm.

Press Source button to select the source (iPod/iPhone, AM, FM, Aux). 2. Press "+" button to increase volume. 3. 2.

3. Use Up/Down arrows to select Region and press Enter. Use Up/Down arrows to select language. Press Enter. Use Up/Down arrows to select radio band region type. Press Enter. Alarm Power 1. 2. Otherwise, press Source until FM or AM is selected. 3.

While listening to AM/FM radio, press and hold Preset for 2 seconds. The Radio Preset screen will be displayed. 2. Use Up/Down arrows to select slot to store preset. Press Enter to confirm. Preset is stored! Setting Presets Select Down 1. Press Preset once at any screen to display the Preset list. 2. Use Up/Down arrows to highlight Preset. Press Enter to confirm.

2. Use Up/Down arrows to highlight Alarm. 3. Use Up/Down arrows to select an Alarm slot to edit. Press Enter to confirm.

Hour field becomes highlighted. 4. Use Up/Down arrows to set Hour. Press Enter to confirm. Minute field becomes highlighted.

5. Use Up/Down arrows to set Minutes. Press Enter to confirm. AM/PM field becomes highlighted. 6. Use Up/Down arrows to set AM/PM. Press Enter to confirm. 7. Press Enter to confirm.



You're reading an excerpt. Click here to read official JBL ON TIME MICRO user guide

<http://yourpdfguides.com/dref/3930239>

Use Up/Down arrows to set Alarm source. Press Enter to confirm. @@@@ Use this same procedure button and Snooze Timer setting hot key. If alarm is sounding, enables snooze mode. Press and hold for 2 seconds to enter Snooze Timer setting screen. Directly switches the JBL On Time Micro source to iPod/iPhone. Sends Scroll Down command to iPod/iPhone navigation. Works in iPod/iPhone navigation only. Sends Scroll Up command to iPod/iPhone navigation. Works in iPod/iPhone navigation only.

Cycles to next source. @@@@Next Track in iPod/iPhone navigation only. Does not affect JBL On Time Micro menu navigation or function. Previous Track in iPod/iPhone navigation only. Does not affect JBL On Time Micro menu navigation or function.

Enter/Select in iPod/iPhone navigation only. Does not affect JBL On Time Micro menu navigation or function. Similar function to the center button of the iPod/iPhone. Menu/Up Level in iPod/iPhone navigation only. Does not affect JBL On Time Micro menu navigation or function.

Similar function to the Menu button of the iPod/iPhone. Play/Pause/Mute button. When iPod/iPhone is the active source, a single press sends the Play/Pause command to the iPod/iPhone. When AM, FM or AUX is the active source, a single press mutes audio/amp on the JBL On Time Micro system. 10 jbl On TIME Micro UsEr GUIde jbl On TIMETM Micro MEnU TrEE Now Playing (ON) Now Playing (Off) Clock Alarm Display Sleep Region 12H 24H HR HR AL1-AL7 HOT KEY POINT (on remote or base unit) Brightness Contrast HOT KEY POINT (on remote) Min Min Select Alarm set sleep timer: 15-30-60 A Selection command displays setting confirmation and returns state to Top Level Menu screen. Set Language: English Spanish French German Italian Dutch am/pm Hr set day Press and hold for 2 sec at any point in menu structure, to return to now Playing screen. A Selection command displays setting confirmation and returns state to Top Level Menu screen. Min MO/TU/ WED/TH/FR/ SA/SU/WK/ ED/WE Enable/ Disable Adjust Adjust A Selection command returns state to display menu screen. Set Radio Type: U.S.

Europe Japan AM FM iPod/ iPhone Aux Tone A Selection command displays setting confirmation and returns state to Top Level Menu screen. A Selection command displays setting confirmation and returns state to Top Level Menu screen. WWW.jbl.cOM 11 English jbl On TIMETM Micro MEnU TrEE (cOnT.) PRESET SOURCE SNOOZE HOT KEY POINT (on remote or base unit) HOT KEY POINT (on remote or base unit) HOT KEY POINT (hold button for 3 sec on base unit) SNOOZE Preset 1-10 Press and hold Preset button while listening to radio to store current station. Select slot 1-10 and press enter to store. set snooze timer AM FM iPod/ iPhone Aux A Selection command displays setting confirmation and returns state to Top Level Menu screen. Select and begin playing preset station. 12 jbl On TIME Micro UsEr GUIde spEclfIcaTIOns JBL ON TIMETM MICRO Frequency Response: 70Hz 20kHz Power Consumption: 30 Watts maximum JBL On TimeTM Micro Transducer: Phoenix SE 1-3/4" (45mm) x 2 (full range per channel) Power: 2 x 6 Watts Input Impedance: >5k Ohms Signal-to-Noise Ratio: >80dB Input Sensitivity: 350mV RMS for rated power output Power (USA/Canada): 120 Volts, 60Hz AC Power (Europe/UK): 220 230 Volts, 50Hz or 60Hz AC Power (Japan): 100 Volts, 50Hz or 60Hz AC Power (Australia): 240 Volts, 50Hz or 60Hz AC UL/ple Inc. , registered in the U.S. and other countries. @@@@iPod/iPhone is a trademark of Apple Inc. @@@@ Made for iPod signifie que le dispositif lectronique a t spcialement conu pour se connecter l'iPod et qu'il est certifi par le dveloppeur comme conforme aux normes de performance Apple. Works with iPhone signifie que le dispositif lectronique a t spcialement conu pour se connecter l'iPhone et qu'il est certifi par le dveloppeur comme conforme aux normes de performance Apple. Apple n'est pas responsable du fonctionnement de ce dispositif ou de sa conformit avec les normes de scurit ou rglementaires. iPhone est une marque dpose d'Apple Inc. Harman Consumer Group, Inc. 8500 Balboa Boulevard, Northridge, CA 91329 USA 516. 255.4525 (USA only) www.jbl.com 2009 Harman International Industries, Incorporated. All rights reserved. Tous droits rservs. Document Number: 950-0275-001 REV. A WWW.jbl.cOM .



[You're reading an excerpt. Click here to read official JBL ON TIME MICRO user guide](http://yourpdfguides.com/dref/3930239)

<http://yourpdfguides.com/dref/3930239>