




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL P 1000. You'll find the answers to all your questions on the JBL P 1000 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL P 1000
User guide JBL P 1000
Operating instructions JBL P 1000
Instructions for use JBL P 1000
Instruction manual JBL P 1000



[You're reading an excerpt. Click here to read official JBL P 1000 user guide](http://yourpdfguides.com/dref/3930651)

<http://yourpdfguides.com/dref/3930651>

Manual abstract:

.... 4.50 VOICE COIL INDUCTANCE @ 1 KHZ: L EVC (MH)
... 1.35 S D (IN 2) .
.....
.. 56.02 DRIVER RADIATING AREA: S D (CM2)

363.00 BL (TM) 12.
46 MOTOR FORCE FACTOR: VAS (FT3)
..... 3.
00 COMPLIANCE VOLUME: VAS (LITERS) 71.00 C MS (μ M/N) . . .

. 379.40 SUSPENSION COMPLIANCE: MMS (GRAMS) 74.20 MOVING MASS, AIR LOAD: MMD (GRAMS) . .
... 70.20 MOVING MASS, DIAPHRAGM: FS (HZ) .
.....
.. 30.00 FREE-AIR RESONANCE: Q MS

..... 5.50 MECHANICAL Q: Q ES
.....
... 0.41 ELECTRICAL Q: Q TS .
.....

. 0.38 TOTAL Q: HAG (IN)
. 0.28 MAGNETIC-GAP HEIGHT: HAG (MM)
.....
7.11 HVC (IN)

0.89 VOICE-COIL HEIGHT: HVC (MM) 22.61 X MAX (IN) .
.....
.. 0.31 MAXIMUM EXCURSION: X MAX (MM) . .
..... @ @

@ @ @ @ @ @ 7.37 .



[You're reading an excerpt. Click here to read official JBL P 1000 user guide](http://yourpdfguides.com/dref/3930651)
<http://yourpdfguides.com/dref/3930651>