



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JBL P 6562. You'll find the answers to all your questions on the JBL P 6562 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JBL P 6562
User guide JBL P 6562
Operating instructions JBL P 6562
Instructions for use JBL P 6562
Instruction manual JBL P 6562



[You're reading an excerpt. Click here to read official JBL P 6562 user guide](#)

<http://yourpdfguides.com/dref/3930219>

Manual abstract:

4mm 1-7/8" 47.5mm 3-1/8" 80mm 3-1/2" 88.3mm P662 5/8" 15.2mm 2-1/4" 57.3mm 3-9/16" 90.5mm 5-1/16" 128.6mm P6562 1/2" 12.7mm 2-3/8" 60.9mm 3-9/16" 90mm 5-11/16" 144mm 3-7/8" 99.2mm 3-1/16" 77.

5mm 6-1/4" 158.2mm 4-5/16" 109mm 6-9/16" 166.5mm 1-13/16" 45.3mm P6562S P562 1/2" 13.2mm 2-1/16" 52.

5mm 3-1/8" 80mm 4-3/4" 120mm 2-1/4" 56.7mm P662S 9/16" 14.2mm 1-15/16" 49mm 3-15/16" 100mm 5-1/16" 128.6mm 2-1/4" 56.7mm 6-1/2" 156mm 3-15/16" 100mm 5-11/16" 144mm 3/8" 10.

3mm 2-1/16" 53mm 6-9/16" 166.5mm 5-1/8" 130mm 4" 101.3mm 6-1/4" 158.2mm 4-5/16" 109mm 2-1/4" 56.7mm 6-1/8" 156mm 2-1/16" 51.6mm 2-1/4" 56.7mm P963 11/16" 17.6mm 3-1/4" 82.4mm P8662 P6462 1-9/16" 40mm 3-9/16" 90.5mm 7-3/16" 182.

4mm 9" 229mm 1/2" 13.2mm 2-5/16" 59.3mm 4-5/16" 110mm 8-3/4" 222mm 5-1/4" 133.5mm 4-13/16" 122mm 6-7/16" 163.6mm 4-5/8" 117.6mm 5-11/16" 144.2mm 3-1/2" 89.2mm 6-1/2" 165mm 9-1/4" 234.5mm 3" 76.2mm 4-1/16" 104mm 3/8" 10mm 2-1/4" 56.

7mm 4-3/16 105.9mm 8-7/16" 213.7mm 5-9/16" 142mm 6-3/16" 157mm 2-15/16" 75mm 1-15/16" 50mm BL (T-m) DCR (ohms) Mms (g) Sd (sq cm) Cms ($\mu\text{m/N}$) Vas (l) Fs (Hz) Qes Qms Qt 1wSPL (dB) P462 2.76 2.28 4.

86 56.8 300 1.36 131.8 1.20 8.

21 1.05 86.0 P562 3.04 2.38 8.16 100.3 332 4.69 96.7 1.28 8.

12 1.10 87.1 P562 5-1/4" 2-Way 2 Ohms 55W 165W 55Hz 23kHz 92dB P662 3.51 2.38 11.79 132.7 301 7.45 84.5 1.21 10.

58 1.09 87.6 P662 6-1/2" 2-Way 2 Ohms 75W 225W 45Hz 23kHz 93dB P662S 3.66 2.30 10.

73 132.7 330 8.17 84.6 0.98 7.

86 0.87 89.0 P662S 6-1/2" 2-Way Shallow 2 Ohms 55W 165W 55Hz 23kHz 93dB P6562 3.43 2.34 12.49 141.0 282 7.87 84.8 1.32 9.

47 1.16 87.5 P6562 165mm 2-Way 2 Ohms 75W 225W 45Hz 23kHz 93dB P6562S 3.73 2.48 11.95 141.0 302 8.43 83.8 1.12 9.

12 1.00 88.4 P6562S 165mm 2-Way Shallow 2 Ohms 55W 165W 55Hz 23kHz 93dB P963 P963 5.41 2.44 21.

83 237.5 422 33.43 52.4 0.60 9.

70 0.56 91.0 P6462 3.00 2.19 5.78 56.8 367 1.66 109.3 0.97 6.

46 0.84 85.4 P6462 4" x 6" 2-Way 2 Ohms 50W 150W 75Hz 23kHz 91dB P8662 3.47 2.40 15.27 158.1 238 8.35 83.5 1.60 5.

95 1.26 86.8 P8662 5" x 7"/6" x 8" 2-Way 2 Ohms 75W 225W 40Hz 23kHz 92dB SPECIFICATIONS P462 Type: Nominal Impedance: Power Handling, RMS: Power Handling, Peak: Frequency Response: Sensitivity (2.83V, 1m): 4" 2-Way 2 Ohms 50W 150W 75Hz 23kHz 91dB 6" x 9" 2-Way 2 Ohms 110W 330W 35Hz 23kHz 96dB GENERAL CARE: The loudspeaker grilles may be cleaned with a damp cloth. @@WARRANTY: Power Series speakers are warranted against defects.

@@Your local JBL car audio retailer can help you determine the length of your warranty. @@@@Harman Consumer Group, Inc. @@All rights reserved. Part No. POWERMEOM11/07 JBL and Power Series are trademarks of Harman International Industries, Incorporated, registered in the United States and/or other countries.

We, Harman Consumer Group, Inc. @Château du Loir, France 11/07 www.jbl.com .



[You're reading an excerpt. Click here to read official JBL P 6562 user guide](http://yourpdfguides.com/dref/3930219)

<http://yourpdfguides.com/dref/3930219>