



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JVC KD-G321. You'll find the answers to all your questions on the JVC KD-G321 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JVC KD-G321  
User guide JVC KD-G321  
Operating instructions JVC KD-G321  
Instructions for use JVC KD-G321  
Instruction manual JVC KD-G321

**JVC**

CD RECEIVER  
RECEPTEUR CD

**KD-G322/KD-G321**

Detachable

MP3

WMA

RDS

COMPACT DISC  
DIGITAL AUDIO

KD-G322

KD-G321

For canceling the display demonstration, see page 5.  
Pour annuler la démonstration des affichages, référez-vous à la page 5.

For installation and connections, refer to the separate manual.  
Pour l'installation et les raccordements, se référer au manuel séparé.

**INSTRUCTIONS**  
MANUEL D'INSTRUCTIONS

GET0344-003A  
[EX:EU]



[You're reading an excerpt. Click here to read official JVC KD-G321 user guide](http://yourpdfguides.com/dref/3663752)  
<http://yourpdfguides.com/dref/3663752>

**Manual abstract:**

There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel. 3. CAUTION: Visible and invisible laser radiation when open and interlock failed or defeated. If you need to operate the unit while driving, be sure to look ahead carefully or you may be involved in a traffic accident. Discs produce very little noise compared with other sources. Lower the volume before playing a disc to avoid damaging the speakers by the sudden increase of the output level. How to reset your unit If this does not work, reset your unit. • Be careful not to drop the disc when it ejects. Note: Only for [EX] model users in UK and European countries For security reasons, a numbered ID card is provided with this unit, and the same ID number is imprinted on the unit's chassis. Keep the card in a safe place, as it will help the authorities to identify your unit if stolen.

How to read this manual • Button operations are mainly explained with the illustrations in the table below. Some related tips and notes are explained in "More about this unit" (see pages 15 & 17). Playing a disc in the unit . How to use the M MODE button If you press M MODE, the unit goes into functions mode, then the number buttons and 4 buttons work as different function buttons. ex.

: When number button 2 works as MO (monaural) button. ••••• If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit. \* You cannot select "DISC" as the playback source if there is no disc in the unit. The power is turned off Adjust the sound as you want. To turn off the power Lights up when receiving an FM stereo broadcast with sufficient signal strength.

Lights up when monaural mode is activated. When a station is received, searching stops. You can preset six stations for each band. "SSM" flashes, then disappears when automatic presetting is over. Local FM stations with the strongest signals are searched and stored automatically in the FM band. 5 MHz into preset number 4 of the FM1 band. What you can do with RDS rDS (Radio Data System) allows FM stations to send an additional signal along with their regular programme signals. By receiving the RDS data, this unit can do the following: • You can tune in to a station broadcasting your favorite programme by searching for a PTY code. If there is a station broadcasting a programme of the same PTY code as you have selected, that station is tuned in. TA Standby Reception allows the unit to switch temporarily to Traffic Announcement (TA) from any source other than AM.

The volume changes to the preset TA volume level if the current level is lower than the preset level (see page 13). You can store six favorite programme types. (This occurs when you are listening to an FM station without the RDS signals required for TA Standby Reception. ) To activate TA Standby Reception, tune in to another station providing these signals. Select the preset number (1 & 6) you want to store into. PTY Standby Reception allows the unit to switch temporarily to your favorite PTY programme from any source other than AM. To activate PTY Standby Reception, tune in to another station providing these signals. Repeat steps 1 and 2 to store other PTY codes into other preset numbers. When driving in an area where FM reception is not sufficient enough, this unit automatically tunes in to another FM RDS station of the same network, possibly broadcasting the same programme with stronger signals (see the illustration below). When shipped from the factory, NetworkTracking Reception is activated.

Playing a disc in the unit To use direct folder access on MP3/WMA discs, it is required that folders are assigned with 2-digit numbers at the beginning of their folder names--01, 02, 03, and so on. All tracks will be played repeatedly until you change the source or eject the disc. You can lock a disc in the loading slot.

You can use only one of the following playback modes at a time. All tracks of the current folder, then tracks of the next folder and so on.

: Elapsed playing time with the current track number : Clock with the current track number \*1 If the current disc is an audio CD, "NO NAME" appears. \*2 If an MP3/WMA file does not have ID3 tags , folder name and file name appear. In this case, the TAG indicator will not light up. You can select a preset sound mode suitable to the music genre (C-EQ: custom equalizer). You can adjust the sound characteristics to your preference.

LOUD\*4 (loudness), [LOUD ON or LOUD OFF] Boost low and high frequencies to produce a well-balanced sound at low volume level. VOL (volume) , [00 to 30 or 50\*6] Adjust the volume. ••••• Repeat steps 2 and 3 to adjust other PSM items if necessary. ••••• You can change the maximum volume level of this unit. ••••• To keep discs clean A dirty disc may not play correctly. ••••• New discs may have some rough spots around the inner and outer edges. If such a disc is used, this unit may reject the disc. ••••• Should this occur, the CD player may malfunction. ••••• Do not touch its recording surface. ••••• Make sure to store discs into the cases after use.

••••• If you want to know more about RDS, visit ••••• The Non-DVD side of a "DualDisc" does not comply with the "Compact Disc Digital Audio" standard. Therefore, the use of NonDVD side of a DualDisc on this product may not be recommended. • All previously stored stations are erased and stations are stored newly. When storing a station manually, the previously preset station is erased when a new station is stored in the same preset number. MP3 and WMA "tracks" (words "file" and "track" are used interchangeably) are recorded in "folders. " • When a disc has been loaded, selecting "DISC" for the playback source starts disc play. Network-Tracking Reception requires two types of RDS signals--PI (Programme Identification) and AF (Alternative Frequency) to work correctly. Without receiving these data correctly, NetworkTracking Reception will not operate correctly. • If a Traffic Announcement is received by TA Standby Reception, the volume level automatically changes to the preset level (TA VOL) if the current level is lower than the preset level.

When a disc is inserted upside down, the disc automatically ejects. While fast-forwarding or reversing on an MP3 or WMA disc, you can only hear intermittent sounds. This unit can play back only files of the same type which are first detected if a disc includes both audio CD (CD-DA) files and MP3/WMA files. • This unit can play back multi-session discs; however, unclosed sessions will be skipped while playing. • Some CD-Rs or CD-RWs may not play back on this unit because of their disc characteristics, or for the following reasons: • Discs are dirty or scratched.



[You're reading an excerpt. Click here to read official JVC KD-G321 user guide](http://yourpdfguides.com/dref/3663752)  
<http://yourpdfguides.com/dref/3663752>

• Moisture condensation occurs on the lens inside the unit. • The pickup lens inside the unit is dirty. • CD-R/CD-RW on which the files are written with "Packet Write" method. CD-RWs may require a longer readout time since the reflectance of CD-RWs is lower than that of regular CDs. • Do not use the following CD-Rs or CD-RWs: • Discs with stickers, labels, or protective seal stuck to the surface.

• Discs on which labels can be directly printed by an ink jet printer. Using these discs under high temperatures or high humidities may cause malfunctions or damage to the unit. This unit can play back MP3/WMA files with the extension code <. This unit can show the names of albums, artists (performer), and ID3 Tag (Version 1. This unit can display only one-byte characters. No other characters can be correctly displayed. This unit can play back MP3/WMA files meeting the conditions below: • Bit rate: 8 kbps -- 320 kbps • Sampling frequency: 48 kHz, 44. The maximum number of characters for file/ folder names vary among the disc format used (includes 4 extension characters--<. This unit can recognize a total of 512 files, of 200 folders, and of 8 hierarchies. @@@@ @@@@ • WMA files encoded with lossless, professional, and voice format.

• WMA files which are not based upon Windows Media® Audio. The search function works but search speed is not constant. If you change the source, playback also stops (without ejecting the disc). Next time you select "DISC" for the playback source, disc play starts from where it has been stopped previously. If the ejected disc is not removed within 15 seconds, the disc is automatically inserted again into the loading slot to protect it from dust. (Disc will not play this time. What appears to be trouble is not always serious. Check the following points before calling a service center. Sound cannot be heard from the speakers. • The unit does not work at all.

Disc cannot be played back. CD-R/CD-RW cannot be pla.



[You're reading an excerpt. Click here to read official JVC KD-G321 user guide](http://yourpdfguides.com/dref/3663752)

<http://yourpdfguides.com/dref/3663752>