



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JVC KD-G431. You'll find the answers to all your questions on the JVC KD-G431 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JVC KD-G431
User guide JVC KD-G431
Operating instructions JVC KD-G431
Instructions for use JVC KD-G431
Instruction manual JVC KD-G431

JVC KD-G432/KD-G431/
KD-SC402/KD-SC401
Installation/Connection Manual
Manuel d'installation/raccordement

© 2008 Victor Company of Japan, Limited

© 2008 VICTOR INC.
EN FR
© 2008 Victor Company of Japan, Limited

ENGLISH

This unit is designed for use as a 12 VDC NEGATIVE ground vehicle system. If your vehicle does not have this system, a voltage converter is required, which can be purchased at JVC INC. CA. EXETER, VERMONT, USA.

WARNINGS

Do not open the case, as it is not suitable for use as the battery's negative terminal in double all electrical connections (including the car).

• **Always disconnect the unit for the car's chassis upon its installation.**

Notes:

- Do not install with use of this period of time. If the fuse blows frequently, consult your JVC INC. CA. EXETER, VERMONT, USA.
- A maximum of 100 watts is allowed for the speaker with maximum power of more than 50 W (both at the car and at the home, with impedance of 4Ω to 16Ω). If the maximum power is less than 50 W, change "AMP/CA" settings to avoid the speaker from being damaged (see page 14 of the USER'S GUIDE).
- To prevent short-circuit, insert the terminal of the 12V/2000 mAh lead with insulating tape.
- The heat sink becomes very hot after use. Be careful not to touch it when removing the case.

FRANCAIS

Cet appareil est conçu pour fonctionner sur les véhicules à câblage continu 12V à masse NEGATIVE. Si votre véhicule ne dispose pas de ce système, un convertisseur de tension est requis, que vous pouvez acheter chez un détaillant d'électronique (JVC).

AVERTISSEMENTS

N'ouvrez pas le boîtier, car il n'est pas adapté à l'utilisation en tant que borne négative de la batterie dans des installations électriques multiples (y compris la voiture).

• **Toujours débrancher l'appareil de la masse du châssis de la voiture après l'installation.**

Remarques:

- Ne pas installer l'appareil pendant la durée de la garantie. Si la fusible saute fréquemment, consultez votre revendeur JVC au Canada (JVC).
- La puissance maximale autorisée pour les haut-parleurs est de 100 W (à la fois dans la voiture et à la maison, avec une impédance de 4Ω à 16Ω). Si la puissance maximale autorisée est inférieure à 50 W, changez "AMP/CA" pour éviter d'endommager les haut-parleurs (voir page 14 du MANUEL D'UTILISATION).
- Pour éviter les courts-circuits, insérez le bornier de la pile avec un ruban isolant.
- Le dissipateur de chaleur devient très chaud après utilisation. Soyez attentif de ne pas toucher ce boîtier après l'appareil.

PRECAUTIONS on power supply and speaker connections:

- **DO NOT connect the speaker leads of the power cord to the car battery; otherwise, the unit will be seriously damaged.**
- **BEFORE connecting the speaker leads of the power cord to the speakers, check the speaker wiring in your car.**

PRECAUTIONS sur l'alimentation et la connexion des enceintes:

- **NE CONNECTEZ PAS les fils de connexion des enceintes d'alimentation à la batterie, sinon, l'appareil sera sérieusement endommagé.**
- **AVANT de connecter les fils d'alimentation des enceintes, vérifiez le câblage des enceintes de votre voiture.**

Parts list for installation and connection

This kit contains parts required for the unit. If any item is missing, consult your JVC INC. CA. EXETER, VERMONT, USA.

Liste des pièces pour l'installation et le raccordement

Cette notice comprend les pièces requises pour l'appareil. Si quelque chose manque, consultez votre revendeur au Canada (JVC) immédiatement.

① Case
Boîtier

② Screws
Vis

③ Screws
Vis

④ Power cord
Câble d'alimentation

⑤ Rubber feet
Pieds caoutchouc

⑥ Lock nut (M3)
Bouche écrou (M3)

⑦ Mounting tab (30 x 10 mm)
Pied de montage (30 x 10 mm)

⑧ Rubber rollers
Roulettes caoutchouc

⑨ Screws
Vis



[You're reading an excerpt. Click here to read official JVC KD-G431 user guide](http://yourpdfguides.com/dref/3661189)

Manual abstract:

It is recommended to connect to the speakers with maximum power of more than 50 W (both at the rear and at the front, with an impedance of 4 to 8). If the maximum power is less than 50 W, change "AMP GAIN" setting to prevent the speakers from being damaged (see page 14 of the INSTRUCTIONS). To prevent short-circuit, cover the terminals of the UNUSED leads with insulating tape. The heat sink becomes very hot after use. Be careful not to touch it when removing this unit. DO NOT connect the speaker leads of the power cord to the car battery; otherwise, the unit will be seriously damaged. BEFORE connecting the speaker leads of the power cord to the speakers, check the speaker wiring in your car. The following parts are provided for this unit. If any item is missing, consult your JVC IN-CAR ENTERTAINMENT dealer immediately. The following illustration shows a typical installation.

If you have any questions or require information regarding installation kits, consult your JVC IN-CAR ENTERTAINMENT dealer or a company supplying kits. @@Before removing the unit, release the rear section. @@@@Install the unit at an angle of less than 30°. installez l'appareil avec un angle de moins de 30°. @@@@If longer screws are used, they could damage the unit.

*Power cannot be turned on. Noise interfere with sounds. @@This unit does not work at all. * Have you reset your unit? @@ Contact your authorized car dealer before installing this unit. @@@@Remote lead Fil d'alimentation à distance Y-connector (not supplied for this unit) Connecteur Y (non fourni avec cet autoradio) You can connect an amplifier to upgrade your car stereo system.*

Connect the remote lead (blue with white stripe) to the remote lead of the other equipment so that it can be controlled through this unit. Disconnect the speakers from this unit, connect them to the amplifier. Leave the speaker leads of this unit unused. Remote lead (Blue with white stripe) Fil d'alimentation à distance (Bleu avec bande blanche) To the remote lead of other equipment or power aerial if any Au fil de télécommande de l'autre appareil ou à l'antenne automatique s'il y en a une If your car is equipped with the steering wheel remote controller, you can operate this unit using the controller. To do it, a JVC's

*OE remote adapter (not supplied) which matches with your car is required. You can connect these components as illustrated below. The iPod*6 can be connected using an interface adapter (not supplied)--KS-PD100. Before connecting the external components, make sure that the unit is turned off. @@@@ failure to do so may cause damage to the unit. @@.*



[You're reading an excerpt. Click here to read official JVC KD-G431 user guide](http://yourpdfguides.com/dref/3661189)

<http://yourpdfguides.com/dref/3661189>