



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JVC KD-R511. You'll find the answers to all your questions on the JVC KD-R511 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JVC KD-R511
User guide JVC KD-R511
Operating instructions JVC KD-R511
Instructions for use JVC KD-R511
Instruction manual JVC KD-R511



Having TROUBLE with operation?
Please reset your unit
Refer to page of How to reset your unit
Vous avez des PROBLÈMES de fonctionnement?
Réinitialisez votre appareil
Référez-vous à la page intitulée Comment réinitialiser votre appareil

JVC



ENGLISH
FRANÇAIS


KD-R511

CD RECEIVER / RÉCEPTEUR CD

Dear Customer,
This apparatus is in conformance with the valid European directives and standards regarding electromagnetic compatibility and electrical safety.
European representative of Victor Company of Japan, Limited is:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Germany

Cher(e) client(e),
Cet appareil est conforme aux directives et normes européennes en vigueur concernant la compatibilité électromagnétique et à la sécurité électrique.
Représentant européen de la société Victor Company of Japan, Limited:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Allemagne

Detachable



Radio Data System **MP3 WMA**



For canceling the display demonstration, see page 4. / Pour annuler la démonstration des affichages, référez-vous à la page 4.

For installation and connections, refer to the separate manual. / Pour l'installation et les raccordements, se référer au manuel séparé.

JVC



INSTRUCTIONS
MANUEL D'INSTRUCTIONS

EN, FR
© 2009 Victor Company of Japan, Limited

1209DTSMDTJEIN

GET0635-003A
[E/EU]



[You're reading an excerpt. Click here to read official JVC KD-R511 user guide](http://yourpdfguides.com/dref/2821591)
<http://yourpdfguides.com/dref/2821591>

Manual abstract:

CAUTION: Visible and/or invisible class 1M laser radiation when open. Do not view directly with optical instruments. @@[European Union only] These symbols indicate that the product and the battery with this symbol should not be disposed as general household waste at its end-of-life. If you wish to dispose of this product and the battery, please do so in accordance with applicable national legislation or other rules in your country and municipality. By disposing of this product correctly, you will help to conserve natural resources and will help prevent potential negative effects on the environment and human health.

Notice: The sign Pb below the symbol for batteries indicates that this battery contains lead. Do not raise the volume level too much, as this will block outside sounds, making driving dangerous. â· Stop the car before performing any complicated operations. If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit. This unit is equipped with the steering wheel remote control function. Before operating, connect a JVC's OE remote adapter (not supplied) which matches your car to the steering wheel remote input terminal on the rear of the unit. How to read this manual The following icons/symbols are used to indicate: Press and hold the button(s) Turn the control dial to make a selection, then press to confirm. (XX) <XXXX> Reference page number Menu setting item Continued on the next page Canceling the display demonstration Setting the clock Basic operations Listening to the radio Listening to a disc Listening to the USB device Listening to the other external components Using the remote controller Selecting a preset sound mode Menu operations Maintenance More about this unit Troubleshooting Specifications How to reset your unit Be careful not to drop the disc when it ejects. â· If this does not work, reset your unit. Auxiliary input jack Remote sensor You can control this unit with an optionally 12).

When you press or hold the following button(s). Selects the available sources (if the power is turned on). "ST" lights up when receiving an FM stereo broadcast with sufficient signal strength.] <TUNER>] <SSM>] <SSM 01 Â 06> / <SSM 07 Â 12> / <SSM 13 Â 18> "SSM" flashes and local stations with the strongest signals are searched and stored automatically. To preset another 6 stations, repeat the above procedure by selecting one of the other 6 SSM setting ranges.

50 MHz into preset number "04. The following features are available only for FM Radio Data System stations. You can tune in to a station broadcasting your favourite programme by searching for a PTY code. If there is a station broadcasting a programme of the same PTY code as you have selected, that station is tuned in. TA Standby Reception allows the unit to switch temporarily to Traffic Announcement (TA) from any source other than AM. â· The volume changes to the preset TA volume level if the current level is lower than the preset level. Network-Tracking Reception When driving in an area where FM reception is not sufficient enough, this unit automatically tunes in to another FM Radio Data System station of the same network, possibly broadcasting the same programme with stronger signals. PTY Standby Reception allows the unit to switch temporarily to your favourite PTY programme from any source other than AM. To activate and select your favourite PTY code for PTY Standby Reception, see 15) <PTY-STANDBY> (If the PTY indicator lights up, PTY Standby Reception is activated. To activate the reception, tune in to another station providing these signals.

Programme Search Usually when you select a preset number, the station preset in that number is tuned in. If the signals from the FM Radio Data System preset station are not sufficient for good reception, this unit, using the AF data, tunes in to another frequency possibly broadcasting the same programme as the original preset station is broadcasting. All tracks will be played repeatedly until you change the source or eject the disc. Discs produce very little noise compared with other sources. Lower the volume before playing a disc to avoid damaging the speakers by the sudden increase of the output level. For MP3/WMA discs, select the desired folder, then the desired track by repeating the control dial procedures. You can use only one of the following playback modes at a time. REPEAT TRACK RPT : Repeats current track FOLDER RPT : Repeats current folder RANDOM FOLDER RND : Randomly plays all tracks of current folder, then tracks of next folders ALL RND : Randomly plays all tracks To cancel repeat play or random play, select "RPT OFF" or "RND OFF. Selects track Fast-forwards or reverses the track Disc title/Album name/performer (folder name)* = Track title (file name)* = Current track number with the elapsed playing time = Current track number with the clock time = (back to the beginning) * If the current disc is an audio CD, "NO NAME" appears. This unit can play MP3/WMA files stored in a USB device.

USB memory All tracks will be played repeatedly until you change the source or detach the USB device. USB devices produce very little noise compared with other sources. Lower the volume before playing a USB to avoid damaging the speakers by sudden increase of the output level. If you have turned off the power (without detaching the USB device). Pressing / SOURCE turns on the power and playback starts from where it has been stopped previously. â· If a different USB device is currently attached, playback starts from the beginning. Straightly pull it out from the unit. You can operate the USB device in the same way you operate the files on a disc. Avoid using the USB device if it might hinder your safety driving. â· Do not pull out and attach the USB device repeatedly while "READING" is shown on the display.

â· Do not start the car engine if a USB device is connected. â· This unit may not be able to play the files depending on the type of USB device. â· Operation and power supply may not work as intended for some USB devices. Make sure all important data has been backed up to avoid losing the data. Some USB devices may not work immediately after attaching USB device or turn on the power. â· For more details about USB operations, 22, 23. Listening to the other external components Turn on the connected component and start playing the source. Adjust the sound as you want. KD-R511 can be remotely controlled as instructed here (with an optionally purchased remote controller). We recommend that you use remote controller RM-RK50 with your unit.

Battery shall not be exposed to excessive heat such as sunshine, fire, or the like. Turns the power on if pressed briefly. When the power is on, pressing the button also mutes the sound or pauses.



[You're reading an excerpt. Click here to read official JVC KD-R511 user guide](http://yourpdfguides.com/dref/2821591)
<http://yourpdfguides.com/dref/2821591>

** Folder that is physically empty or folder that contains data but does not contain valid MP3/WMA track. Maximum Power Output: Continuous Power Output (RMS): Front/Rear: 50 W per channel Front/Rear: 20 W per channel into 4 , 40 Hz to 20 000 Hz at no more than 1% total harmonic distortion. Compact disc player Non-contact optical pickup (semiconductor laser) 2 channels (stereo) 5 Hz to 20 000 Hz 96 dB 98 dB Less than measurable limit Max. Design and specifications are subject to change without notice. JVC bears no responsibility for any loss of data in the USB mass storage class device while using this System. Microsoft and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. .*



[You're reading an excerpt. Click here to read official JVC KD-R511 user guide](#)

<http://yourpdfguides.com/dref/2821591>