



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JVC KD-R721BT. You'll find the answers to all your questions on the JVC KD-R721BT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JVC KD-R721BT
User guide JVC KD-R721BT
Operating instructions JVC KD-R721BT
Instructions for use JVC KD-R721BT
Instruction manual JVC KD-R721BT



Having TROUBLE with operation?
Please reset your unit
Refer to page of How to reset your unit

Vous avez des PROBLÈMES de fonctionnement?
Réinitialisez votre appareil
Référez-vous à la page intitulée Comment réinitialiser votre appareil

Dear Customer,
This apparatus is in conformance with the valid European directives and standards regarding electromagnetic compatibility and electrical safety.

European representative of Victor Company of Japan, Limited is:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Germany

Cher(e) client(e),
Cet appareil est conforme aux directives et normes européennes en vigueur concernant la compatibilité électromagnétique et à la sécurité électrique.

Représentant européen de la société Victor Company of Japan, Limited:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Allemagne


JVC



ENGLISH
FRANÇAIS

KD-R721BT

CD RECEIVER / RÉCEPTEUR CD



Radio Data System WMA MP3

For canceling the display demonstration, see page 4. / Pour annuler la démonstration des affichages, référez-vous à la page 4.

For installation and connections, refer to the separate manual. / Pour l'installation et les raccordements, se référer au manuel séparé.

JVC



INSTRUCTIONS MANUEL D'INSTRUCTIONS

EN, FR
© 2011 Victor Company of Japan, Limited

0111DTSMDTJEIN

GET0710-003A
[E/EU]



[You're reading an excerpt. Click here to read official JVC KD-R721BT user guide](http://yourpdfguides.com/dref/3940764)
<http://yourpdfguides.com/dref/3940764>

This unit supports the following Bluetooth profiles. 3 To use a Bluetooth device with this unit, connect the supplied USB Bluetooth Adapter (KS-UBT1) to one of the USB input terminals of the unit. Once the USB Bluetooth Adapter is attached, this unit is always available for pairing. Only one USB Bluetooth Adapter can be detected at a time. If you wish to perform complicated operations (such as dialing the numbers, using phonebook, etc.

), stop your car in a safe place. Some Bluetooth devices may not be connected to this unit depending on the Bluetooth version of the device. If you connect a different USB Bluetooth Adapter, all the registered devices and information will be cleared. This unit may not work for some Bluetooth devices.

Connecting condition may vary depending on the circumstances around you. If you turn off the unit, detach the control panel, or unplug the USB Bluetooth Adapter during a phone call conversation, the Bluetooth connection is disconnected. When the unit is turned off, the device is disconnected. If you wish to receive more information about Bluetooth, visit the following JVC web site: <<http://www>>. When you connect a Bluetooth device to the unit for the first time, make pairing between the unit and the device. Up to five devices can be registered in total.

Pairing sequence may be different from what is described below. Use the Bluetooth device to search and select "JVC Unit. Then, confirm the passkey on the unit by pressing the control dial. If <DELETE NO> is selected, the unit returns to step 4 above.

when <AUTO ANSWER> is activated. The unit answers the incoming calls automatically. During a phone call conversation. (As the number increases, the microphone becomes more sensitive. you can transfer a maximum of 400 numbers.

OFF : The unit does not connect the Bluetooth device automatically.

*2 Displayed only when a Bluetooth phone/audio player is connected. You can connect an Apple iPod/iPhone using the USB 2. Apple iPod/iPhone USB cable from the rear of the unit and/or USB 2. Avoid using the iPod/iPhone if it might hinder your safety driving. For <APP MODE>, applicable only for some audio applications.

Repeat this step until the desired track is selected. If the selected menu contains many tracks, you can fast search (± 10 , ± 100 , ± 1000) through the menu by turner is less than 50 W to prevent damaging the speakers. (The AF indicator lights up.) / WIDE : Subject to interference noises from adjacent stations, but sound quality will not be degraded and the stereo effect will remain. *7 The volume level automatically changes to "VOLUME 30" if you change to <LOW POWER> with the volume Level set higher than "VOLUME 30.

/ APP MODE : The sound of any functions (musics, games, applications, etc.) running on the connected iPod/iPhone is emitted through the speakers connected to this unit. NORMAL / FASTER / SLOWER : You can select the playback speed of the Audiobooks sound file in your iPod/iPhone. (Initial selected item depends on your iPod/iPhone setting.) If the USB Bluetooth Adapter is not connected to the unit, "PLEASE CNNT BT ADAPTER" scrolls on the display.

*11 Displayed only when any source other than "AM/ AUX IN" is selected separately. *12 Displayed only when a USB Bluetooth Adapter is connected to the unit and when any source other than Symptom Sound cannot be heard from the speakers. The unit does not work at all. general "AUX IN" cannot be selected. Sound is sometimes interrupted while listening to an external component connected to the auxiliary input jack.

The correct characters are not displayed (e. / Make sure the unit is not muted/paused. (page 25) Check to be sure the recommended stereo mini plug is used for connection. (page 21) This unit can only display letters (upper case), numbers, and a limited number of symbols. Symptom Disc cannot be played back.

CD-R/CD-RW cannot be played back and Insert a finalized CD-R/CD-RW (finalize with the component which track cannot be skipped. you used for recording). Disc playback Disc sound is sometimes interrupted. "NO DISC" appears on the display. Stop playback while driving on rough roads.

Disc cannot be played back. the disc cannot be ejected properly. Make sure nothing is blocking the loading slot. Do not use too many hierarchical levels and folders. Tracks do not play back in the order you have intended them to play.

The elapsed playing time is not correct. The playback order is determined when the files are recorded. This sometimes occurs during playback. This is caused by how the tracks are recorded on the disc. Do not use too many hierarchical levels and folders.

/ Turn off the power then on again. USB playback While playing a track, sound is sometimes interrupted. Tracks/folders are not played back in the order you have intended. skip to another file. The tracks have not been properly copied into the USB device. Copy tracks again into the USB device, and try again. the playback order is determined by the file name. an over-current occurs. Turn off, then turn on the unit. Check whether the track is a playable file format.

/ Check whether the connected USB device is compatible with this "NO USB" appears on the display. Connect the USB Bluetooth Adapter (KS-UBT1) to the unit before you can perform any operation. search from the Bluetooth device again. / Reset the unit, then search from the Bluetooth device again. Make sure you have entered the same PIN code to both the unit and target device. Reduce the distance between the unit and the Bluetooth mobile phone. / Move the car to a place where you can get a better signal reception. You may have tried to copy the same entries (as stored) to the unit. press DISP or T/P BACK to exit.

Reduce the distance between the unit and the Bluetooth audio player.

/ Disconnect the device connected for Bluetooth Phone. / Turn off, then turn on the unit. / Connect the player again, when the sound is not yet restored.

"VOICE" calling method is not successful. Use "VOICE" calling method in a more quiet environment.

/ Reduce the distance from the microphone when you speak the name. The unit is preparing to use the Bluetooth function. If the message does not disappear, turn off and turn on the unit, then connect the device again (or reset the unit). (page 3) Reset the unit and try the operation again. If "HW ERROR" appears again, consult your nearest JVC IN-CAR ENTERTAINMENT dealer.

Symptom The iPod does not turn on or does not work. The headphones are disconnected during playback. Check whether the connected iPod/iPhone is compatible with this unit. This unit can play back multi-session discs; however, unclosed sessions will be skipped while playing.



[You're reading an excerpt. Click here to read official JVC KD-R721BT user guide](http://yourpdfguides.com/dref/3940764)

<http://yourpdfguides.com/dref/3940764>

â· This unit can play back files with the extension code <. This unit can play back the files meeting the conditions below: For MP3/WMA discs: Â Bit rate: MP3/WMA: 5 kbps -- 320 kbps Â Sampling frequency: MP3: 32 kHz, 44. This unit can show WMA/WAV Tag and ID3 Tag Version 1. The search function works but search speed is not constant. â· This unit can play back files recorded in VBR (variable bit rate). The maximum number of characters for: Â Folder/file names : 25 characters (includes 4 extension characters--<.

This unit can recognize a total of 20 000 files, 2 000 folders (999 files per folder). However, the display can show until 999 folders/files. â· This unit cannot play back the following files: Â MP3 files: encoded in MP3i and MP3 PRO format; an inappropriate format; layer 1/2. Â WMA files: encoded in lossless, professional, and voice format; not based upon Windows MediaÂ® Audio; copy-protected with DRM. Microsoft and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other trademarks and trade names are those of their respective owners. Maximum Power Output : 50 W per channel Continuous Power Output (RMS) : 20 W per channel into 4 , 40 Hz to 20 000 Hz at no more than 1% total harmonic distortion. "Made for iPod," and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance.

Type : Compact disc player Signal Detection System : Non-contact optical pickup (semiconductor laser) Number of Channels : 2 channels (stereo) Frequency Response : 5 Hz to 20 000 Hz Signal-to-Noise Ratio : 102 dB Wow and Flutter : Less than measurable limit MP3 Decoding Format (MPEG1/2 Audio Layer 3) : Max. "Made for iPod," and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. The countries where you may use the BluetoothÂ® function .



[You're reading an excerpt. Click here to read official JVC KD-R721BT user guide](http://yourpdfguides.com/dref/3940764)

<http://yourpdfguides.com/dref/3940764>