



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for JVC KD-R821BT. You'll find the answers to all your questions on the JVC KD-R821BT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual JVC KD-R821BT
User guide JVC KD-R821BT
Operating instructions JVC KD-R821BT
Instructions for use JVC KD-R821BT
Instruction manual JVC KD-R821BT

Having TROUBLE with operation?
Please reset your unit
Refer to page of How to reset your unit

Vous avez des PROBLÈMES de fonctionnement?
Réinitialisez votre appareil
Référez-vous à la page intitulée Comment réinitialiser votre appareil

Dear Customer,
This apparatus is in conformance with the valid European directives and standards regarding electromagnetic compatibility and electrical safety.

European representative of Victor Company of Japan, Limited is:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Germany

Cher(e) client(e),
Cet appareil est conforme aux directives et normes européennes en vigueur concernant la compatibilité électromagnétique et à la sécurité électrique.

Représentant européen de la société Victor Company of Japan, Limited:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Allemagne

ENGLISH

FRANÇAIS

KD-R821BT
CD RECEIVER / RÉCEPTEUR CD

Detachable

Radio Data System

Made for

**WMA
MP3**

For canceling the display demonstration, see page 4. / Pour annuler la démonstration des affichages, référez-vous à la page 4.

For installation and connections, refer to the separate manual.
Pour l'installation et les raccordements, se référer au manuel séparé.

EN, FR
© 2011 Victor Company of Japan, Limited

INSTRUCTIONS
MANUEL D'INSTRUCTIONS

GET0717-003A
[E/EU]



[You're reading an excerpt. Click here to read official JVC KD-R821BT user guide](http://yourpdfguides.com/dref/3940760)
<http://yourpdfguides.com/dref/3940760>

Manual abstract:

CAUTION: Visible and/or invisible class 1M laser radiation when open. Do not view directly with optical instruments. Adjust the volume so that you can hear sounds outside the car. Driving with the volume too high may cause an accident. @ @ If you wish to dispose of this product and the battery, please do so in accordance with applicable national legislation or other rules in your country and municipality. By disposing of this product correctly, you will help to conserve natural resources and will help prevent potential negative effects on the environment and human health. Notice: The sign Pb below the symbol for batteries indicates that this battery contains lead. Digital devices (CD/USB) produce very little noise compared with other sources. @ @ @ @ @ @ @ @ How to reset your unit 13 14 17 17 Connecting a Bluetooth device Using a Bluetooth mobile phone Using a Bluetooth audio player Changing the Bluetooth settings

Be careful not to drop the disc when it ejects. â · If this does not work, reset your unit.

Cleaning the unit Wipe off the dirt on the panel with a dry silicon or soft cloth. Failure to observe this precaution may result in damage to the unit. Cleaning the connector Wipe off dirt on the connector of the unit and panel. 18 Listening to an iPod/iPhone 21 Listening to the other external components 21 Selecting a preset sound mode 22 Menu operations 26 Troubleshooting 29 Specifications condensation : When the car is airconditioned , moisture may collect on the laser lens. This may cause disc read errors.

In this case, remove the disc and wait for the moisture to evaporate. Temperature inside the car : If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit. If the temperature inside the car is below 0Â°C, the movement of animation and text scroll will be halted on the display to prevent the display from being blurred. appears on the display. When the temperature increases, and the operating temperature is resumed, these functions will start working again.

When you use the remote controller for the first time, pull out the insulation sheet. Battery shall not be exposed to excessive heat such as sunshine, fire, or the like. Do not install any battery other than CR2025 or its equivalent. Store the battery in a place where children cannot reach. â · Do not recharge, short, disassemble, heat the battery, or dispose of it in a fire. â · Do not leave the battery with other metallic materials. â · Do not poke the battery with tweezers or similar tools. â · Wrap the battery with tape and insulate when throwing away or saving it. This unit is equipped with the steering wheel remote control function. This unit can only play the CDs with: Handling discs: Â · On the disc, or use a disc with tape stuck on it.

â · Do not use any accessories for the disc. â · Clean from the center of the disc and move outward. â · Clean the disc with a dry silicon or soft cloth. Do not use any solvents. â · When removing discs from this unit, pull them out horizontally. â · Remove the rims from the center hole and disc edge before inserting a disc.

Discs with coloring on the recording surface or discs that are dirty. â · You cannot play a Recordable/ReWritable disc that has not been finalized. (For the finalization process refer to your disc writing software, and your disc recorder instruction manual. Attempt to insert using an adapter can cause malfunction. Detaches the panel When you press or hold the following button(s). Selects the available sources (if the power is turned on). Mutes the sound or pauses during playback. Hold the EQ button on the main unit to enter tone level adjustment directly. (page 21) Â · Enters "HF (hands-free) Menu" screen (page 14) or answers incoming call when the unit rings.

(page 16) Â · Ends a call [Hold]. Lights up when receiving an FM stereo broadcast with sufficient signal strength.] <Tuner>] <SSM>] <SSM 01 Â 06 / 07 Â 12 / 13 Â 18> "SSM" appears and local stations with the strongest signal are searched and stored automatically. To preset another 6 stations, repeat the above procedure by selecting one of the other SSM setting ranges. The following features are available only for FM Radio Data System stations.

News Standby Reception allows the unit to switch temporarily to your News programme from any source other than AM. to activate News Standby Reception , see <News-Standby>. (page 25) The unit will not switch to Traffic Announcement or News Standby Reception when a call connection is established through "BT FRONT/ BT REAR. You can tune in to a station broadcasting your favourite programme by searching for a PTY code. Network-Tracking Reception When driving in an area where FM reception is not sufficient enough, this unit automatically tunes in to another FM Radio Data System station of the same network, possibly broadcasting the same programme with stronger signals. If there is a station broadcasting a programme of the same PTY code as you have selected, that station is tuned in. TA Standby Reception allows the unit to switch temporarily to Traffic Announcement (TA) from any source other than AM. It will be applied the next time Traffic Announcement function is turned on. Programme Search Usually when you select a preset number, the station preset in that number is tuned in. If the signals from the FM Radio Data System preset station are not sufficient for good reception, this unit, using the AF data, tunes in to another frequency possibly broadcasting the same programme as the original preset station is broadcasting.

All tracks will be played repeatedly until you change the source or eject the disc. If the ejected disc is not removed within 15 seconds, it will automatically reload into the loading slot. If the MP3/WMA disc contains many tracks, you can fast search (Â±10, Â±100, Â±1 000) through the disc by turning the control dial quickly. For MP3/WMA disc, you can also use the search menu (A to Z, 0 to 9, and OTHERS) to scroll through the list menu. @ @ The track list with the selected character appears. Only the existing characters will be shown on the search menu. @ @ @ @ @ @ You can use only one of the following playback modes at a time. @ @ You can use these two terminals at the same time. @ @ @ @ @ @ Avoid using the USB device if it might hinder your safety driving.

@ @ @ @ â · When connecting a USB cable, use the USB 2.

Do not use a USB device with 2 or more partitions. @ @ â · This unit cannot recognize a USB device whose rating is other than 5 V and exceeds 1 A. â · Do not pull out and attach the USB device repeatedly while "Reading" is shown on the display. â · This unit may not recognize a memory card inserted into the USB card reader.



[You're reading an excerpt. Click here to read official JVC KD-R821BT user guide](http://yourpdfguides.com/dref/3940760)
<http://yourpdfguides.com/dref/3940760>

• Connect only one USB device to the unit at a time.

Operation and power supply may not work as intended for some USB devices. This unit can play back multi-session discs; however, unclosed sessions will be skipped while playing. • This unit can play back files with the extension code <. This unit can play back the files meeting the conditions below: For MP3/WMA discs: • Bit rate: MP3/WMA: 5 kbps -- 320 kbps • Sampling frequency: MP3: 32 kHz, 44. This unit can show WMA/WAV Tag and ID3 Tag Version 1.

The search function works but search speed is not constant. • This unit can play back files recorded in VBR (variable bit rate). The maximum number of characters for: • Folder/file names : 25 characters (includes 4 extension characters--<. This unit can recognize a total of 20 000 files, 2 000 folders (999 files per folder). • This unit cannot play back the following files: • MP3 files: encoded in MP3i and MP3 PRO format; an inappropriate format; layer 1/2. • WMA files: encoded in lossless, professional, and voice format; not based upon Windows Media® Audio; copy-protected with DRM. The Bluetooth devices can be connected without cables and communicate with each other. By connecting the supplied USB Bluetooth Adapter (KS-UBT1) to one of the USB input terminals of this unit, you can operate a Bluetooth device using this unit. Once the USB Bluetooth Adapter is attached, this unit is always available for pairing. • Only one USB Bluetooth Adapter can be detected at a time.

Refer to pages i and ii at the end of the document to check the countries where you may use the Bluetooth function. This unit supports the following Bluetooth profiles • If you wish to perform complicated operations (such as dialing the numbers, using phonebook, etc.), stop your car in a safe place. • Some Bluetooth devices may not be connected to this unit depending on the Bluetooth version of the device. • If you connect a different USB Bluetooth Adapter, all the registered devices and information will be cleared. • This unit may not work for some Bluetooth devices. • Connecting condition may vary depending on the circumstances around you. • If you turn off the unit, detach the control panel, or unplug the USB Bluetooth Adapter during a phone call conversation, the Bluetooth connection is disconnected. When the unit is turned off, the device is disconnected. @@@@Up to five devices can be registered in total.

"Pairing Full" appears if you try to pair the 6th device. Pairing sequence may be different from what is described below.

@@The unit answers the incoming calls automatically. During a phone call conversation. @@@@As the number increases, the microphone becomes more sensitive.

@@You cannot read, edit, or send a message through the unit. @@@@@@@@@@@@@@@@@@ you can transfer a maximum of 400 numbers. @@[Initial: 0000] Turn the control dial to select a number, press 4 / ¢lights *2. / Time Set : Sets the start/end timer for dimmer. @@Repeat this step to enter the end time.

@@@@May not work correctly on some vehicles (particularly on those having a control dial for dimming). In this case, change the setting to any other than <Dimmer Auto>. / Auto : Positive pattern will be selected during the day time *4; while negative pattern will be used during the night time *4. Level 01 -- Level 08 [Level 05] : Adjust the display contrast to make the display indications clear and legible. On : Boost low and high frequencies to produce a well-balanced sound at a low volume level. / Off : Cancels. Level Å5 -- Level +5 [Level 0] : Presets the volume adjustment level of each source (except "FM"), compared to the FM volume level. The volume level will automatically increase or decrease when you change the source. Before adjustment, select the source you want to adjust. LOW 55Hz / MID 85Hz / HIGH 120Hz : Frequencies lower than 55 Hz/ 85 Hz/ 120 Hz are sent to the subwoofer.

Frequencies lower than 62 Hz/ 95 Hz/ 135 Hz are cut off from the front/rear speakers. Low Power : Vol 0 Å Vol 30 (Selects if the maximum power of each speaker is less than 50 W to prevent damaging the speakers. *5 If you are using a two-speaker system, set the fader level to <00>. *8 The volume level automatically changes to "Vol 30" if you change to <Low Power> with the volume level set) / Wide : Subject to interference noises from adjacent stations, but sound quality will not be degraded and the stereo effect will remain. AF : When the currently received signals become weak, the unit switches to another station (the programme may differ from the one currently received). (The AF indicator lights up.) / AF REG : When the currently received signals become weak, the unit switches to another station broadcasting the same programme. / Application Mode : The sound of any functions (musics, games, applications, etc.) running on the connected iPod/iPhone is emitted through the speakers connected to this unit. @@(Initial selected item depends on your iPod/iPhone setting.

@@@@@The unit does not work at all. "AUX IN/ EXT IN" cannot be selected. General Sound is sometimes interrupted while listening to an external component connected to the auxiliary input jack. / Make sure the unit is not muted/paused. (page 25) Check to be sure the recommended stereo mini plug is used for connection.

The correct characters are not displayed This unit can only display letters (capital: A Å Z, small: a Å z), (e. Numbers (0 Å 9), a limited number of symbols (! Disc cannot be played back. CD-R/CD-RW cannot be played back and track cannot be skipped. Disc playback Disc sound is sometimes interrupted. Disc cannot be played back.

Insert a finalized CD-R/CD-RW (finalize with the component which you used for recording). Stop playback while driving on rough roads. This occurs sometimes due to over-heating. Make sure nothing is blocking the loading slot. @@Do not use too many hierarchical levels and folders. @@ have intended them to play. The elapsed playing time is not correct. This sometimes occurs during playback. This is caused by how the tracks are recorded on the disc.

@@Do not use too many hierarchical levels and folders.

/ Turn off the power then on again. @@Folders with order you have intended. Numbers on the initial of their names are sorted in numerical order. However, folders with no numbers on the initial of their names are sorted according to the file system of the USB device. While playing a track, sound is sometimes interrupted. The tracks have not been properly copied into the USB device. Copy tracks again into the USB device, and try again. Turn off, then turn on the unit. Check whether the connected USB device is compatible with this unit. Check whether the track is a playable file format.



[You're reading an excerpt. Click here to read official JVC KD-R821BT user guide](http://yourpdfguides.com/dref/3940760)
<http://yourpdfguides.com/dref/3940760>

/ Reset the unit, then search from the Bluetooth device again. Make sure you have entered the same PIN code to both the unit and target device. Reduce the distance between the unit and the Bluetooth mobile phone. / Move the car to a place where you can get a better signal reception. Reduce the distance between the unit and the Bluetooth audio player.

/ Disconnect the device connected for Bluetooth Phone. / Turn off, then turn on the unit. / Connect the player again, when the sound is not yet restored. Check whether the connected audio player supports AVRCP (Audio/Video Remote Control Profile). The sound is interrupted or skipped during playback of a Bluetooth audio player.

The unit does not response when you You may have tried to copy the same entries (as stored) to the unit. Tried to copy the phonebook to the unit. press DISP or T/P BACK to exit. "Voice" calling method is not successful. Use "Voice" calling method in a more quiet environment. / Reduce the distance from the microphone when you speak the name. / Change the "NR/EC Mode" to "Off" (page 15) , then try again. Connect the USB Bluetooth Adapter to the unit before you can perform any operation. If "Error" appears again, check if the device supports the function you have tried. The unit is preparing to use the Bluetooth function.

If the message does not disappear, turn off and turn on the unit, then connect the device again (or reset the unit). (page 3). Reset the unit and try the operation again. If "HW Error" appears again, consult your nearest JVC IN-CAR ENTERTAINMENT dealer. The headphones are disconnected during playback. Check whether the connected iPod/iPhone is compatible with this unit. The iPod does not turn on or does not work. Microsoft and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other trademarks and trade names are those of their respective owners. â· "Made for iPod," and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. Maximum Power Output : 50 W per channel Continuous Power Output (RMS) : 20 W per channel into 4 , 40 Hz to 20 000 Hz at no more than 1% total harmonic distortion. Type : Compact disc player Signal Detection System : Non-contact optical pickup (semiconductor laser) Number of Channels : 2 channels (stereo) Frequency Response : 5 Hz to 20 000 Hz Signal-to-Noise Ratio : 102 dB Wow and Flutter : Less than measurable limit "Made for iPod," and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. The countries where you may use the Bluetooth® function .



[You're reading an excerpt. Click here to read official JVC KD-R821BT user guide](#)

<http://yourpdfguides.com/dref/3940760>