



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KENWOOD KAC-M1804. You'll find the answers to all your questions on the KENWOOD KAC-M1804 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual KENWOOD KAC-M1804
User guide KENWOOD KAC-M1804
Operating instructions KENWOOD KAC-M1804
Instructions for use KENWOOD KAC-M1804
Instruction manual KENWOOD KAC-M1804

KENWOOD

KAC-M1804

COMBINATION CAR STEREO, AM/FM
INSTRUCTION MANUAL
MODE D'EMPLOI - INSTRUCTIONS
MANUAL DE INSTRUCCIONES
JVC KENWOOD Corporation

Register Online

Warranty Card

Model: _____

Serial No: _____

Date of Purchase: _____

Place of Purchase: _____

Authorized Dealer: _____

Signature: _____

SAFETY PRECAUTIONS

PRECAUTIONS DE SECURITE

PRECAUCIONES DE SEGURIDAD



You're reading an excerpt. [Click here to read official KENWOOD KAC-M1804 user guide](http://yourpdfguides.com/dref/5533332)
<http://yourpdfguides.com/dref/5533332>

Manual abstract:

KENWOOD USA CORPORATION WHO IS PROTECTED This warranty is enforceable only by the original purchaser. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. If a problem develops during or after the Limited Warranty Period, or if you have any questions regarding the operation of the product, you should contact your KENWOOD Authorized Dealer or Authorized Service Center. If the problem or your question is not handled to your satisfaction, please contact our Customer Relations Department at the address listed below: KENWOOD ELECTRONICS

CANADA INC. (e) Defects resulting from disaster, accident, abuse, misuse, lightning, power surges, neglect or lack of periodic maintenance, unauthorized modification or failure to follow instructions in the owner's manual. (f) Defects or damage as a result of repairs performed by a person or party not authorized by KENWOOD. (g) Defects resulting from the use of parts or devices that do not conform to KENWOOD specifications. (h) Damage or deterioration occurring to any exterior finishes, cosmetic parts, tape heads, adaptors, antennas, cables, tapes, discs or faults or damage caused by defective or leaking batteries. (i) Defects or damage occurring during shipping (claims should be presented to the shipping company). (hereinafter called "KENWOOD"), gives the following written warranty to the original customer of each new Kenwood product distributed in Canada by KENWOOD and purchased from a dealer authorized by KENWOOD.

Kenwood Corporation ("Kenwood") warrants this product for a period of one (1) year from the date of original purchase. **WHAT WE WILL PAY FOR** We will pay for all labor and material expenses for covered items. Payment of shipping charges is discussed in the next section of this warranty.

Take or ship it to any KENWOOD Authorized Service Center in the U. Along with & complete description of the problem.

3. Whenever your units are taken or sent for warranty service, you must include a copy of the original dated sales receipt as proof of warranty coverage. **WHAT IS COVERED AND WHAT IS NOT COVERED** Except as specified below, this warranty covers all defects in material and workmanship in Kenwood car stereo components. The following are not covered by the warranty: 1. Any product which is not distributed in the U.

By Kenwood or which is not purchased in the U. From an authorized Kenwood car stereo dealer or an automobile dealer, unless the product is purchased through the U. Any product on which the serial number has been defaced, modified or removed. Any shipment of the product (claims must be presented to the carrier). Accident, acts of nature, misuse, abuse, neglect, unauthorized product modification or failure to follow instructions supplied with the product. Any other cause which does not relate to a product defect. **DISCLAIMER** KENWOOD disclaims any responsibility for loss of time or use of the product or any other indirect, incidental or consequential damage to other products or goods, inconvenience or commercial loss. **INSTRUCTION MANUAL**

AMPLIFICATEUR COMPACT DIGITAL 4 CANAUX WARRANTY PERIOD This Kenwood product is warranted for parts and labour for a period of one (1) year from the date of original purchase, lease or rental, except for products which are used in a professional or commercial application, which are warranted for a period of ninety (90) days for parts and labour and are subject to the terms and conditions of the warranty. **TO OBTAIN WARRANTY SERVICE** Should your Kenwood product require warranty service, deliver it to any authorized KENWOOD service centre and present the original copy of your bill of sale and this warranty card as proof of warranty, or send your product fully insured and freight prepaid to the nearest authorized KENWOOD service centre. To avoid possible shipping damage, make sure the product is properly packed.

(b) Products purchased from a dealer not authorized by KENWOOD. (c) Products with the serial number defaced, altered or missing. (d) Periodic check-ups which do not disclose any defects covered by this warranty. Take the time to read through this instruction manual. Familiarity with installation and operation procedures will help you obtain the best performance from your new power amplifier. Attention: This card and receipt (or invoice) are necessary to purchase a new panel in case of theft or damage. For your records Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your Kenwood dealer for information or service on the product. Military exchange service overseas may be serviced under warranty in the continental U. , subject to the following conditions.

Safety precautions LIMITATION OF IMPLIED WARRANTIES Any and all implied warranties, including warranties of merchantability and fitness for a particular purpose, shall be limited in duration to the length of this warranty. **Précautions de sécurité Protection function** The protection function is activated in the following situations: This unit is equipped with a protection function for protecting this unit and your speakers from various accidents or problems that can occur. When detects a low impedance at the speaker connections. **gUAM: Kenwood Rep ; ; c/o Guam NEX No.**

The following are not covered by this warranty.

3. 4. House call charges for any repairs. Do not open the top or bottom covers of the unit. Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity.

Also avoid places with too much dust or the possibility of water splashing. When replacing a fuse, only use a new one with the prescribed rating. Using a fuse with the wrong rating may cause your unit to malfunction. To prevent a short circuit when replacing a fuse, first disconnect the wiring harness. **NOTE**

If you experience problems during installation, consult your Kenwood dealer. Do not turn the power on if the ground wire is not connected. Do not install the unit on rear tray, or air bag safety parts. The installation to the vehicle should securely fasten the unit to a place in which it will not obstruct driving. If the unit comes off due to a shock and hits a person or safety part, it may cause injury or an accident. After installing the unit, check to make sure that electrical equipment such as the brake lamps, turn signal lamps and windshield wipers operate normally.

Specifications Specifications subject to change without notice. 45 W × 4 Signal to noise ratio (Reference: 1Watt into 4 ohms) . (grosor: 15 mm o más) 3 Parts included Pieces comprises Partes incluidas 350 mm (13-3/4) Connection / Raccordements / Conexiones Remove the ignition key and disconnect the negative Terminal of the battery to prevent short circuits.



[You're reading an excerpt. Click here to read official KENWOOD](#)

[KAC-M1804 user guide](#)

<http://yourpdfguides.com/dref/5533332>

WARNING WARNING ADVERTENCIA Spécifications A-4 B-3 Fuse (15 A) NOTE If you can't find the specified capacity fuse at your store etc. , consult your Kenwood dealer. Fusible (15 A) A-6 2 Parts included Pieces comprises Parties incluidas L R R L White Blanc Blanco White/Black Blanc/Noir Blanco/Negro Gray Gris Gris Gray/Black Gris/Noir Gris/Negro Green Vert Verde Green/Black Vert/Noir Verde/Negro Purple Violet Purpúreo Purple/Black Violet/Noir Purpúreo/Negro FRONT L Particular attention must be given to making good electrical contact at the amplifier-output and speaker terminals. Poor or loose connections can cause sparking or burning at the terminals because of the very high power that the amplifier can deliver. 74 dBA L R FRONT REAR SPEAKER OUTPUT • If sound is not output normally, immediately turn power off and check connections. □ Be sure to turn the power off before changing the setting of any switch. @@@@ @ • Connect the speaker wires to appropriate speaker connectors separately.

Sharing the negative wire of the speaker or grounding speaker wires to the metal body of the car can cause this unit to fail. □ After installation, check that the brake lamps, turn signal lamps and windshield wipers work properly. 0,5 kg (1,1 libras) Type B: SPEAKER INPUT connection Type B: Raccordement SPEAKER INPUT Tipo B: Conexión SPEAKER INPUT FACTORY INSTALLED HEAD UNIT REAR R L R R L L R R L *2 *1 B-5 A-5 B-4 1 Parts included Pieces comprises Parties incluidas A-2 B-2 Ground wire (Black) Câble de masse (Noir) Cable de masa (Negro) FCC WARNING This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. @@@@ @@@@ However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. □ Increase the separation between the equipment and receiver. □ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. □ Consult the dealer or an experienced r.



[You're reading an excerpt. Click here to read official KENWOOD KAC-M1804 user guide](#)
<http://yourpdfguides.com/dref/5533332>