



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KONICA MINOLTA DI7210. You'll find the answers to all your questions on the KONICA MINOLTA DI7210 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual KONICA MINOLTA DI7210**  
**User guide KONICA MINOLTA DI7210**  
**Operating instructions KONICA MINOLTA DI7210**  
**Instructions for use KONICA MINOLTA DI7210**  
**Instruction manual KONICA MINOLTA DI7210**



KONICA MINOLTA

## Parts Catalog

The essentials of imaging

### **FN-10/FS-210**

1475



[You're reading an excerpt. Click here to read official KONICA MINOLTA DI7210 user guide](http://yourpdfguides.com/dref/592891)  
<http://yourpdfguides.com/dref/592891>

**Manual abstract:**

The part numbers listed in Parts Catalog are those which were assigned to the parts making up the machine at the time machine was originally introduced onto the market. Parts whose INDEX numbers are shown white against a black background in the illustration are those to be used in only certain market areas. These part numbers are given in the lower half part of the list section. Check the SFIX No. listed in SFIX CHART on page II to find which part number is applicable to your own area. Parts whose INDEX numbers are shown black against a white background in the illustration are those to be used in all market areas. These parts are listed on the upper half part of the list section. If "NS" follows a part number given in the list section, it indicates that we do not keep a stock of the part. The part is not required for ordinary service jobs, either. If "RP" is shown in the REC column of the list section, it indicates that the part is functionally important.

In the exploded views in this Parts Catalog the parts (Screws & Washes, etc...) which are indicated with a "four-digit" numbers are listed in numerical order in the section "SCREWS AND WASHERS". Please check these "four-digit" numbers with the part numbers ("ten-digit" numbers) which should be used for ordering the part.

All part numbers consist of "ten-digit" which should all be quoted when ordering a part. @@@@6. 7. 8. Parts Catalog SFIX CHART SFIX No. 612 COUNTRY EXCEPT JAPAN VOLTAGE FREQUENCY (Hz) PAPER SIZE SFIX No. 651 JAPAN COUNTRY VOLTAGE FREQUENCY (Hz) PAPER SIZE CONTENTS 1. 2. 3. 4. 5. 6. 7. 8. 9.

10. 11. 12. 13. 14. 15. 16. 17. 18. 19.  
20. 21. 22. 23. 24.

25. FRAME SECTION .....	1 HOUSING .....
.....	3 PAPER TRANSPORT SECTION (A) .....
.....	5 PAPER TRANSPORT SECTION (B) .....
.....	7 PAPER TRANSPORT SECTION (C) .....
.....	9
ELEVATOR DRIVE SECTION .....	11 SHIFT DRIVE SECTION .....
.....	13 PAPER EXIT SECTION .....
.....	15 DRIVE SECTION (A) .....
.....	17 DRIVE SECTION (B) .....
.....	19 STAPLER UNIT (A) .....
.....	21 STAPLER UNIT (B) .....
.....	23 STAPLER UNIT (C) .....
.....	25 STAPLER UNIT (D) .....
.....	27 STAPLER UNIT (E) .....
.....	29 STAPLER UNIT (F) .....
.....	41 WIRE HARNESS SECTION (C) .....
.....	43 WIRE HARNESS SECTION (D) .....
.....	45 SCREWS AND WASHERS .....
.....	47 NUMERICAL INDEX .....
.....	48 JANUARY 2004 II 1 FRAME SECTION 03 01 1703 FN-10 1 21 06 07 04 02 9105 1703 1704 05 05 9105 1704 20 1703 19 9112 08 9112 9112 08 1703 18 07 1703 1399 1703 17 17 09 10 15 1703 1703 1703 08 16 9105 16 11 1399 1703 9105 13 12 13 14 14 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 INDEX PART NO.



[You're reading an excerpt. Click here to read official KONICA MINOLTA DI7210 user guide](http://yourpdfguides.com/dref/592891)  
<http://yourpdfguides.com/dref/592891>

@@@4014-1010-01 9384-1010-31 1475-1001-01 ROLLER PART NAME PWB SUPPORT 11.11H CONTORL BOARD UNIT REC QTY 1 1 1 PHOTO INTERRUPTER BUSHING NS STOP PLATE SCREW NS SCREW RAIL RAIL NUT CASTOR SCREW STOPPER RUBBER NS ARM RETAINING RING TENSION SPRING PART NAME REC QTY SFIX 2 2 HOUSING FN-10 3 25 07 02 06 08 05 1504 03 04 02 01 27 26 28 29 10 24 1703 09 33 35 34 32 1703 31 10 30 10 1504 11 10 10 19 20 34 1504 12 14 16 15 18 2713 21 22 1703 36 13 17 3524 23 1703 INDEX 02 03 04 06 07 08 10 11 12 14 15 16 17 18 19 20 21 22 INDEX 01 01 05 05 09 09 13 13 24 24 25 25 27 27 32 32 PART NO. 4014-2364-01 4014-1125-01 4594-2216-01 1474-1029-01 1474-1028-01 4594-2213-01 4594-2007-01 4594-2029-01 1475-1006-01 4014-1239-01 4014-1701-01 4970-1018-01 4014-1020-01 4014-4005-01 4014-1301-01 4014-1250-01 4594-2009-01 4014-1249-01 PART NO.

4024-2132-01 4970-1011-01 4024-2133-01 4970-1009-01 4024-2134-01 4970-1007-01 4024-2135-01 4970-1008-01 4024-2136-02 4970-1015-01 4594-2189-01 4970-1012-01 4024-2137-01 4970-1013-01 1475-1004-01 1475-1005-01 TOP PLATE NS TOP COVER SIDE COVER/UPPER NS COVER SIDE COVER/LEFT NS COVER FRONT DOOR NS FRONT COVER REAR COVER NS REAR COVER COVER NS COVER TOP PLATE NS TOP COVER SIDE COVER/LOWER SIDE COVER/LOWER ROLL PRESSURE SPRING SHAFT NS COVER TRAY LABEL SCREW HANDLE NS LABEL ACTUATOR PLATE NS SCREW MAGNET CATCH SCREW SWITCH INSULATING SHEET SCREW COVER PART NAME REC QTY 4 2 2 1 1 1 5 1 1 1 2 2 2 1 1 1 1 1 INDEX 23 26 28 29 30 31 33 34 35 36 PART NO. 4014-1242-01 4024-3024-01 4970-1017-01 4594-2075-01 4970-1014-01 1474-1015-01 4970-1095-01 4594-2154-01 1475-1003-01 1475-1002-01 ACTUATOR SCREW NS GUIDE EARTH GROUND NS BRACKET PART NAME REC QTY 1 2 1 1 1 1 1 2 1 1 NEUTRALIZING BRUSH NS GUIDE GUIDE TRAY STOPPER PART NAME REC QTY 1 612 1 651 1 612 1 651 1 612 1 651 1 612 1 651 1 612 1 651 2 612 2 651 1 612 1 651 1 651 1 612 SFIX 4 3 PAPER TRANSPORT SECTION (A) 1704 FN-10 5 1704 2518 04 05 06 1704 03 01 16 23 15 9102 15 9102 22 02 9112 14 10 21 1704 11 09 20 07 1704 12 13 10 09 08 09 11 10 9112 19 18 17 A 9102 1703 14 12 13 15 9102 15 16 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 INDEX PART NO. 4970-1024-01 4970-1022-01 4970-1023-01 4024-2032-01 1474-1010-01 1474-1013-01 4970-1019-01 4970-1020-01 4014-2532-01 4014-1729-01 4014-1780-01 4594-2210-01 4014-2498-01 4970-1021-01 4014-1241-01 4594-2068-01 4594-2050-01 4014-1020-01 PART NO. NS GUIDE PLATE NS GUIDE PLATE GUIDE PART NAME REC QTY 1 1 1 1 1 1 1 3 3 2 2 2 4 4 1 1 INDEX 19 20 21 22 23 PART NO. 4594-2005-01 4594-2062-01 4594-2051-01 4594-2063-01 4594-2066-01 SCREW TORSION SPRING GUIDE TORSION SPRING SHEET PART NAME REC QTY 1 1 1 1 1 PHOTO INTERRUPTER ROLLER ROLLER NS GUIDE PLATE NS GUIDE PLATE BUSHING STOPPER RING BUSHING RETAINING RING BUSHING NS LABEL ROLLER TENSION SPRING GUIDE MAGNET CATCH PART NAME REC QTY SFIX 6 4 PAPER TRANSPORT SECTION (B) FN-10 7 17 09 10 08 07 01 01 02 11 01 06 05 04 03 22 25 23 18 01 C 17 9102 9102 A 24 23 B 20 21 22 1704 B 1704 19 C 1704 04 04 03 06 12 1704 9102 A 15 17 9102 1704 03 14 04 13 17 18 16 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 INDEX PART NO. 4024-2006-01 4380-1244-01 4594-2210-01 4014-2498-01 4014-2532-01 4014-1729-01 4594-2056-12 1474-1011-01 4594-2093-01 4594-2058-01 4970-1032-01 4970-1027-01 4594-2060-02 4970-1031-01 4970-1028-01 4970-1030-01 4014-1241-01 4594-2061-01 PART NO. PIN RETAINING RING BUSHING BUSHING STOPPER RING ROLLER TENSION SPRING GUIDE GUIDE KNOB GUIDE TENSION SPRING NS GUIDE PLATE GUIDE ROLLER TENSION SPRING PART NAME CONVEYANCE ROLLER REC RP QTY 4 1 4 5 1 2 1 1 1 1 1 1 1 1 1 4 4 INDEX 19 20 21 22 23 24 25 PART NO. 4970-1026-01 4970-1033-01 4970-1025-01 4594-2005-01 4014-1020-01 4594-2053-01 4970-1021-01 NS GUIDE PLATE GUIDE NS GUIDE PLATE SCREW MAGNET CATCH GUIDE NS LABEL PART NAME REC QTY 1 1 1 2 2 1 1 PART NAME REC QTY SFIX 8 5 PAPER TRANSPORT SECTION (C) 02 01 07 06 04 07 08 05 03 1704 FN-10 9 30 35 1704 1704 36 37 34 34 30 32 12 9112 29 13 10 1704 33 1704 09 11 10 10 11 32 31 9102 27 26 15 14 25 25 25 9105 9105 9105 9102 27 28 10 11 25 24 23 23 23 9112 12 13 A 16 9105 9105 23 1704 22 10 10 17 11 14 14 18 15 A 19 1704 21 1704 20 1704 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 INDEX PART NO. 1474-1011-01 4594-2074-01 4594-2088-01 4594-2069-01 4970-1036-01 1474-1012-01 4014-1055-01 4594-2070-01 4970-1034-01 4594-2210-01 4014-2498-01 4014-1780-01 4014-2382-01 4014-1729-01 4014-2532-01 4970-1021-01 4594-2093-01 4594-2059-01 4594-2064-01 PART NO. ROLLER ROLLER TENSION SPRING SHEET STOPPER ROLLER PAPER EXIT ROLLER SPONGE NS GUIDE PLATE RETAINING RING BUSHING BUSHING STOPPER RING BUSHING NS LABEL TENSION SPRING GUIDE TORSION SPRING PART NAME REC QTY 1 1 1 5 1 1 INDEX 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 PART NO.

4594-2007-01 4970-1037-01 4594-2065-01 4594-2039-01 4970-1038-01 4594-2061-01 4594-2052-12 4014-1241-01 4594-2072-01 1474-1003-01 4594-2077-01 4594-2076-01 4014-1023-01 4594-2001-01 4594-2082-01 4024-2184-01 4433-6752-01 4594-2078-01 SCREW NS GUIDE PLATE TORSION SPRING ROLL NS SPRING ROLL PIN TENSION SPRING GUIDE ROLLER TENSION SPRING NS GUIDE PLATE TORSION SPRING ACTUATOR PART NAME REC QTY 1 1 1 4 1 4 1 2 2 1 2 1 2 1 2 1 3 1 RP 10 1 1 6 4 2 2 3 2 1 1 1 1 PHOTO INTERRUPTER SCREW HOLDER EDGE COVER WIRING SADDLE ACTUATOR PART NAME REC QTY SFIX 10 6 ELEVATOR DRIVE SECTION 01 1705 FN-10 11 9112 FRONT 1703 1704 1703 1703 9112 26 27 B 1705 01 9112 9112 02 03 9115 24 1703 1703 B A 1704 25 04 1703 A 1717 23 03 08 07 06 26 27 22 1704 1703 18 20 9112 1703 09 C 07 06 9115 18 9112 21 9112 3726 10 1704 12 12 11 1704 1704 1704 1703 1703 9112 18 19 05 13 12 C 16 17 18 7202 0508 14 13 12 15 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 INDEX PART NO. 4594-2098-01 4594-2160-01 4014-1023-01 4594-2161-01 1474-1021-01 4014-1270-01 4594-2101-01 4594-2099-01 4594-2014-01 4024-2075-01 4014-1285-01 4594-2210-01 4014-2171-01 1474-1023-01 1474-1022-01 1474-1033-01 1474-1024-01 4014-1026-01 PART NO. PULLEY WIRE PART NAME REC QTY 2 1 2 1 1 2 2 1 3 1 1 4 2 INDEX 19 20 21 22 23 24 25 26 27 PART NO. 1474-1019-01 1474-1020-01 4014-2803-01 1474-1031-01 1474-1030-01 4594-2097-01 1474-1018-01 4970-1039-01 4594-2100-01 GEAR GEAR PLATE PAPER TRAY/2 PAPER TRAY/1 ACTUATOR PART NAME REC QTY 1 1 1 1 1 1 1 4 4 PHOTO INTERRUPTER WIRE GEAR PULLEY BALL BEARING HOLDER PIN DC BRUSHLESS MOTOR PULLEY 16T RETAINING RING BUSHING PULLEY WORM WASHER TIMING BELT BUSHING PART NAME REC 93L 16T NEUTRALIZING BRUSH NS SHAFT ROLL 1 1 1 4 QTY SFIX 12 7 SHIFT DRIVE SECTION FN-10 13 1704 03 1704 01 02 1703 21 B 1703 1683 19 08 20 04 18 04 21 A 04 05 04 B 04 07 06 08 11 9105 12 17 A 9112 04 04 9112 9105 13 12 1704 9102 11 10 09 16 9102 14 14 15 INDEX 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 INDEX PART NO.



You're reading an excerpt. [Click here to read official KONICA MINOLTA DI7210 user guide](http://yourpdfguides.com/dref/592891)  
<http://yourpdfguides.com/dref/592891>





