




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY TX3TH. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY TX3TH in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

## User manual LA CROSSE TECHNOLOGY TX3TH User guide LA CROSSE TECHNOLOGY TX3TH Operating instructions LA CROSSE TECHNOLOGY TX3TH Instructions for use LA CROSSE TECHNOLOGY TX3TH Instruction manual LA CROSSE TECHNOLOGY TX3TH

### 433MHz Thermo Hygro Outdoor Transmitter for use with the Weather Station

Congratulations on purchasing this optional 433 MHz Thermo Hygro Outdoor Transmitter for use with the Weather Station. Please read the following information to ensure that this transmitter works correctly.



#### FEATURES OF THE THERMO HYGRO OUTDOOR TRANSMITTER

- Remote transmission of outdoor temperature and outdoor relative humidity via 433MHz to base Weather Station.
- LCD display showing current outdoor temperature in Celsius (°C) and current outdoor relative humidity in RH (%).
- Wall mounting holder.

#### SETTING UP:

Before activating the Thermo Hygro Outdoor Transmitter for use with the base receiver Weather Station, ensure all batteries are removed from each of the units for at least 30 seconds before proceeding with these steps:

1. Insert 2 x AA, IEC LR6, 1.5V batteries, observing correct polarity, into the battery compartment of the Weather Station.
2. Unscrew the screw on the back of the Thermo Hygro Outdoor Transmitter compartment and remove the cover.
3. Insert the 2 x AAA, IEC LR3, 1.5V batteries, observing correct polarity, into the battery compartment.
4. Replace battery cover on unit and seal by re-screwing.
5. Repeat step 2-4 for each additional Thermo Hygro Outdoor Transmitter.



Immediately after power-up, the LCD segments will light up briefly on the base receiver Weather Station before displaying the current outdoor temperature in °C and the current outdoor relative humidity in %. When the Thermo Hygro Outdoor Transmitter has transmitted data by 433MHz, it will register accordingly on the LCD of the base receiver. For full operating instructions, please refer to the main instruction manual for the Weather Station.

#### Notes:

- Setting up should not take longer than three minutes to complete otherwise start up problems may occur.
- When installing the batteries always check the correct polarity before inserting and ensure the batteries do not spring free from the contacts otherwise start up problems may occur.

- If setting up has taken over three minutes, then reset the units (see "Resetting" below).

#### 433MHZ SIGNAL RECEPTION


If the outdoor temperature and the outdoor relative humidity are not received by the base Weather Station twice after setting up, the display on the Weather Station will show "- - °C" and "- - %", please check the following points:

1. Distance transmitters at least 2 meters away from any interfering sources such as computer monitors or TV sets or antennas
2. Avoid placing the temperature transmitter onto or in the immediate proximity of metal window frames.
3. Using other electrical products such as headphones or speakers operating on the 433MHz frequency may prevent reception of the transmitted data. Interference can also be caused by neighbours using similar electrical devices.


#### AFFIXING THE THERMO HYGRO OUTDOOR TRANSMITTER:

The Thermo Hygro Outdoor Transmitter has a holder and is supplied with screws and double-sided tape for affixing either by method preferred. Before securing the transmitter to the desired location, check that the temperature can be received first.

#### To affix by screw, follow these steps:



#### To affix using double-sided tape, follow these steps:



**Note:** Do not secure the transmitter on metal frames or doors because this may cause interference with 433MHz transmission.

#### RESETTING

There are times when the receiver unit and the Thermo Hygro Outdoor Transmitter need to be reset for example a changing of batteries.

1. Remove the batteries from each unit and wait at least 30 seconds
2. Proceed from step 1 in Setting up.

#### BATTERY CHANGE:

For best performance and running accuracy the batteries of all units should be replaced at least once a year.

**!** Please help in the preservation of the environment and return used batteries to an authorized depot only.

#### MAINTENANCE:

- Avoid locations prone to extreme temperatures, vibration and shock since these may cause damage and inaccurate readings.
- Do not submerge any of the units in water or use them

- Avoid placing the units in any way other than what they have been designed for.
- Remove all low powered batteries immediately to avoid leakage and damage. Replace only with new batteries of the recommended type.
- Do not make any repairs to the units. Return to the original point of purchase for repair by qualified personnel.

#### THERMO HYGRO OUTDOOR TRANSMITTER SPECIFICATIONS:

- Temperature measuring range: -29.9°C to +59.9°C with 0.1°C resolution
- Relative Humidity measuring range: 1% to 99% with 1% resolution
- Transmission interval: every 1 minute
- Transmission frequency: 433.92 MHz
- Transmission range: 25 meters maximum
- Power Source: 2 x AAA, IEC LR3, 1.5V
- Dimensions (L x W x ): 56 x 24 x 80 mm

#### LIABILITY DISCLAIMER:

- The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences occurring should an inaccurate reading take place.
- This product is not to be used for medical purposes or for public information.
- The specifications of this product may change without prior notice.
- This product is not a toy. Keep out children's reach.
- No part of this manual may be reproduced without written consent of the manufacturer.

#### R&TTE Directive 1999/5/EC

Summary of the Declaration of Conformity: We hereby declare that this wireless transmission device does comply with the essential requirements of R&TTE Directive 1999/5/EC.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY TX3TH user guide](http://yourpdfguides.com/dref/1116231)  
<http://yourpdfguides.com/dref/1116231>

**Manual abstract:**

3. Distance transmitters at least 2 meters away from any interfering sources such as computer monitors or TV sets or antennas Avoid placing the temperature transmitter onto or in the immediate proximity of metal window frames. Using other electrical products such as headphones or speakers operating on the 433MHz frequency may prevent reception of the transmitted data. Interference can also be caused by neighbours using similar electrical devices. Avoid placing the units in any way other than what they have been designed for. Remove all low powered batteries immediately to avoid leakage and damage.

Replace only with new batteries of the recommended type. Do not make any repairs to the units. Return to the original point of purchase for repair by qualified personnel. Outdoor temperature display in °C Holder THERMO HYGRO OUTDOOR TRANSMITTER SPECIFICATIONS: · Temperature measuring range: -29.

· 9°C to +69.9°C with 0.1°C resolution · Relative Humidity measuring range: 1% to 99% with 1% resolution · Transmission interval: every 1 minute · Transmission frequency: 433.92 MHz · Transmission range: 25 meters maximum · Power Source: 2 x AAA, IEC LR3, 1.5V · Dimensions (L x W x ): 56 x 24 x 80 mm LIABILITY DISCLAIMER: · The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences occurring should an inaccurate reading take place.

· This product is not to be used for medical purposes or for public information. @@ · This product is not a toy. Keep out children's reach. @@@@ To affix by screw, follow these steps: 1. @@ Drill the marked area to the required depth.

@@@@ · Wall mounting holder. @@2. 3. 4. 5. @@@@ Replace battery cover on unit and seal by re-screwing. @@3. To affix using double-sided tape, follow these steps: 1. 2. 3.

Clean both surfaces before affixing doublesided tape. @@ Now peel the other side of the tape and stick the holder firmly onto the surface. Do not stick onto bricks, enamel finished or greasy surfaces. R&TTE Directive 1999/5/EC Summary of the Declaration of Conformity : We hereby declare that this wireless transmission device does comply with the essential requirements of R&TTE Directive 1999/5/EC. Battery cover Note: Do not secure the transmitter on metal frames or doors because this may cause interference with 433MHz transmission. Immediately after power-up, the LCD segments will light up briefly on the base receiver Weather Station before displaying the current outdoor temperature in °C and the current outdoor relative humidity in %. When the Thermo Hygro Outdoor Transmitter has transmitted data by 433MHz, it will register accordingly on the LCD of the base receiver. For full operating instructions, please refer to the main instruction manual for the Weather Station. Notes: · Setting up should not take longer than three minutes to complete otherwise start up problems may occur. @@1.

2. @@ · Do not submerge any of the units in water or use them .



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY TX3TH user guide](http://yourpdfguides.com/dref/1116231)  
<http://yourpdfguides.com/dref/1116231>