



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY WS8002. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY WS8002 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual LA CROSSE TECHNOLOGY WS8002**  
**User guide LA CROSSE TECHNOLOGY WS8002**  
**Operating instructions LA CROSSE TECHNOLOGY WS8002**  
**Instructions for use LA CROSSE TECHNOLOGY WS8002**  
**Instruction manual LA CROSSE TECHNOLOGY WS8002**

WS 8002 Manual  
Instruction Manual



**Technical data:**

- ▶ Time and date
- ▶ Time in 12/24 hour format
- ▶ Calendar
- ▶ Date and weekday display
- ▶ Temperature display in °C or °F
- ▶ Weekday display in seven languages: English, German, Italian, French, Danish, Dutch, Spanish
- ▶ Alarm with Snooze function
- ▶ Thermometer. Indoor measurement ranges: **0°C - 50°C**
- ▶ Battery: 1.5V "AA" size x 1 pc (not included)

**Important information:**

- ▶ When you insert the batteries all the symbols on the display will briefly light up and you will hear a signal tone, LCD full display for 2 seconds with beeping

**Manual time setting:**

- ▶ Press and hold down the "SET" button for 2 seconds, the 12/24 hour mode display starts to flash. Now use "▲" and "▼" buttons to set the correct 12/24 hour mode.
- ▶ Press "SET" to confirm your setting, the offset display starts to flash. Now use "▲" and "▼" buttons to set the correct hour.
- ▶ Press "SET" to confirm your setting, the Minute displays starts to flash. Now use "▲" and "▼" buttons to set the correct minute.
- ▶ Press "SET" to confirm your setting, the Year display 2004 starts to flash. Now use "▲" and "▼" buttons to set the correct year.
- ▶ Press SET to confirm your setting, the Month display starts to flash. Now use "▲" and "▼" buttons to set the correct month.
- ▶ Press "SET" to confirm your setting, the Date display starts to flash. Now use "▲" and "▼" buttons to set the correct date.
- ▶ Press "SET" to confirm your setting, the language selection for the Weekday displays starts to flash. Now use "▲" and "▼" buttons to select a language.
- ▶ Press "SET" to confirm your setting and to end the setting procedures, enter the clock mode.

**Info:**

- ▶ After 30 seconds without pressing any button, the clock switches automatically from set mode to normal time mode.

**Setting the daily alarms:**

- To view the set alarm times, under the clock mode, press once ALARM button, LCD displays the ((●)) icon.
- ▶ Press and hold down the ALARM button for 2 seconds until Alarm Time flashing icon is displayed. Now use the "▲"



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS8002 user guide](http://yourpdfguides.com/dref/3678220)  
<http://yourpdfguides.com/dref/3678220>

**Manual abstract:**

5V "AA" size x 1 pc (not included) Important information: When you insert the batteries all the symbols on the display will briefly light up and you will hear a signal tone, LCD full display for 2 seconds with beeping Manual time setting: Press and hold down the "SET" button for 2 seconds, the 12/24 hour mode display starts to flash. Now use "" and "" buttons to set the correct 12/24 hour mode. Press "SET" to confirm your setting, the offset display starts to flash. Now use "" and "" buttons to set the correct hour. @@@@Now use "" and "" buttons to set the correct year. Press SET to confirm your setting, the Month display starts to flash. Now use "" and "" buttons to set the correct month. Press "SET" to confirm your setting, the Date display starts to flash. Now use "" and "" buttons to set the correct date. Press "SET" to confirm your setting, the language selection for the Weekday displays starts to flash.

Now use "" and "" buttons to select a language. Press "SET" to confirm your setting and to end the setting procedures, enter the clock mode. Info: After 30 seconds without pressing any button, the clock switches automatically from set mode to normal time mode. Setting the daily alarms: To view the set alarm times, under the clock mode, press once ALARM button, LCD displays the ((( ))) icon. Press and hold down the ALARM button for 2 seconds until Alarm Time flashing icon is displayed.

Now use the "" WS 8002 Manual and "" buttons to select the alarm time you require and briefly press the ALARM button to set this Alarm time. The Hour display of the Alarm time starts to flash. Use the "" and "" buttons to set the required hour. @@@@In this case the alarm will be repeated automatically after 24 hours. @@Then Snooze function is active.

The ((( ))) icon appears on the display. @@@@individual models. @@· Precautions shall be taken when handling the batteries. @@@@Replace only with new batteries of the recommended type. @@@@· Do not submerge the unit in water. @@The liquid crystals can be harmful to user's health. · Do not make any repair attempts to the unit. @@Opening and tampering with the unit may invalidate their guarantee. · Never touch the exposed electronic circuit of the device as there is a danger of electric shock should it become exposed. · Do not expose the units to extreme and sudden temperature changes, this may lead to rapid changes in forecasts and readings and thereby reduce their accuracy.

Liability Disclaimer · The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment WS 8002 Manual ······ Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste. The unrestricted disposal of electronic waste may do harm on public health and the quality of environment. This product must however not be thrown in general rubbish collection points. As stated on the gift box and labeled on the product, reading the "User manual" is highly recommended for the benefit of the user. @@@@Weather forecasts given by this product should be taken only as an indication and not as being totally accurate. The specifications of this product may change without prior notice. This product is not a toy. Keep out of the reach of children.

No part of this manual may be reproduced without written consent of the manufacturer. R&TTE Directive 1999/5/EC Summary of the Declaration of Conformity: We hereby declare that this wireless transmission device does comply with the essential requirements of R&TTE Directive 1999/5/EC. .



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS8002 user guide](http://yourpdfguides.com/dref/3678220)  
<http://yourpdfguides.com/dref/3678220>